


- Ⓡ :TO POWER SUPPLY/RF SECTION
- Ⓢ :TO SYSTEM CONTROL & SERVO SECTION
- Ⓥ :TO LUMINANCE & CHROMINANCE/AUDIO SECTION
- Ⓐ :TO HI-FI AUDIO SECTION

- VIDEO MAIN SIGNAL PATH IN REC MODE
- VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
- AUDIO MAIN SIGNAL PATH IN REC MODE
- AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE



TV	
1	AUDIO OUT (R)
2	AUDIO IN (R)
3	AUDIO OUT (L)
4	GND (A)
5	GND
6	AUDIO IN (L)
7	
8	PB +12V
9	GND
10	IIC CLOCK
11	
12	IIC DATA
13	GND
14	GND
15	
16	
17	GND
18	GND
19	VIDEO OUT
20	VIDEO IN
21	GND

NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS(Ⓡ ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR.(SP MODE)
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT THE BRACKETS(Ⓡ ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL.(SP MODE)
NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.