





A	TUNER AUDIO (R)		←	(A1)
A	TUNER AUDIO (L)		←	(A2)
S	AUDIO DEF	→		(A3)
S	SYS IIC DATA	→		(A4)
S	SYS IIC CLOCK	→		(A5)
V	TUNER AUDIO (N)		←	(A6)
V	TUNER VIDEO		←	(A7)
S	AFC S-CURVE	→		(A8)
S	SW2	→		(A9)
S	VIDEO OUT	→	→	(A10)
A	RFC AUDIO OUT	→	→	(A11)



DU7601		
19	SW1	PK0701-1
20	SW2	PK0701-2
21		PK0701-3
22	SIF/QPSK	PK0701-4
23	AFC S-CURVE	PK0701-5
24	TUNER VIDEO	PK0701-6
25	TUNER SV	PK0701-7
26		PK0701-8
27	GND	PK0701-9

TO TV DEMODULATOR  
PACK PK0701(0-1)

PK7301	
1	SIF/QPSK
2	GND
3	TUNER AUDIO (N)
4	—
5	—
6	—
7	TUNER 5V

TO NICAM DECODER PACK  
PK7301 (D-1)

PK7302	
1	SYS IIC CLOCK
2	SYS IIC DATA
3	—
4	TUNER AUDIO (R)
5	GND
6	TUNER AUDIO (L)

O NICA M DECODER PACK  
PK7302 (C-1)

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.