


VIDEO SIGNAL PATH

AUDIO SIGNAL PATH



PP0701 (TO TUNER)		
1	AGC	
2	IF	
3	GND	
4		

PK0701		
DU7601-19	SECAM VL (H)	1
DU7601-20	SECAM (H)	2
DU7601-21	TUNER AUDIO(N)	3
DU7601-22	SIF/OPSK	4
DU7601-23	AFC S-CURVE	5
DU7601-24	TUNER VIDEO	6
DU7601-25	UNREG 5.6V	7
DU7601-26	SW 12V	8
DU7601-27	GND	9

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.