






G
F
E
D
C
B
A


- (R) :TO POWER SUPPLY/RF SECTION
(S) :TO SYSTEM CONTROL & SERVO SECTION
(V) :TO LUMINANCE & CHROMINANCE/AUDIO SECTION
(A) :TO HI-FI AUDIO SECTION



VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
AUDIO MAIN SIGNAL PATH IN REC MODE



AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE



TV

| | |
|----|---------------|
| 1 | AUDIO OUT (R) |
| 2 | AUDIO IN (R) |
| 3 | AUDIO OUT (L) |
| 4 | GND (A) |
| 5 | GND |
| 6 | AUDIO IN (L) |
| 7 | BLUE |
| 8 | PB +12V |
| 9 | GND |
| 10 | CONTROL |
| 11 | GREEN |
| 12 | GND |
| 13 | GND |
| 14 | GND |
| 15 | RED |
| 16 | BLANKING |
| 17 | GND |
| 18 | GND |
| 19 | VIDEO OUT |
| 20 | VIDEO IN |
| 21 | GND |

DECODER/EXT

| | |
|----|---------------|
| 1 | AUDIO OUT (R) |
| 2 | AUDIO IN (R) |
| 3 | AUDIO OUT (L) |
| 4 | GND (A) |
| 5 | GND |
| 6 | AUDIO IN (L) |
| 7 | BLUE |
| 8 | PB +12V |
| 9 | GND |
| 10 | IIC CLOCK |
| 11 | GREEN |
| 12 | IIC DATA |
| 13 | GND |
| 14 | GND |
| 15 | RED |
| 16 | BLANKING |
| 17 | GND |
| 18 | GND |
| 19 | VIDEO OUT |
| 20 | VIDEO IN |
| 21 | GND |

NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR.(SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.(SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.