


VIDEO MAIN SIGNAL PATH IN REC MODE AUDIO MAIN SIGNAL PATH IN REC MODE
 VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE



NOTE : DO NOT USE ANY PARTS NUMBER SHOWN ON THIS SCHEMATIC
 DIAGRAM FOR ORDERING.
 WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.