

(P) :TO POWER TRANSFORMER SECTION
(S) :TO SYSTEM CONTROL & SERVO SECTION
(V) :TO LUMINANCE & CHROMINANCE/AUDIO SECTION

G

F


E

D

C

B

A



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS
SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU
ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-SJ30AF
POWER SUPPLY SECTION IN MAIN SCHEMATIC DIAGRAM