



## 8 SCHEMATIC DIAGRAMS

### 8.1. POWER TRANSFORMER SECTION IN MAIN SCHEMATIC DIAGRAM






## 8.2. SYSTEM CONTROL & SERVO SECTION IN MAIN SCHEMATIC DIAGRAM







NV-SJ30AF  
SYSTEM CONTROL & SERVO SECTION IN MAIN  
SCHEMATIC DIAGRAM

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR  
ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

12


13

14

15

16


17



NV-SJ30AF  
SYSTEM CONTROL & SERVO SECTION IN MAIN  
SCHEMATIC DIAGRAM

17 18 19


## 8.3. LUMINANCE & CHROMINANCE/ AUDIO SECTION IN MAIN SCHEMATIC DIAGRAM













## 8.4. POWER SUPPLY SECTION IN MAIN SCHEMATIC DIAGRAM





DO NOT USE ANY PART NUMBER SHOWN ON THIS  
SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU  
ORDER A PART, PLEASE REFER TO PARTS LIST.

NV-SJ30AF  
POWER SUPPLY SECTION IN MAIN SCHEMATIC DIAGRAM

6


7

8


9

10


## 8.5. KEY SWITCH & LED DRIVE SECTION IN MAIN SCHEMATIC DIAGRAM




## 8.6. FRONT SCHEMATIC DIAGRAM



## 8.7. SECAM SECTION IN MAIN SCHEMATIC DIAGRAM



IN PLAYBACK MODE



NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NV-SJ30AF  
SECAM SECTION IN MAIN SCHEMATIC DIAGRAM