


F
E
D
C
B
A

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

TO LUMINANCE & CHROMINANCE/
AUDIO SECTION P5501(E-23)

FSC	1
GND	2
C SYNC	3
Y/C VIDEO OUT	4
VIDEO 5V	5
PB SECAM	6
V.EE	7
REC C SECAM	8
SECAM	9
RF CHROMA	10



NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS() ON THIS DIAGRAM IS RECORD MODE
WITH SECAM COLOUR.(SP MODE)
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE
WITH SECAM COLOUR SIGNAL.(SP MODE)

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS
SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU
ORDER A PART,PLEASE REFER TO PARTS LIST.

1 2 3 4 5 6 7 8 9