

A

B

C

D

E

F

1

C MAIN P.C.B. (SIDE : A)

(SIDE : B)

2

3



4

5

6


7

8




To **B** LCD P.C.B.(CN202)

A SD CARD P.C.B. (SIDE : A)




(SIDE : B)




(REP3244A-S)

To **C** MAIN P.C.B.(CN1)

B LCD P.C.B. (SIDE : A)



(SIDE : B)



(REP3244A-S)