







**M5218AFPE3
IC301
BUFFER AMP**

Buffer amp.
-B1 +B7

- JK401**
- 1 Lch OUT
 - 2 A.GND
 - 3 Rch OUT
 - 4 MUTE
 - 5 POWER
 - 6 +B(13V)
 - 7 LED CNT
 - 8 CT
 - 9 D.GND
 - 10 -B(13V)
 - 11 +B(15V)
 - 12 +B(10V)
 - 13 KEY SE
 - 14 JOG A
 - 15 JOG B
 - 16 +B(5.6V)
 - 17 -B(-30V)
 - 18 FL1
 - 19 FL2
 - 20 SYNC

To Amplifier Block Diagram

To CD Player/
Cassette Deck
Block Diagram

To Mini Disc Deck
Block Diagram

**M5M34051FPE1
IC502
DIFFERENTIAL RECEIVER**

- JK403**
- 1 LED CNT
 - 2 CLK+
 - 3 CLK-
 - 4 CS
 - 5 +B(10V)
 - 6 DATA+
 - 7 DATA-
 - 8 MD REQ
 - 9 IO SEL
 - 10 CHREQ
 - 11 D.GND
 - 12 Rch IN
 - 13 D.GND
 - 14 Lch IN
 - 15 A.GND
 - 16 Rch OUT
 - 17 A.GND
 - 18 Lch OUT
 - 19 LOAD SW

**LC72722PMTLM
IC501
RDS DECODER**

**TC74HCT7007A
IC503
BUFFER AMP**

- Notes)
- Signal line
 - ◀ FM signal
 - ▶ AM signal
 - ⏏ FM OSC signal
 - ⏏ AM OSC signal
 - () indicates pin No. of right channel.