

SCHEMATIC DIAGRAM - 3

— : +B Line

⇨ : FM Signal Line

⇨ : AM Signal Line


⇨ : FM/AM Signal Line

⇨ : FM OSC Signal Line

⇨ : AM OSC Signal Line

**B** MAIN/TUNER CIRCUIT


**J** TUNER CIRCUIT



**SCHEMATIC DIAGRAM-4**

- : +B Line
- - - : -B Line
- ⇒ : Main Signal Line
- ⇒ : AUX Signal Line
- ⇒ : Playback Signal Line
- ⇒ : CD Signal Line
- ⇒ : FM/AM Signal Line
- ⇒ : Record Signal Line

**B MAIN/TUNER CIRCUIT**



**C**  
TO PANEL  
CIRCUIT  
(CP605) ON  
SCHEMATIC  
DIAGRAM-6


**K**  
TO DECK  
CIRCUIT  
(H1001/W1001)  
ON SCHEMATIC  
DIAGRAM-8

# SCHEMATIC DIAGRAM-5

————— : +B Line

- - - - - : -B Line

⇒ : Main Signal Line



TO POWER CIRCUIT (CP500) ON SCHEMATIC DIAGRAM-7

TO POWER CIRCUIT (CP501) ON SCHEMATIC DIAGRAM-7

TO MOTOR CIRCUIT (CN1) ON SCHEMATIC DIAGRAM-9

TO PANEL CIRCUIT (CP604) ON SCHEMATIC DIAGRAM-6