

NO.	PART NUMBER	PART NAME	CONNECTION
①	LSUA0030	11Pin Extension Cable	FP6 on Main C.B.A. - SD Holder F.P.C. of Side Case L Unit
②	LSUA0020	20Pin Extension Cable	FP9 on Main C.B.A. - Zoom Switch F.P.C. of Side Case L Unit
③	VFKW0124A	14Pin Extension Cable	FP301 on Main C.B.A. - CCD F.P.C. on Lens Unit
④	VUVS0012	22Pin Extension Cable	FP701 on Main C.B.A. - Lens F.P.C. on Lens Unit
⑤	LSUA0017	18Pin Extension Cable	FP4 on Main C.B.A. - Capstan F.P.C. on Mechanism Chassis Ass'y
⑥	LSUA0016	10Pin Extension Cable	FP3 on Main C.B.A. - Cylinder F.P.C. on Mechanism Chassis Ass'y
⑦	VUVS0007	12Pin Extension Cable	FP5 on Main C.B.A. - Head Amp F.P.C. on Mechanism Chassis Ass'y
⑧	VUVS0015	28Pin Extension Cable	FP2 on Main C.B.A. - Mechanism F.P.C. on Mechanism Chassis Ass'y