



Reassembly Notes:

1. Installation of S Brake Drive Lever, Tension Drive Arm

- 1) Confirm that the Intermediate Gear, Main Plate Unit, Mode Switch, and Cam Gear are in proper position. Refer to "Cam Gear."
- 2) Install the S Brake Drive Lever so that the Cam Follower Pin on S Brake Drive Lever is inserted to outside groove on the Cam Gear.
- 3) Install the Tension Drive Arm so that the Cam Follower Pin on Tension Drive Arm is inserted to inside groove on the Cam Gear.