



42 Lock Pick Lever



41 Lock Lever Unit



Reassembly Notes:

1. Installation of Lock Lever Unit

1) Install the Lock Lever Unit so that Pin A and Pin B are inserted to slots on Lock Lever Unit and Guide Pin on chassis is inserted to slot on Lock Lever Unit.