

Note:
This hole on Reduction
Gear is not used to align.

Gear of
Loading Motor
Unit

⑨ Reduction Gear B

⑩

Gear of
Mode Switch

