


VIDEO MAIN SIGNAL IN REC MODE
 VIDEO MAIN SIGNAL IN PLAYBACK MODE
 AUDIO MAIN SIGNAL IN REC MODE
 AUDIO MAIN SIGNAL IN PLAYBACK MODE

AV JACK
 VEJ1378



NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

1

2

3

AV JACK C.B.A. (VEP00X57A)

