

Model :107S21/97C CM23 GS3

Parts indicated on exploded view

1	3138 127 50070	FRONT CABINET ASSY
41	3138 104 54090	FRONT CABINET
49	3138 104 54100	BUTTON-FUNCTION
47	3138 104 53710	BUTTON POWER
2	3138 127 50080	BACK COVER ASSY
42	3138 104 54110	BACK COVER
3	3138 107 98400	PEDESTAL ASSY
44	3138 104 48610	BASE-PEDESTAL
53	3138 104 48600	SWIVEL-PEDESTAL
1151	9301 833 90323	CRT 17" M41EHN323X160/G341BA
1156	3138 178 51901	107S2(71K)-P MAIN PCB ASSY
1157	3138 178 50681	107S2(71K)-P VIDEO PCB ASSY
1158	3138 178 51911	107S2(71K)-P KEY CNTR PCB ASSY
601	3138 117 02630	E-DFU assy -V/E (CD-ROM+ Quick Start Guide)
602	3138 117 02640	E-DFU (CD-ROM Disc)-V/E
178	3138 105 40011	Quick start guide (Western Europe Languages)
450	3138 106 58361	CARTON
451	3138 106 56352	CUSHION-TOP-L
452	3138 106 56342	CUSHION-TOP-R
454	3138 106 56581	PE BAG
1053	2438 070 98118	MAINS CORD (125V)
1054	3138 168 72841	I/F CABLE
1101	2422 086 00208	FUSE T4AH/ 250V
5113	3138 168 72851	POWER TRANSFORMER
5601	3138 178 77941	LINEARITY COIL
5612	3138 168 73091	L.O.T(LCE)
7101	9322 135 00687	MOS TRANSTER SSP7N60A
7102	9352 645 03112	TEA1504AP/N2 14P
7112	9337 711 00686	IC TL431
7113	9335 282 90682	IC L7808CT
7114	9335 107 20682	IC L7805CV
7501	9352 637 56112	IC TDA4841PS-V2 32P
7606	9340 299 10127	TRANSTER BU2522AF
7613	9311 010 33687	TRA MOW TIP122
7685	9340 258 70126	TRA SIG MPSA44
7701	9322 145 97667	LM2439T 9P
7801	8238 274 39611	CPU 6148-K420PH-12A 42P
7803	9322 126 62682	IC M24C16-BN6 8P