
















STABILIZING CIRCUIT +5V



To	3193
	3194
	3195
	3197
	7175

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24


1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24


1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24


1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24




1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24














REFER TO CDC MECHANISM- CDM12.1





Дис 27 Принципиальная схема



« баску управления
механизмом проигрывателя
компакт-диск CDC

For software V76


1807
T024 1 H POS' (HOME SW)
T023 2 SW1
T022 3 SW2
T021 4 SW3 (DISK LOCK)





1808
T020 1 STORE'
T019 2 EJECT'
T018 3 DISK DETECT'
T017 4 DISK COUNT'
T016 5 CENTRE POS OVER'
T015 6 0V (GND)
T014 7 +5V


1802
T028 1 FRONT (OPEN)
T027 2 REAR (CLOSE)
T026 3 DOWN
T025 4 UP


1804
T009 7 LO
T008 6 GNDA
T007 5 RO
T006 4 RESET
T005 3 ACKN
T004 2 STROBE
T003 1 DATA

1805
T002 2
T001 1









Горющие трансформеры

