

Service  
Service  
**Service**

Product Service Group CE Audio

# Service Information

Already published Service Informations:

## SPARE PART CODENUMBERS FOR SERVICE CATEGORY I PRODUCTS

This publication gives a survey of service spareparts for those typenumbers for which no service manual has been published.

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AE1000	9965 000 03271	9965 000 03262			4822 101 11476			9965 000 03270	HANDLE 9965 000 03263
AE1505	9965 000 04070	9965 000 04071			9965 000 04073		9965 000 04069	9965 000 04068	HANDLE 9965 000 04072
AE1605	9965 000 07190	9965 000 07191			9965 000 07189			9965 000 07188	HANDLE CLIP 9965 000 07192
AE2110	4822 303 14079	4822 442 01735					4822 267 31921	4822 240 10349	DC JACK 4822 267 31966 HANDLE 4822 498 10725
AE2150	4822 303 14079	4822 442 01735					4822 267 31921	4822 240 10349	AC/DC ADAPTOR 120V UL 4822 219 10663 AC/DC ADAPTOR 230V 4822 219 10658 AC/DC ADAPTOR 240V UK 4822 219 10662 DC JACK 4822 267 31966 HANDLE 4822 498 10725
AE2170		4822 442 01715						4822 240 10347	BAND SWITCH KNOB 4822 410 12242 BATT DOOR SHIELDING 4822 466 12156 CLOCK MODULE RING 4822 532 13117 HANDLE 4822 498 10723 INSULATOR BAND SWITCH 4822 532 13116
AE2180		4822 442 01715						4822 240 10347	BAND SWITCH KNOB 4822 410 12242 BATT DOOR SHIELDING 4822 466 12156 CLOCK MODULE RING 4822 532 13117 HANDLE 4822 498 10735 INSULATOR BAND SWITCH 4822 532 13116
AE2340	4822 303 30481	4822 423 41271			4822 101 30869	220V		4822 240 30728	TACT SWITCH 4822 276 13576
AE2380	9965 000 02254	9965 000 02230			9965 000 02253	230V	4822 267 31921	9965 000 02252	HANDLE SWITCH-POWER 9965 000 02251 SWITCH-SLEEP 9965 000 02250
AE3350	4822 526 10618	4822 426 60658			4822 101 40171			4822 240 30741	ANTENNA CONTACT 4822 290 81702 IC CXA1019S 4822 209 15034 SUPPORTER 4822 417 11246 TUNING KNOB 4822 413 41904 VOLUME KNOB 4822 413 41905
AE6360		4822 443 10497			4822 101 30872				HEADPHONE AY3677/09 9965 000 07194
AE6370		9965 000 07193							
AE6565		9965 000 01981			4822 101 11457		4822 267 31862		
AE6570		9965 000 01981			4822 101 11457		4822 267 31862	4822 240 10141	7 OHM

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AE6775		4822 442 01891			4822 101 11457		4822 267 31862		EARPHONE AY3656 4822 242 11054
AE6780		4822 442 01891			4822 101 11457		4822 267 31862	4822 240 10141 7 OHM	EARPHONE AY3656 4822 242 11054
AJ3000		4822 442 01756			4822 101 21256			4822 240 10357 32 OHM	TACT SWITCH (HOR) 4822 276 13499 TACT SWITCH (VER) 4822 276 13872
AJ3005 (AJ3016) (AJ3017) (AJ3018) (AJ3019)		4822 442 01756			4822 101 21256			4822 240 10357 32 OHM	AC/DC 120-230V/7.5V 4822 219 10673 AC/DC 120V/7.5V 250MA 4822 219 10675 AC/DC 230V/7.5V 250MA 4822 219 10677 AC/DC 240V/7.5V 250MA 4822 219 10674 TACT SWITCH (HOR) 4822 276 13499 TACT SWITCH (VER) 4822 276 13872
AJ3010		9965 000 06622			9965 000 06624	230V VDE 240V BS 120V UL 230V ARG		9965 000 06623 8 OHM	
AJ3050 (AJ3051) (AJ3052)		9965 000 11401			9965 000 11403			9965 000 11402 32 OHM	AC/DC ADAPTOR 230V 9965 000 11405 AC/DC ADAPTOR 240V BS 9965 000 11571 DC JACK TC18-099-03 9965 000 11404
AJ3120		9965 000 06681			9965 000 06683	230V VDE 240/05 BS 230V ARG 120V UL		9965 000 06682 8 OHM	
AJ3125		9965 000 11401			9965 000 07811	230V VDE 240V BS		9965 000 06623 8 OHM	
AJ3130		3140 114 29480			4822 101 21256	230V 120/230V		4822 240 10276 8 OHM	DISPLAY LTC-637D1G-W 4822 130 90817 IC LM8560B 4822 209 71497 TACT SWITCH 2422 128 02923
AJ3140 (AJ3141) (AJ3142) (AJ3143) (AJ3144)		4822 423 41163			4822 101 21256	120/230V 120V UL 230V VDE 230V WHI 240V 240V WHI		4822 240 10118 8 OHM	DISPLAY LTC637D1G-W 4822 130 90817 IC LM8562 4822 209 32851 KNOB CLOCK FUNCTION 4822 410 10398 KNOB LOCK WHI 4822 410 10417 TACT SWITCH 4822 276 13577 VOLTAGE SELECTOR 4822 272 10225
AJ3145		4822 423 41163			4822 101 21256	120V UL 230V VDE		4822 240 10118 8 OHM	DISPLAY LTC637D1G-W 4822 130 90817 IC LM8562 4822 209 32851 TACT SWITCH 4822 276 13577

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AJ3220		9965 000 06711			9965 000 06712	120V UL 230V VDE 230V ARG		9965 000 06623	8 OHM
AJ3225		9965 000 06711			9965 000 07811	230V VDE 240V BS 120VUL		9965 000 08025	8 OHM
	/05							9965 000 06623	8 OHM
AJ3230		9965 000 08706			9965 000 08707	230V VDE 240V BS 120VUL		9965 000 06682	8 OHM
AJ3260		9965 000 09455			9965 000 09453	230V VDE 240V BS 120VUL		9965 000 09450	8 OHM
AJ3380		4822 423 41163			4822 101 11868	120/230V 120V 230V 240V		4822 240 10041	8 OHM
AJ3430					9965 000 05552	230V VDE 120V UL		9965 000 05551	16 OHM
AJ3480		4822 423 41163			4822 101 11868	120/230V 120V 230V 240V		4822 240 10041	8 OHM
AQ4150	4822 303 14031	4822 442 01893	4822 492 42776	4822 443 11263	4822 100 30197	120/230V 230V 240V	4822 267 31923	4822 240 30757	8 OHM
	/..S								

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AQ4460	3140 118 71480	3140 114 21550	4822 492 70231	3140 114 21540	2122 373 00014	120/230V 3140 118 32240		8240 008 67110 8240 008 67120	ARM-HANDLE(L) ARM-HANDLE(R) DAMPER ASSY EJECT SLIDER HEAD - ERASE HEAD - R/P LENS-CASS DOOR MAIN BELT 42.3X1.2 MICROPHONE MOTOR 3140 114 25270 3140 114 25280 4822 529 10322 4822 403 70968 4822 249 40306 4822 249 10565 3140 113 21600 9965 000 00678 4822 242 10786 4822 361 21641
AQ5150	4822 303 14003	4822 442 01892	4822 492 42775	4822 443 11262	4822 100 30195 4822 100 30196	120/230V 230V 4822 146 31477 4822 146 31475	4822 267 31921	4822 240 30756	AC SOCKET VDE CASSETTE DOOR LENS EJECT HOOK A ERASE HEAD HANDLE MAIN BELT MOTOR EG-530-AD-9F R/P HEAD MS15R-AA-2N1 ROLLER ARM ASSY 4822 267 31891 4822 381 12107 4822 403 70968 4822 249 40306 4822 498 10739 4822 358 31257 4822 361 21765 4822 249 10397 4822 528 70695
AQ5160	4822 303 14058	4822 443 10569	4822 492 11401	4822 443 10568	4822 101 11744 4822 101 11745 (BAL)	120/230V 4822 146 10759	4822 277 21794	4822 240 10215	CASSETTE DOOR LENS CONDENSER MIC. DAMPER ASSY E. HEAD EJECT HOOK A HANDLE LEAF SPRING LEAF SWITCH MAIN BELT A MAINS CABLE SBC1201 MOTOR MOTOR PULLEY PINCH ROLLER ARM PINCH ROLLER ASSY R/P HEAD SOCKET MAINS SUB BELT 4822 450 10296 4822 242 10046 4822 529 10257 4822 249 40306 4822 403 70968 4822 498 10642 4822 492 11399 4822 278 90663 4822 358 31257 4822 321 10249 4822 361 21765 4822 528 81497 4822 528 70849 4822 528 70695 4822 249 30218 4822 265 20318 4822 358 31124

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AQ5460	3140 118 71480	4822 443 11219	4822 492 42709	4822 443 11218	4822 101 21163 4822 101 11963	120/230V 4822 146 11159	4822 265 11317	4822 240 10379 8 OHM	BELT-F.F. BELT-MAIN DAMPER ASSY HEAD, ERASE HEAD, R/P LENS-CASS DOOR MAINS SOCKET MICROPHONE MOTOR POWER SWICH PULLEY-MOTOR ROLLER ARM ASSY SLIDER-EJECT SWITCH-LEAF TA8227P VOLTAGE SELECTOR
AQ6340		4822 443 10279	4822 492 11097	4822 443 10278	4822 100 20868		4822 265 10504	4822 240 10151 8 OHM	CASSETTE DOOR LENS COUNTER COUNTER BELT DC JACK E. HEAD MIC MOTOR PHONE JACK (BLACK) R/P HEAD PUSH SWITCH SW1 SLIDE SWITCH SW2 SLIDE SWITCH SW5 SLS KONB SPEAKER GRILLE SWITCH CONTACT TAPE DECK VZRS KNOB
AQ6345 (AQ6346)		9965 000 03639	9965 000 03642	9965 000 03640	9965 000 03646		9965 000 03649	9965 000 03645 8 OHM	CASS DECK HT23-16 CASS DOOR LENS CONDENSOR MIC COUNTER BELT MICROPHONE JACK SPEAKER 36MM 8 OHM TAPE COUNTER

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AQ6455		4822 443 10766	4822 492 11454	4822 443 10767	4822 100 11349	120/230V 230V	4822 265 11029	4822 240 30576	BELT COUNTER 4822 358 10217 CASSETTE DOOR LENS 4822 450 10378 CONDENSER MIC 4822 242 10786 E. HEAD 4822 249 40306 JACK MIC (BLACK) 4822 265 11028 MAIN BELT 4822 358 10218 MOTOR EG-530AD-6F 4822 361 21779 R/P HEAD 4822 249 30218 SUB BELT 4822 358 31124 TAPE COUNTER 4822 349 11027 VOLTAGE SELECTOR 4822 272 10225
AQ6455		4822 443 10783	4822 492 11483	4822 443 10784	4822 105 11128 4822 100 20874 (TONE)	120/230V 230V	4822 265 11029	4822 240 30635	BELT COUNTER 4822 358 10222 CASSETTE DOOR LENS 4822 381 11901 CONDENSER MIC 4822 242 10786 DAMPER ASSY 4822 529 10257 E. HEAD 4822 249 40276 IC TDA1904 4822 209 81953 JACK MIC (BLACK) 4822 265 11028 MAIN BELT 4822 358 10218 MOTOR MMN-6S9RX 4822 361 11007 R/P HEAD 4822 249 10486 SUB BELT 4822 258 31124 TAPE COUNTER 4822 349 11027 VOLTAGE SELECTOR 4822 272 10225
AQ6487		4822 442 01053	4822 492 11463	4822 443 10803			4822 265 10949		BELT CLIP 4822 401 11694 DC JACK 4822 265 20685 MOTOR PULLEY 4822 358 10199 MOTOR RF-410CA 2V 4822 361 21613 PLAY HEAD P-5044 4822 249 30209 TAPE DECK TN-44-102 4822 691 10594
AQ6491		4822 442 01739			4822 101 11429		4822 267 31862		BELT CLIP 4822 401 11801 CASS MECHANISM MCT-7 4822 691 10516 EARPHONE AY3650 4822 242 10745
AQ6492		4822 442 01739			4822 101 11429		4822 267 31862		BELT CLIP 4822 401 11801 CASS MECHANISM MCT-7 4822 691 10516 EARPHONE AY3650 4822 242 10745
AQ6495		9965 000 09158			9965 000 09157		9965 000 09159		BELT CLIP 9965 000 09160 DC JACK 9965 000 09161 EARPHONE AY3651 9965 000 02257 TAPE DECK TN-8 9965 000 09162

MODEL	AERIAL	BATTERY COVER	CASSETTE DOOR SPRING	CASSETTE DOOR	VOLUME CONTROL	TRANSFORMER	HEADPHONE SOCKET	LOUDSPEAKER	MISCELLANEOUS
AQ6581		4822 443 10897			4822 101 11429		4822 267 31862		BELT CLIP CASS MECHANISM MCT-7 EARPHONE AY3640/17 4822 401 11734 4822 691 10516 4822 242 10865
AQ6582		4822 442 01714	4822 492 11727	4822 443 11144	4822 101 11429		4822 267 31862		BELT CLIP (GREY) CASSETTE DECK MCT-7 EARPHONE AY3650 4822 401 11798 4822 691 10516 4822 424 10745
AQ6583		4822 443 10897			4822 101 11429		4822 267 31862		BELT CLIP CASS MECHANISM MCT-7 DC JACK 4822 401 11734 4822 691 10516 4822 265 10662 4822 424 10745
AQ6595		9965 000 09164			9965 000 09157		9965 000 09159		BELT CLIP DC JACK EARPHONE AY3651 TAPE DECK TN-8 9965 000 09165 9965 000 09166 9965 000 02257 9965 000 09162
AQ6591		9965 000 03651	9965 000 03653	9965 000 03652	4822 101 11429		4822 267 31862		BELT CLIP TAPE DECK MCT-7 9965 000 02826 4822 691 10516
AQ6598		9965 000 02824	9965 000 02825	9965 000 02823	4822 101 11429		4822 267 31862		BELT CLIP DC JACK TAPE DECK TN-44-106 9965 000 02826 9965 000 02827 9965 000 02828
AQ6601		9965 000 09168			4822 101 11429		4822 267 31862		BELT CLIP DC JACK EARPHONE AY3651 TAPE DECK MCT-7 9965 000 02256 4822 265 10662 9965 000 02257 4822 691 10516
AQ6681		4822 443 10928	4822 492 11618	4822 443 10929	4822 101 11429		4822 267 31862		BELT CLIP CASS DOOR LENS CASS MECHANISM MCT-7 DC JACK EARPHONE AY3650 4822 401 11734 4822 450 10497 4822 691 10516 4822 265 10662 4822 242 10745
AQ6682		4822 443 10928	4822 492 11775	4822 443 11257	4822 101 11429		4822 267 31862		BELT CLIP CASS MECHANISM MCT-7 DC JACK EARPHONE AY3640/17 LOCK BUTTON PRESET KEY 4822 401 11734 4822 691 10516 4822 265 10662 4822 242 10865 4822 410 12496 4822 410 12495
AQ6691		9965 000 02255			4822 101 11429		4822 267 31862		BELT CLIP TAPE DECK MCT-7 9965 000 02256 4822 691 10516