


DIAGRAM-SCHALTBILD-SCHEMA C

CHANNEL SELECTOR
KANALWAHLELER
SELECTTORE CANALE

IF AMPL.+DET. +AGC +AFC
ZF VERST. +DEM. +AVR. -AFA.
AMPL. FI +RIVEL. CAG. +CAF.

CHROMINANCE + LUMINANCE
FARBART + LEUCHTDICHTE
CROMINANZA + LUMINANZA

R-G-B AMPLIFIER
R-G-B VERSTAEKER
AMPLIFICATORE R-V-B



SEE SERVICE MANUAL
REMARKS
SIEHE ANMERKUNGEN
IN DER SERVICE
DOKUMENTATION
VEDERE NOTE SU
DOCUMENTAZIONE

REMARKS-ANMERKUNGEN-NOTE

- 1) -NOT PRESENT FOR PAL/SECAM SETS
- NICHT PRESENT IN PAL/SECAM GERAEETEN
- ASSENTE SUI MODELLI CON PAL/SECAM

