


11. SCHEMATIC CIRCUIT DIAGRAM

TUNER AMP UNIT




NOTE:
 □ Symbol indicates a resistor.
 No differentiation is made between chip resistors and discrete resistors.
 —|— Symbol indicates a capacitor.
 No differentiation is made between chip capacitors and discrete capacitors.

Decimal points for resistor and capacitor fixed values are expressed as:
 2.2→2R2
 0.022→R022

The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

Fig. 7



● Circuit diagram
 (KEH-1400/X1M/UC, 1450/X1M/ES, 1311/X1M/UC, 1100/X1M/UC, 1150/X1M/ES)

