

## Powerware Gold Plans are designed to fit your single-phase UPS needs.

Match the available plans to the product	Gold	Gold Plus	On-Site Gold	On-Site Gold Plus
<b>3110</b>	S	-	-	-
<b>3115</b>	S	-	-	-
<b>5115</b>	S	-	-	-
<b>5125</b>	S	A	-	-
<b>5140</b>	S	-	A	-
<b>Prestige 650-2000VA</b>	S	-	-	-
<b>Prestige 2.5 - 6kVA</b>	B	-	A	-
<b>9104</b>	-	-	S	-
<b>9120</b>	S	A	A+	A+
<b>9125, 700 - 2000VA</b>	S	-	S	-
<b>9150 Profile</b>	B	-	S	-
<b>9170+</b>	S	S	A	A+
B = Basic                      S = Standard                      A = Advanced				

### Feature summary for each plan

	Gold	Gold Plus	On-Site Gold	On-Site Gold Plus
Start-up service* (M-F, 5 x 8)		X	X	X
Unit Performance Check** (M-F, 5 x 8)				Annual**
Battery Performance Check** (M-F, 5 x 8)				Annual**
Guaranteed 24 Hour Response ***			X	X
On-Site Corrective Maintenance* (M-F, 5 x 8)			X	X
Expedited Delivery of Replacement Parts, Modules and Batteries	X	X	X	X
Standard Battery Coverage	X	X	X	X
Telephone Technical Support	X	X	X	X
Connectivity Support	X	X	X	X

\* Upgradable to 7 x 24 service.

\*\* Initial unit start-up serves as the Annual performance check during the first year of operation; subsequent PMs are scheduled on request from Customer beginning in the second year of operation.

\*\*\* Unit must be within 100 miles of Powerware established service location, and based on type of coverage in effect to qualify for 24 hour response.

Specifications subject to change without notice