FERRUPS CTO Configuration Guide



FERRUPS FE500VA 60 HZ

Invensys Powerware Division 2727 Kurtz Street San Diego, CA 92110 U.S.A. 800.356.5794 www.powerware .com



FE500VA CTO Configuration Guide

Configuring Your FERRUPS UPS

FERRUPS must be ordered using a Configure To Order (CTO) Number that reflects the cabinet style, VA rating, voltages, runtime, and other options pertaining to the FERRUPS configuration. As you select the options needed, they will become part of the CTO number.

Sample CTO Number: FA000BB2A0A0A0A. See page 500-4 for a CTO worksheet.

External battery packs, bypass switches and other external options will need to be ordered as separate line items.

Base Unit						
Base Model, Frequency, Cabinet Style	CTO Order Code	Base Price				
FE500VA, 60 Hz Tower	FA	\$849				

Input / Output Voltage						
Input Voltage	Output Voltage	CTO Order Code	Base Price			
120	120	0	\$0			
208	120/208	1	\$150			
208	120/240	2	\$150			
240	120/240	3	\$150			
240	240 (International Models)	6	\$150			
220	127/220	7	\$150			

Battery and Battery Charger								
Battery Configuration Battery Charger CTO Order Code Option Pri								
9 minute internal	standard	0	\$100					
20 minute internal	standard	1	\$150					
75 minute internal	standard	2	\$264					
Set up for internal (less batteries)	standard	3	\$49					
set up for external battery pack1	standard	4	\$48					
set up for external battery pack ¹	15 amp internal upgrade ²	6	\$548					

¹ Includes External Battery Connector Order desired external battery pack as a separate line. See page 500-3.

² Required for external battery packs 24me and 25me

Internal Maintenance Bypass Switch							
Internal Maintenance Bypass Switch CTO Order Code Option F							
No internal maintenance bypass switch option available ¹	0	\$0					

¹External maintenance bypass switch available for hardwired systems. Order desired maintenance bypass switch as a separate line item on your order. See page 500-3.

FE500VA CTO Configuration Guide

Input Connection							
Input Voltage Selected	Input Connection	CTO Order Code	Option Price				
Any	Hardwired ¹	А	\$40				
400 - 11	5-15P ²	В	\$ 0				
120 volt	L5-15P ²	Н	\$15				
000 000 040	6-15P ²	Е	\$ 0				
208, 220, 240	IEC320 – Jumper Cord ³	0	\$15				

¹ Hardwired input requires hardwired output

Output Connection

Output Connection Configuration is designated by 8 digits within the unit CTO number. These eight digits allow selection of the type and quantity for up to four different types of receptacles.

Output Voltage Required	Output Connection	CTO Order Code	Option Price	
Any	Hardwired ¹	A0A0A0A0	\$0	
	(2) 5-15R Duplex	B2A0A0A0	\$0	
120 volt only	(1) 5-15R Duplex (1) L5-15R Duplex	B1G1A0A0	\$75	
	(2) L5-15R Duplex	G2A0A0A0	\$75	
208, 220, 240 only	(2) 6-15R Duplex	D2A0A0A0	\$150	
208, 220, 240 only	(4) IEC320	U1A0A0A0	\$100	
Mixed Voltages	(1) 5-15R Duplex (1) 6-15R Duplex	B1D1A0A0	\$75	
120/208, 120/240, or 127/220	(1) L5-15R Duplex (1) 6-15R Duplex	D1G1A0A0	\$150	

¹ Hardwired output requires hardwired input

Internal Options							
Option	CTO Order Code	Option Price					
No other option	A	\$0					
AVR (recommended when loads contain PFC power supplies)	В	\$100					
Caster Kit (if ordered with unit)	С	\$100					
Anchor Kit for structural slab floor	D	\$200					
Anchor Kit for raised or access floor	Е	\$200					
AVR and Caster Kit	Н	\$200					
AVR and Anchor Kit for structural slab floor	I	\$300					
AVR and Anchor Kit for raised or access floor	J	\$300					
Neutral to Ground bond removal (For Shipboard Use)	Q	\$25					
Neutral to Ground bond removal and AVR (For Shipboard Use)	R	\$125					

² NEMA line cord requires NEMA receptacles

³ International line cord requires international receptacles

FE500VA CTO Configuration Guide

External Options

External battery packs, bypass switches and other external options are not a part of the CTO number and will need to be ordered as separate line items. Some external options require that the UPS be configured for use with the option.

External Battery Packs							
Runtime Full/Half Battery Charger Required Order Number Lis							
3h40m/10h22m	Standard Battery Charger ¹ 15 Amp Battery Charger Upgrade Optional	21me	\$638				
7h50m/22h09m	15 Amp Battery Charger Upgrade ¹	24me	\$1,230				
8h45m/24h44m	15 Amp Battery Charger Upgrade ¹	25me	\$1,430				

¹Order battery charger as part of UPS. See page 500-1.

External Battery Accessories					
Option	Order Number	List Price			
External Battery Connector Extension	BCS-0108	\$50			
Required for all external battery configurations except 21me – 25me.	200 0100	ΨΟΟ			

External Maintenance Bypass Switches ¹ (Recommended for hardwired units)								
UPS Input Voltage	Voltage Switch Type Order Number Lis							
120	MBB (Make Before Break)	BPE01MBB1A	\$400					
120	MBB, with AS/400 (iSeries) Option	BPE01MBBAS1A	\$400					
	BBM (Break Before Make)	BPE02BBM1A	\$450					
208, 220	BBM with AS/400 (iSeries) Option	BPE02BBMAS1A	\$450					
	BBM with Locking Handle	BPE02BBM1A/L	\$650					
	MBB (Make Before Break)	BPE02MBB1A	\$550					
240	MBB with AS/400 (iSeries) Option	BPE02MBBAS1A	\$550					
	MBB with Locking Handle	BPE02MBB1A/L	\$750					

¹ Bypass Switch must be mounted on the wall near the UPS.

Other External Options						
Option	Order Number	List Price				
Voltage Matching Transformer – 208V input, 120/240V output Required for applications using MBB bypass with source voltage of 208V.	TRN-1175	\$490				
Casters (if ordered as separate item)	CAA-0004	\$100				
IBM AS/400 (iSeries) Interface Kit – UPS without maintenance bypass switch	IPK-0001	\$95				
IBM AS/400 (iSeries) Interface Kit – UPS with maintenance bypass switch	IPK-0002	\$120				
EnviroCom TM I	ENV-0100	\$439				
EnviroCom II	ENV-0200	\$949				
BestLink SNMP/WEB Adapter	IPK-0318	\$349				
Hand-held Remote Control Panel with Cable	RCK-0007	\$250				
Signal Splitter Box	IPK-0022	\$199				

FE500VA Quote Sheet

The UPS CTO Worksheet										
	UPS CTO Order Code						List Price	Discount	Net Price	
Base Unit: FE500VA, 60 Hz Tower	FA									
Input / Output Voltage										
Battery and Battery Charger										
Internal Maintenance Bypass Switch			0					_	_	-
Input Connection										
Output Connection										
Internal Options										
Complete UPS CTO Number	FA		0							
	•		•	•	U	PS Subto	otal			
External Battery Pack										
Battery Pack Selected:										
External Maintenance Bypass	Swite	h								
External Maintenance Bypass Switch S	electe	d:								
Other External Options										
Voltage Matching Transformer						TRN-11	175			
Casters (if ordered as separate item)						CAA-00	004			
IBM AS/400 (iSeries) Interface Kit	iitah					IPK-00	01			
 UPS without maintenance bypass sw IBM AS/400 (iSeries) Interface Kit 	nich					IDI(00				
 UPS with maintenance bypass switch 						IPK-00	02			
EnviroCom [™] I						ENV-01	100			
EnviroCom II						ENV-02	200			
BestLink SNMP/WEB Adapter						IPK-03	18			
Hand-held Remote Control Panel with 0	Cable					RCK-00	007			
Signal Splitter Box						IPK-00				
						Sub To	otal			
									Freight	
									Insurance	
Tax/Duty										
Quote Total										
Special Instructions:										