FERRUPS CTO Configuration Guide



FERRUPS FE1.4kVA 60 HZ

Invensys Powerware Division 2727 Kurtz Street San Diego, CA 92110 U.S.A. 800.356.5794 www.powerware .com



Configuring Your FERRUPS UPS

FERRUPS must be ordered using a Configure To Order (CTO) Number that reflects the cabinet style, VA rating, voltages, runtime, and other options pertaining to the FERRUPS configuration. As you select the options needed, they will become part of the CTO number.

Sample CTO Number: FE000BB2A0A0A0A. See page 1.4k-6 for a CTO worksheet.

External battery packs, bypass switches and other external options will need to be ordered as separate line items.

Base Unit						
Base Model, Frequency, Cabinet Style	CTO Order Code	Base Price				
FE1.4kVA, 60 Hz Tower	FE	\$1799				

Input / Output Voltage								
Input Voltage	Output Voltage	CTO Order Code	Base Price					
120	120	0	\$0					
208	120/208	1	\$150					
208	120/240	2	\$150					
240	120/240	3	\$150					
240	240 (International Models)	6	\$150					
220	127/220	7	\$150					

Battery and Battery Charger								
Battery Configuration	Battery Charger	CTO Order Code	Option Price					
11 minute internal	standard	0	\$200					
22 minute internal	standard	1	\$404					
45 minute internal	standard	2	\$454					
Set up for internal (less batteries)	standard	3	\$86					
set up for external battery pack1	standard	4	\$22					
set up for external battery pack ¹	15 amp internal upgrade ²	6	\$667					

¹ Includes External Battery Connector Order desired external battery pack as a separate line. See page 1.4k-5.

² Required for external battery pack 10me

Internal Maintenance Bypass Switch							
Internal Maintenance Bypass Switch CTO Order Code Option Pri							
No internal maintenance bypass switch option available ¹	0	\$0					

¹External maintenance bypass switch available for hardwired systems. Order desired maintenance bypass switch as a separate line item on your order. See page 1.4k-5.

Input Connection								
Input Voltage Selected	Input Connection	Input Connection CTO Order Code						
Any	Hardwired ¹	А	\$40					
120 volt	5-15P ²	В	\$ 0					
	5-20P ³	С	\$25 ³					
	6-15P	Е	\$ 0					
208, 220, 240	L6-20P	K	\$60					
	L6-30P	L	\$60					
	IEC320 – Jumper Cord ⁴	0	\$15					

¹ Hardwired input requires hardwired output ² Cannot be used with 15 Amp battery charger ³ 5-20P option price is \$0 if 15 Amp battery charger is selected

⁴ Limits output connections to two panels

Output Connection

Output Connection Configuration is designated by 8 digits within the unit CTO number. These eight digits allow selection of the type and quantity for up to four different types of receptacles.

- Three output slots available when a NEMA line cord is selected
- Two output slots available when an international line cord is selected.
- If multiple quantities of one type of receptacle is desired, enter the type once with the total quantity (ex: B2 not B1B1).
- Always enter the receptacle types alphabetically (ex: B1C1 not C1B1).
- If hardwire output is desired, select type "A", quantity "0" for all four receptacle types (ex: A0A0A0A0).
- If fewer than four types of receptacle are selected, complete the remaining receptacle digits with A0 (ex: B1C1A0A0).

Output Voltage Beguired	Outnut Connection	CTO Or	der Code	Option Price	
Output Voltage Required	Output Connection	Туре	Qty	per Panel	
Any	Hardwired ¹	Α	0	\$0	
120 volt	5-15R Duplex	В		\$0	
Choose up to three panels	5-20R Duplex (UL)	С		\$50	
208, 220, or 240 volt	6-15R Duplex	D		\$75	
Choose up to three panels	6-20R Duplex	Е		\$75	
	L5-15R Duplex	G		\$75	
120 volt Choose up to three panels	L5-20R	Н		\$75	
	L5-30R	I		\$75	
	L6-15R Duplex	J		\$75	
208, 220, or 240 volt	L6-20R	K		\$75	
Choose up to three panels	L6-30R	L		\$75	
120/240 volt	L14-20R	М		\$75	
Choose up to three panels	L14-30R	N		\$75	
208, 220, 240 only Choose up to two panels	IEC320 10A (Qty 2 per panel)	U		\$50	
Receptacle Output Connection Hardwire Output Connection C	 <u>A </u>	<u>A 0</u> <u>A 0 A 0</u>			

¹ Hardwired output requires hardwired input

Internal Options								
Option	CTO Order Code	Option Price						
No other option	А	\$0						
AVR (recommended when loads contain PFC power supplies)	В	\$100						
Caster Kit (if ordered with unit)	С	\$120						
Anchor Kit for structural slab floor	D	\$200						
Anchor Kit for raised or access floor	Е	\$200						
Caster Kit and Anchor Kit for structural slab floor	F	\$300						
Caster Kit and Anchor Kit for raised or access floor	G	\$300						
AVR and Caster Kit	Н	\$220						
AVR and Anchor Kit for structural slab floor	I	\$300						
AVR and Anchor Kit for raised or access floor	J	\$300						
AVR, Caster Kit and Anchor Kit for structural slab floor	K	\$400						
AVR, Caster Kit and Anchor Kit for raised or access floor	L	\$400						
Neutral to Ground bond removal (For Shipboard Use)	Q	\$25						
Neutral to Ground bond removal and AVR (For Shipboard Use)	R	\$125						

External Options

External battery packs, bypass switches and other external options are not a part of the CTO number and will need to be ordered as separate line items. Some external options require that the UPS be configured for use with the option.

External Battery Packs								
Runtime Full/Half	Battery Charger Required ¹	Order Number	List Price					
2h20m/6h35m	Standard Battery Charger ¹ 15 Amp Battery Charger Upgrade Optional	8me	\$1,230					
3h10m/8h57m	Standard Battery Charger ¹ 15 Amp Battery Charger Upgrade Optional	9me	\$1,430					
5h20m/15h5m	15 Amp Battery Charger Upgrade ¹	10me	\$2,421					

External Battery Accessories Order Number List Price Option **External Battery Connector Extension**

BCS-0108

\$50

External Maintenance Bypass Switches ¹ (Recommended for hardwired units)								
UPS Input Voltage Switch Type Order Number								
120	MBB (Make Before Break)	BPE01MBB1A	\$400					
120	MBB, with AS/400 (iSeries) Option	BPE01MBBAS1A	\$400					
	BBM (Break Before Make)	BPE02BBM1A	\$450					
208, 220	BBM with AS/400 (iSeries) Option	BPE02BBMAS1A	\$450					
	BBM with Locking Handle	BPE02BBM1A/L	\$650					
	MBB (Make Before Break)	BPE02MBB1A	\$550					
240	MBB with AS/400 (iSeries) Option	BPE02MBBAS1A	\$550					
	MBB with Locking Handle	BPE02MBB1A/L	\$750					

¹ Bypass Switch must be mounted on the wall near the UPS.

¹Order battery charger as part of UPS. See page 1.4k-1.

Required for all external battery configurations except 8me - 10me.

Other External Options							
Option	Order Number	List Price					
Voltage Matching Transformer – 208V input, 120/240V output Required for applications using MBB bypass with source voltage of 208V.	TRN-1175	\$490					
Casters (if ordered as separate item)	CAA-0005	\$120					
IBM AS/400 (iSeries) Interface Kit – UPS without maintenance bypass switch	IPK-0001	\$95					
IBM AS/400 (iSeries) Interface Kit – UPS with maintenance bypass switch	IPK-0002	\$120					
EnviroCom TM I	ENV-0100	\$439					
EnviroCom II	ENV-0200	\$949					
BestLink SNMP/WEB Adapter	IPK-0318	\$349					
Hand-held Remote Control Panel with Cable	RCK-0007	\$250					
Signal Splitter Box	IPK-0022	\$199					

FE1.4kVA Quote Sheet

The UPS CTO Worksheet										
		UPS CTO Order Code					List Price	Discount	Net Price	
Base Unit: FE1.4kVA, 60 Hz Tower	FE									
Input / Output Voltage										
Battery and Battery Charger										
Internal Maintenance Bypass Switch			0					-	_	ı
Input Connection										
Output Connection										
Internal Options							L			
Complete UPS CTO Number	FE		0							
					U	PS Subto	otal			
External Battery Pack										
Battery Pack Selected:										
External Maintenance Bypass S	Switc	h								
External Maintenance Bypass Switch S	electe	d:								
Other External Options										
Voltage Matching Transformer						TRN-11	75			
Casters (if ordered as separate item)						CAA-00	005			
IBM AS/400 (iSeries) Interface Kit – UPS without maintenance bypass sw	itch					IPK-00	01			
IBM AS/400 (iSeries) Interface Kit – UPS with maintenance bypass switch						IPK-00	02			
EnviroCom TM I						ENV-01	00			
EnviroCom II						ENV-02	200			
BestLink SNMP/WEB Adapter						IPK-03	18			
Hand-held Remote Control Panel with C	able					RCK-00	007			
Signal Splitter Box						IPK-00	22			
						Sub To	otal			
									Freight	
									Insurance	
									Tax/Duty	
									Quote Total	
Special Instructions:										