


4

5


6

7


8




Einsatz 1-4
1340 018 - 01153 (4)




Einsatz 1-5
1340 018 - 01162 (4)




Einsatz 1-6
1340 018 - 01163 (4)




Einsatz 1-7
1340 018 - 01164 (4)




Einsatz 1-8
1340 018 - 01165 (4)




Einsatz 2-4
1340 018 - 01157 (4)




Einsatz 2-5
1340 018 - 01170 (4)




Einsatz 2-6
1340 018 - 01171 (4)




Einsatz 2-7
1340 018 - 01172 (4)




Einsatz 2-8
1340 018 - 01173 (4)




Einsatz 3-4
1340 018 - 01161 (4)




Einsatz 3-5
1340 018 - 01178 (4)




Einsatz 3-6
1340 018 - 01179 (4)




Einsatz 3-7
1340 018 - 01180 (4)




Einsatz 3-8
1340 018 - 01181 (4)




Einsatz 4-4
1340 018 - 01189 (4)




Einsatz 4-5
1340 018 - 01190 (4)



Einsatz 4-6
1340 018 - 01191 (4)



Einsatz 4-7
1340 018 - 01192 (4)



Einsatz 4-8
1340 018 - 01193 (4)

Bereiche:


1

2


3

4


1
Eingangskreis




Einsatz 1-1
1340 018 - 01150 (4)



Einsatz 1-2
1340 018 - 01151 (4)




Einsatz 1-3
1340 018 - 01152 (4)




Einsatz 1-4
1340 018 - 01153 (4)


2
1. Zwischenkreis




Einsatz 2-1
1340 018 - 01154 (4)



Einsatz 2-2
1340 018 - 01155 (4)




Einsatz 2-3
1340 018 - 01156 (4)




Einsatz 2-4
1340 018 - 01157 (4)


3
2. Zwischenkreis




Einsatz 3-1
1340 018 - 01158 (4)



Einsatz 3-2
1340 018 - 01159 (4)




Einsatz 3-3
1340 018 - 01160 (4)




Einsatz 3-4
1340 018 - 01161 (4)


4
Oszillator




Einsatz 4-1
1340 018 - 01186 (4)



Einsatz 4-2
1340 018 - 01187 (4)



Einsatz 4-3
1340 018 - 01188 (4)



Einsatz 4-4
1340 018 - 01189 (4)


1

2


3

A

Einsatz 1-7
1340.018 - 01520




Einsatz 2-7
1340.018 - 01526




B

Einsatz 1-8
1340.018 - 01521




Einsatz 2-8
1340.018 - 01527




C

Einsatz 1-9
1340.018 - 01522




Einsatz 2-9
1340.018 - 01528




D

Einsatz 1-10
1340.018 - 01523




Einsatz 2-10
1340.018 - 01529




E

Einsatz 1-12
1340.018 - 01525



Einsatz 2-12
1340.018 - 01531



Diese Unterlage ist unser Eigentum. Mißbrauch, Vervielfältigung oder Mitteilung an Dritte wird verfolgt.

KA 1.6	VEB	
Funkwerk Köpenick		
8.8.62	Katitschke	
Ausgabe	Tag	Name

**Betriebsempfänger
Selektor**

1340.021-00001 Sp 9

Blattzahl: 3
Blatt Nr. 1

VP	P.
Nr.	Nr.