

**DUPLEX UNIT**  
**(Machine Code: G806)**

---

# 1. REPLACEMENT AND ADJUSTMENT

<b>⚠ CAUTION</b>
------------------

Turn off the main power switch and unplug the machine before attempting any of the procedures in this section.
--

## 1.1 EXTERIOR COVERS

Refer to the G552 Service Manual for details.

## 1.2 DUPLEX BOARD AND SENSORS

Refer to the G552 Service Manual for details.

## **2. DETAILED DESCRIPTIONS**

### **2.1 OVERALL MACHINE INFORMATION**

#### **2.1.1 MECHANICAL COMPONENT LAYOUT**

Refer to the G552 Service Manual for details.

#### **2.1.2 DRIVE LAYOUT**

Refer to the G552 Service Manual for details.

#### **2.1.3 ELECTRICAL COMPONENT LAYOUT**

Refer to the G552 Service Manual for details.

### **2.2 DETAILED DESCRIPTIONS**

#### **2.2.1 BASIC OPERATION**

Refer to the G552 Service Manual for details.

#### **2.2.2 FEED IN AND EXIT MECHANISM**

Refer to the G552 Service Manual for details.