

Copy Tray Type 2075  
(B756)


**Copy Tray Type 2075 (B756)**

**PARTS CATALOG**

This catalog gives the numbers and names of parts on this machine.

1.Copy Tray (B756) ..... 2  
**Parts Index** ..... **5**

# 1.Copy Tray (B756)



### 1.Copy Tray (B756)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF04 3107	Guide:Copy Tray	1
2	AF04 3106	Copy Tray:Exit	1
3	B065 1344	G4 Cap	1
4	B065 1299	Cap:Mm22	4
5	B132 7035	Spring Plate:Sensor:Exit	1
6	B132 7106	Lever	1
7	B132 7034	Bracket:Sensor:Paper Volume Sensor	1
8	AW02 0145	Photointerruptor:Flat	1
9	A353 3172	Actuator Bracket	1
10	A379 1225	Upper Sensor Actuator	1
11	A229 4489	Sensor Bracket	1
12	AW02 0160	Paper Feed Sensor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0451 3006N	Tapping Screw - 3x6	
103	1105 0522	Edge Saddle - LES0510	

# Parts Index

## Parts Index

Part No.	Description	Page and Index No.
A229 4489	Sensor Bracket	3 - 11
A353 3172	Actuator Bracket	3 - 9
A379 1225	Upper Sensor Actuator	3 - 10
B065 1299	Cap:Mm22	3 - 4
B065 1344	G4 Cap	3 - 3
B132 7034	Bracket:Sensor:Paper Volume Sensor	3 - 7
B132 7035	Spring Plate:Sensor:Exit	3 - 5
B132 7106	Lever	3 - 6

Part No.	Description	Page and Index No.
AF04 3106	Copy Tray:Exit	3 - 2
AF04 3107	Guide:Copy Tray	3 - 1
AW02 0145	Photointerruptor:Flat	3 - 8
AW02 0160	Paper Feed Sensor	3 - 12

Part No.	Description	Page and Index No.
0451 3006N	Tapping Screw - 3x6	3 - 102
0451 4008N	Tapping Screw:4x8	3 - 101
1105 0522	Edge Saddle - LES0510	3 - 103

Part No.	Description	Page and Index No.