

DF57 (A318)


PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

1. Exterior and Transport Section (A318)	2
2. Feed In Section(A318)	4
3. Invert and Exit Section (A318)	6
4. Main Board (A318)	8
5. Indication Board (A318)	10
6. Main Harness (A318)	12
7. Interface Harness (A318)	14
Parts Index	17



1. EXTERIOR AND TRANSPORT SECTION (A318)


Index No.	Part No.	Description	Q'ty Per Assembly
1	A465 1337	Decal - Original Table - LT	1
1	A465 1338	Decal - Original Table - A4	1
2	A422 1335	Magnet - Original Table	1
3	A465 2025	Original Limit Decal	1
4	A422 1376	Rear Side Guide	1
5	5894 2747	Mylar- Original Guides	6
6	A422 1366	Front Side Guide	1
7	A422 1361	Rack - Side Guide	2
8	A318 1241	Original Table	1
	A422 1323	x/o MB15	1
9	5443 2712	Cork Pad	1
10	5443 2657	Gear - 28Z	1
11	5443 2713	Wave Washer	1
12	5443 2660	Spacer - 6x22x0.5mm	1
13	A465 2010	Misfeed Removal Decal - English	1
13	A465 2050	Misfeed Removal Decal - Multi	1
14	A422 1385	Original Exit Guide	1
15	A318 1550	Angle Stopper	1
	A465 1125	x/o MB17	1
16	A465 1398	Lift Switch Actuator	1
17	A437 1178	DF Harness Bracket	1
18	A318 1191	Mounting Bracket	1
18	A465 1195	Mounting Bracket MB10 (Deleted)	1
19	A422 1381	Shoulder Screw - M4	2
20	5936 2480	Magnet Catch Ass'y	2
21	A318 1135	Magnet Catch Bracket	1
22	5875 2088	Shoulder Screw - M4	6
23	AA14 3005	Stepped Screw - M4x2.5	2
24	A422 1108	Stopper	2
25	A422 1078	Bushing - 6x12x4mm	2
26	A318 1300	DF Upper Cover	1
27	A318 1100	Front Frame	1
28	A422 1185	Belt Guide - Front Left	1
29	A422 1187	Belt Guide - Front Right	1
30	5447 3655	Bushing - 4mm	8

Index No.	Part No.	Description	Q'ty Per Assembly
31	A3182017	Decal - DIP Switch	1
32	A437 1120	Bracket - Belt Tension Spring	1
33	A422 1112	Belt Tension Spring	2
34	A465 1127	Transport Belt	1
35	A422 1114	Driven Roller - Transport Belt	1
36	A422 1106	Stay	1
37	A4651118	Belt Support Roller	4
38	59365348	Thin Original Feed Switch	1
39	A422 1107	Stay - Belt Support Roller	3
40	A497 1101	Belt Pressure Roller	1
41	A437 1115	Drive Roller - Transport Belt	1
42	A422 1188	Belt Guide - Rear Right	1
43	A422 1186	Belt Guide - Rear Left	1
44	A422 1103	Rear Frame	1
45	A422 1056	Gear - 19T	1
46	A3181181	Feed-out Motor Cover	1
	A3181184	00 MB24	
47	A437 1190	Grounding Plate	1
49	A318 1331	Grip Cover	1
50	A3181171	Belt Driie Motor Cover	1
	A318 1498	00 MB24	
51	A422 1475	Main Board Cover	1
	A422 1183	00 MB24	
52	59367901	Decal - English	1
53	A465 1397	Spacer - 0.5mm	4
54	A465 1389	Spacer - 0.2mm	4
55	A465 1110	Magnet Catch Spacer	1
56	A422 1130	Reflector Plate	1
57	A422 1603	Seal - 2x8x1 4	1
58	A422 1604	Cushion - 8x1 5x25	1
59	A465 0656	Original Table Ass'y - LT	1
59	A465 0657	Original Table Ass'y - A4	1
60	A465 1179	DF Bracket	1
61	A49711 52	Magnet - APS	1
62	A318 1530	DF Halfway Sensor Actuator	1

Index No.	Part No.	Description	Q'ty Per Assembly
63	A497 2025	Cushion - 5x5x3	2
64	A465 2031	Decal - Set	1
65	A422 1066	Stopper	1
66	A318 1195	Mounting Bracket	1
		MB10 (ADDED)	
67	A318 1560	ADF Cushion	1
		MB27 (ADDED)	

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0060W	Philips Pan Head Screw - M4x6	
101	0353 0050W	Tapping Screw - M3x5	
102	0413 0082W	Tapping Screw - M3x8	
103	0951 4005W	Philips Screw With Flat Washer - M4x5	
104	0584 0103W	Hexgon With Flange Screw - M4x10	
105	0951 4006W	Philips Screw With Flat Washer - M4x6	
106	0951 3006B	Philips Screw with Flat Washer - M3x6	
107	0344 0060W	Philips Truss Head Screw - M4x6	
108	0801 1185	Philips Truss Head Screw - M4x8	
109	0720 0040E	Retaining Ring - M4	
110	0720 0050E	Retaining Ring - M5	
111	0720 0030E	Retaining Ring - M3	
112	0701 0060B	Flat Washer - M6	
114	0632 0100G	Pin - 2x10mm	
115	0344 0600D	Philips Truss Head Screw - M4x6	
116	0313 0050W	Philips Pan Head Screw - M3x5	
117	0742 3906	Ball Bearing - 6mm	
118	0741 3806	Ball Bearing - 6x13x5mm	
119	1106 0222	Cord Clamp	
120	1100 0340	Closed Terminal	
121	0314 0050	Philips Pan Head Screw - M4x5	
122	0315 0120W	Philips Pan Head Screw - M5x12	
	0315 0100W	Philips Pan Head Screw - M5x10 x/o MB8	

2. FEED IN SECTION (A318)



2. FEED IN SECTION (A318)


Index No.	Part No.	Description	Q'ty Per Assembly
1	A497 1077	Mylar - 18x306	1
3	A497 1052	Pull-out Bracket	1
	A465 1057	x/o MB22	1
4	5413 3903	Pin - Transfer Guide Plate	1
5	A422 1086	Pull-out Spring	2
6	A422 1063	seal - 0.7X13X20	2
7	A422 1064	Hinge - Pull-out	1
8	5205 5250	LED Sensor Type - S	2
9	A422 1087	Shoulder Screw - M3x3	2
10	A497 5202	Harness - Pulse Generator	1
	A422 5202	x/o MB9	1
11	A437 1065	Lower Guide Plate	1
12	A422 1071	Pull-out Lever	2
13	A422 1068	Relay Roller	2
14	A422 1067	Relay Roller Shaft	1
15	A422 1080	Pulse Generator	1
16	A422 5201	Interface Harness	1
17	A437 1026	Upper Guide Plate	1
18	A422 1040	Feed-in Solenoid Lever	1
19	AA14 3005	Stepped Screw - M4x2.5 MB5	1
20	5446 4577	Spring - Turn Plate MB5	1
21	A422 1074	Shoulder Screw - M4x2.5 MB5	1
22	A422 1075	Feed-in Unit Release Lever MB5	1
23	5219 1957	Stepped Screw - M4 MB5	1
24	A422 1073	Release Spring	1
25	A422 1072	Front Side Plate	1
26	A422 5252	Solenoid - DC24V	1
27	A422 1047	Set Sensor Bracket	1
28	A422 5270	Photosensor	2
29	A422 5207	Harness - Registration	1
30	A422 5208	Harness - Paper Size	1
31	A422 1093	Sensor Bracket	1
32	5875 2088	Shoulder Screw - M4	2
33	A422 1078	Bushing - 6x12x4mm	4
34	A422 1051	Gear - 23T	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A422 1044	Idle Shaft	1
36	A422 1503	Idle Shaft	1
37	A422 1042	Idle Gear - 22Z	1
38	A422 1046	Pick-up Roller	1
39	A422 1048	Pick-up Shaft	1
40	A422 1002	Clutch Boss	1
41	5918 2163	Clutch Spring	1
42	5918 2164	Clutch Sleeve	1
43	A422 1001	Gear - 24T	1
44	A422 1023	Feed Roller Shaft	1
45	A422 1045	Pull-out Roller	2
46	A318 1090	Side Roller	2
47	A497 1034	Feed Roller	1
	A422 1003	x/x MB20	1
48	A422 1041	Gear - 27T	1
49	A422 1025	Original Guide	1
50	A422 1602	Pick-up Lever Plate	1
51	A422 1600	Pick-up Lever	1
52	A422 1601	Pick-up Shaft	1
53	A422 1032	Lever - Pick-up Solenoid	1
54	A422 1031	Lever - Pick-up Spring	1
55	A422 1082	Pick-up Spring	1
56	A422 1033	Pick-up Solenoid Bracket	1
57	5894 2229	Solenoid Pin	2
58	A422 5255	Solenoid - DC24V (Invertor)	1
59	A422 1505	Gear - 57T	1
60	A422 1005	Clutch Pawl - Pick-up Roller	1
61	A422 1049	Gear - 27T	1
62	A422 1050	Gear - 29T	1
63	A318 1021	Side Plate	1
64	5894 2176	Spring - Detent Arm	1
65	A422 1291	Rear Guide Plate	1
66	A422 1290	Front Guide Plate	1
67	A422 1351	Seal - 0.5x37x71mm	1
68	A422 1360	Friction Belt Holder	1

Index No.	Part No.	Description	Q'ty Per Assembly
	A422 1352	x/x MB20	1
69	A422 1358	Friction Belt	1
	A497 1170	x/x MB20	1
70	A422 1356	Pin - 3x26mm	1
71	A422 1355	Friction Belt Spring	2
72	A422 1069	Friction Roller MB2 (OBS)	1
73	A422 1295	Set Sensor Actuator	1
74	A422 1176	Set Sensor Actuator Bracket	1
75	A422 1390	Entrance Seal	1
76	A465 5260	Indication Board	1
77	A422 1177	Indication Bracket	1
78	A422 1504	Shaft/Gear - 16T	1
79	A422 1506	Gear - 25T	1
80	A318 1510	Rear Side Plate	1
81	A422 1507	Feed-in Motor Bracket	1
82	A422 1501	Gear - 20T	1
83	A318 9500	Feed-in Motor - 115V	1
	A422 5300	o/o MB6	1
83	AX06 0067	Feed-in Motor - 220/240V	1
	AX06 0043	o/o MB13	1
	A422 5300	o/o MB5	1
84	A338 5204	Feed-in Motor Harness	1
	A422 5204	o/o MB7	1
85	A497 1015	Gear - 45Z	1
86	A422 1396	Mylar - 0.125x14x45.5	1
87	A422 1603	Seal - 2x8x1 4	1
88	A422 5212	Grounding Wire MB9 (Deleted)	1
89	A465 1075	Shaft - 3x25	1
90	A465 1074	Pin - 4x77.5	1
91	A465 1073	Pin - 4x76.5	1
92	A465 1072	Lock Spring	2
93	A465 1068	Cushion - 2.5x1 4x43	1
94	A465 1077	Release Lever	1
95	A465 1076	Release Lever Knob	1
96	A465 1069	Harness Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
97	A465 1080	Fixing Plate - Feed-in Unit	1
98	A465 1066	Mylar - 0.1x21x58	1
99	A465 1067	Mylar - 0.1x14.5x44	1
200	A465 1027	Guide Plate - Paper Feed	2
201	A465 1070	Lever Spring	1
202	A422 1022	Support Plate	1
203	A497 1024	Guide Mylar MB20 (ADDED)	1
100	0314 0060W	Philips Pan Head Screw - M4x6	
101	0313 0060W	Philips Pan Head Screw - M3x6	
102	0951 3010W	Philips Screw With Fiat Washer- M3x10	
103	0951 4006W	Philips Screw With Fiat Washer- M4x6	
104	0313 0120W	Philips Pan Head Screw - M3x12	
105	0313 0040W	Philips Pan Head Screw - M3x4	
106	0951 3004W	Philips Screw with Flat Washer - M3x4	
107	0720 0040E	Retaining Ring - M4	
108	0720 0060E	Retaining Ring - M6	
109	0720 0025E	Retaining Ring - M2.5	
110	0632 0100G	Pin - 2x10mm	
111	0632 0140G	Parallel Pin	
112	0632 0080G	Parallel Key - 2x8mm	
113	0573 0030E	Hexagon Headless Set Screw- M3x3	
114	0573 0060E	Hexagon Headless Set Screw - M3x6	
115	0354 0060W	Philips Truss Head Screw - M4x6	
116	1105 0199	Clamp	
117	1105 0008	Nylon Clip - 2N	
118	1105 0009	Nylon Clip - 5N	
119	0741 3505	Ball Bearing - 5x10x4	
120	0741 3506	Ball Bearing - 6x12x4 mm	
121	0805 3383	Bushing - M5	
122	0950 4006W	Philips Screw With Lock Washer- M4x6	
123	0720 0030E	Retaining Ring - M3	
124	0951 4005W	Philips Screw With Fiat Washer- M4x5	

3. INVERT AND EXIT SECTION (A318)





Index No.	Part No.	Description	Q'ty Per Assembly

4. MAIN BOARD (A318)

CONNECTOR

SYMBOL NO.	INDEX NO.
CM101	105
CM102	103
CM103	106
CM104	104
CM105	107
CM106	3

CAPACITOR

SYMBOL NO.	INDEX NO.
C101	140
C102	148
C103	145
C104	147
C105	146
C106	142
C107	151
C108	147
C109	144
C110	145

SYMBOL NO.	INDEX NO.
C111	152
C112	152
C113	143
C114	154
C115	154
C116	141
C117	142
C118	156
C119	156
C120	156

SYMBOL NO.	INDEX NO.
C121	156
C122	156
C123	156
C124	156
C125	156
C126	156
C127	156
C128	156
C129	156
C130	156

SYMBOL NO.	INDEX NO.
C131	156
C132	156
C133	156
C134	156
C135	156
C136	167
C137	156
C138	156
C139	156
C140	156

SYMBOL NO.	INDEX NO.
C141	156
C142	150
C143	156
C144	156
C145	150
C146	156
C147	156
C148	156
C149	156
C150	156

SYMBOL NO.	INDEX NO.
C151	156
C152	155
C153	156
C154	156
C155	153

DIP SW

SYMBOL NO.	INDEX NO.
DIP101	113

D100E

SYMBOL NO.	INDEX NO.
D101	117
D102	117

FUSE

SYMBOL NO.	INDEX NO.
FU101	112
	111

IC

SYMBOL NO.	INDEX NO.
IC101	126
IC102	116
IC103	4
	1
IC104	127
IC105	122
IC106	2
	110
IC107	120

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
IC108	129
IC109	123
IC110	121
IC111	129
IC112	124
IC113	125
IC114	129
IC115	128
IC116	119

SYMBOL NO.	INDEX NO.
RAY	135

JSM

SYMBOL NO.	INDEX NO.
JSM1	108
JSM2	108
JSM3	108
JSM4	108

LFD

SYMBOL NO.	INDEX NO.
LED101	118
LED102	118
LED103	118
LED104	118
LED105	118
LED106	118
LED107	118

NP

SYMBOL NO.	INDEX NO.
NP101	139

OSC

SYMBOL NO.	INDEX NO.
OSC101	130

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q101	115

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY101	135

RESISTOR

SYMBOL NO.	INDEX NO.
R101	133
R102	131
R103	171
R104	171
R105	171
R106	169
R107	168
R108	173
R109	134
R110	134

SYMBOL NO.	INDEX NO.
R111	132
R112	132
R113	132
R114	172
R115	174
R116	170
R117	162
R118	165
R119	162
R120	160

SYMBOL NO.	INDEX NO.
R121	165
R122	157
R123	162
R124	162
R125	159
R126	160
R127	160
R128	150
R129	160
R130	161

PUSH SWITCH

SYMBOL NO.	INDEX NO.
SW101	114
SW102	114

TEST PIN

SYMBOL NO.	INDEX NO.
TP101	102
TP102	102
TP103	102
TP104	102
TP105	102
TP106	102
TP107	102

T

SYMBOL NO.	INDEX NO.
T168	162

POTENTIOMETER

SYMBOL NO.	INDEX NO.
VR101	137
VR102	136
VR103	136
VR106	138

SYMBOL NO.	INDEX NO.
R131	161
R132	161
R133	165
R134	165
R135	165
R136	163
R137	165
R138	162
R139	158
R140	162

SYMBOL NO.	INDEX NO.
R141	162
R142	162
R143	163
R144	166
R145	162
R146	162
R147	162
R148	162
R149	162
R150	162

SYMBOL NO.	INDEX NO.
R151	162
R152	162
R153	162
R154	162
R155	162
R156	162
R157	160
R158	160
R159	163
R160	163

SYMBOL NO.	INDEX NO.
R161	162
R162	162
R163	162
R164	162
R165	162
R166	162
R167	162
R169	162
R170	159
R171	162

SYMBOL NO.	INDEX NO.
R172	162
R173	162
R174	162
R175	162
R176	159
R177	159
R178	159
R179	159
R180	162
R181	162

SYMBOL NO.	INDEX NO.
R182	159
R183	159
R184	159
R185	159
R186	159
R187	162
R188	159
R189	159
R190	162
R191	159

SYMBOL NO.	INDEX NO.
R192	166
R193	166
R194	166
R195	166
R196	164

4. MAIN BOARD (A318)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A465 5177	DF Main Board	1
	A465 5176	x/o MB26	1
	A465 5175	x/o MB18	1
	A465 5190	o/o MB5,MB6	1
	4422 5350	IC - HCTL-3	1
1	A456 5140	IC- D271 28A-2	1
2	A465 5187	x/o MB26	1
	A465 5185	x/o MB18	1
3	A465 5210	Fiber Connector - 2P	1
4	5936 5221	Heat Sink	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1005 0843	Heat Sink - OSH2425SP	
102	1101 0328	Connector Pin Contact	
103	1102 0958	Connector - 2P	
104	1102 2966	Connector - HIF3BA-34PA	
105	1103 0881	Connector - 4P	
106	1103 1726	Connector - 4P	
107	1103 1729	Connector - 7P	
108	1103 1878	Connector - 2P	
110	1104 0271	LSI Socket - 28P	
111	1104 0333	Fuse Holder	
112	1107 0413	Fuse - 3A 125V	
113	1204 0883	DIP Switch	
114	1204 1385	Push Switch	
115	1401 0282	Transistor - 2SB1020	
116	1401 0329	Transistor Array - MP4503	
117	1401 0832	Diode - DSA1A1	
118	1403 0308	LED - TLR-102A	
119	1403 0784	Photocoupler - ON3131	
	1403 0388	Photocoupler - ON3111 o/o MB21	
120	1407 0602	IC - TC4040BP	
121	1407 0604	IC - TC4049BP	
122	1407 1026	IC - SN74LS373N	
123	1407 1334	IC - μ PD7810G	
124	1407 1348	IC - TD62304AP	
125	1407 1535	IC - TD62308AP	
126	1408 0076	IC - μ PC14312H	
127	1408 0408	IC - PST518A	
128	1408 0521	IC - M51971L	
129	1408 0578	IC - HA1 7339	
130	1503 0070	Ceramic Oscillator - 10MHZ	
131	1600 0239	Resistor - 0.47 Ω $\pm$ 5% 1W	
132	1600 0544	Resistor - 1k Ω $\pm$ 10% 1W	
133	1600 0576	Resistor - 33 Ω $\pm$ 10% 5W	
134	1601 1732	Resistor - 390 Ω $\pm$ 5% 1W	
135	1601 7326	Resistor Array - 10k Ω	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1601 8145	Variable Resistor - 5k Ω 0.5W	
137	1601 8147	Variable Resistor - 10k Ω 0.5W	
138	1601 8148	Variable Resistor - 20k Ω 0.5W	
139	1602 0953	Coil - 800 μ H 2.5A	
140	1604 1358	Capacitor - 1000 μ F 10V	
141	1604 1378	Capacitor - 1 μ F 50V	
142	1604 1379	Capacitor - 2.2 μ F $\pm$ 20% 50V	
143	1604 1380	Capacitor - 3.3 μ F 50V	
144	1604 1381	Capacitor - 4.7 μ F 50V	
145	1604 1382	Capacitor - 10 μ F 50V	
146	1604 1383	Capacitor - 22 μ F 50V	
147	1604 1386	Capacitor - 100 μ F $\pm$ 20% 50V	
148	1604 1390	Capacitor - 1000 μ F 50V	
150	1605 0141	Capacitor - 4700PF 50V	
151	1606 0658	Capacitor - 0.1 μ F 50V	
152	1606 1308	Capacitor - 27pF 50V	
153	1606 1326	Capacitor - 100pF 50v $\pm$ 10%	
154	1606 1348	Capacitor - 0.022 μ F 50V	
155	1606 1451	Capacitor - 0.1 μ F 50V	
156	1606 1452	Capacitor - 0.01 μ F 50V	
157	1610 0035	Resistor - 100 Ω 1/8W $\pm$ 5%	
158	1610 0047	Resistor - 330 Ω 1/8W $\pm$ 5%	
159	1610 0053	Resistor - 1k Ω 1/8W $\pm$ 5%	
160	1610 0057	Resistor - 1.5k Ω 1/8W $\pm$ 5%	
161	1610 0065	Resistor - 3.3K Ω 1/8W $\pm$ 5%	
162	1610 0067	Resistor - 4.7k Ω 1/8W $\pm$ 5%	
163	1610 0071	Resistor - 10k Ω $\pm$ 5% 1/8W	
164	1610 0073	Resistor - 12K Ω 1/8W $\pm$ 5%	
165	1610 0079	Resistor - 22k Ω 1/8W $\pm$ 5%	
166	1610 0107	Resistor - 1M Ω 1/8W $\pm$ 5%	
167	1610 0286	Capacitor - 100pF 50V $\pm$ 10%	
168	1611 4103	Resistor - 10k Ω 1/4T $\pm$ 5%	
169	1611 4121	Resistor - 120 Ω 1/4T $\pm$ 5%	
170	1611 4229	Resistor - 2.2 Ω 1/4W $\pm$ 5%	
171	1611 4272	Resistor - 2.7k Ω 1/4T $\pm$ 5%	

Index No.	Part No.	Description	Q'ty Per Assembly
172	1611 4393	Resistor - 39k Ω 1/4T $\pm$ 5%	
173	1611 4472	Resistor - 4.7k Ω $\pm$ 5% 1/4W	
174	1611 4563	Resistor - 56k Ω 1/4T $\pm$ 5%	

5. INDICATION BOARD (A318)

LED

CONNECTOR


SYMBOL NO.	INDEX NO.		SYMBOL NO.	INDEX NO.
LED200	105		CN200	101
LED201	105			103
LED202	106		CN201	102
				104

5. INDICATION BOARD (A318)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A465 5260	Indication Board	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 1306	Terminal	
102	1100 1328	Contact	
103	1102 1805	Connector - 4P	
104	1102 1967	Connector - 6P	
105	1403 0236	L.E.D. - MU02-520	
106	1403 0237	L.E.D. - MU20-220	

6. MAIN HARNESS (A318)




6. MAIN HARNESS (A318)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A318 5220	Main Harness	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 0340	Closed Terminal	
102	1100 1169	Fastening Receptacle	
103	1100 1253	Pin - Mate-N-Lock	
104	1100 1327	Contact	
105	1100 1348	Pin Contact	
106	1102 1408	Connector - 1P	
107	1102 1756	Connector - 2P	
108	1102 1910	Connector - 2P	
109	1102 1911	Connector - 3P	
110	1102 1912	Connector - 4P	
111	1102 1914	Connector - 6P	
112	1102 1924	Connector - 2P	
113	1102 1925	Connector - 3P	
114	1102 1938	Connector - 2P	
115	1102 1939	Connector - 3P	
116	1103 0659	Connector - 34P	
119	1607 0116	Ferrite Core	

7. INTERFACE HARNESS (A318)



7. INTERFACE HARNESS (A318)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A318 5207	Interface Harness - 115V	1
	A318 5205	Interface Harness x/o MB23	1
	A318 5206	Interface Harness - 220/240V	1
	A318 5205	Interface Harness x/o MB12	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 0051	Connector	
102	1100 1190	Socket - Mate-N-Lock	
103	1100 1447	Socket - Mate-N-Lock	
104	1102 1374	Connector - 4P	
105	1102 1517	Connector - 4P	
106	1102 1089	Connector - 3P	
107	1100 1259	Socket - Mate-N-Lock	
108	1102 2025	Pin Housing - 3P	
109	1100 1330	Socket Contact	

PARTS INDEX

Part No.	Description	Page and Index No.
A318 1021	Side Plate	5-63
A318 1090	Side Roller	5-46
A318 1100	Front Frame	3-27
A318 1119	Left Hinge Bracket	7- 5
A318 1135	Magnet Catch Bracket	3-21
A318 1171	Belt Drive Motor Cover	3-50
A318 1181	Feed-out Motor Cover	3-46
A318 1184	o/o MB24	3-
A318 1191	Mounting Bracket	3- 18
A318 1195	Mounting Bracket	3-66
	MB10 (ADDED)	3-
A318 1241	Original Table	3- 8
A318 1300	DF Upper Cover	3-26
A318 1331	Grip Cover	3-49
A318 1498	o/o MB24	3-
A318 1510	Rear Side Plate	5-80
A318 1530	OF Halfway Sensor Actuator	3-62
A318 1550	Angle Stopper	3-15
A318 1560	ADF Cuchion	3-67
	MB27 (ADDED)	3-
A318 1611	I/F Harness Bracket	7- 11
A318 2017	Decal - DIP Switch	3-31
A318 5205	Interface Harness x/o MB23	7- 7
A318 5205	Interface Harness x/o MB12	7- 7
A318 5205	Interface Harness x/o MB23	15-
A318 5205	Interface Harness x/o MB12	15-
A318 5206	Interface Harness - 220/240V	7- 7
A318 5206	InterFace Harness - 220/240V	15- *
A318 5207	Interface Harness - 115V	7- 7
A318 5207	Interface Harness - 115V	15- *
A318 5220	Main Harness	7- 10
A318 5220	Main Harness	13- *
A318 9500	Feed-in Motor - 115V	5-83

Part No.	Description	Page and Index No.
AA00 0072W	Caution Decal - Fuse	7-56
AA14 3005	Stepped Screw - M4x2.5	3-23
AA14 3005	Stepped Screw - M4x2.5 MB5	5- 19
AW01 0010	Photosensor	7-54
AX06 0043	o/o MB13	5-
AX06 0067	Feed-in Motor - 220/240V	5-83
A338 5204	Feed-in Motor Harness	5-84
A409 1143	Pulley - 50T	7-43
A409 1150	Spring Anchor	7-30
A409 1161	Pulley - 21T	7-27
A409 1192	Pulley - 15T	7- 15
A409 1195	Exit Drive Shaft	7- 17
A409 1197	Spacer - 10x16x1 .6mm	7-20
A422 1001	Gear - 24T	5-43
A422 1002	Clutch Boss	5-40
A422 1003	x/x MB20	5-
A422 1005	Clutch Pawl - Pick-up Roller	5-60
A422 1022	Support Plate	5-202
A422 1023	Feed Roller Shaft	5-44
A422 1025	Original Guide	5-49
A422 1031	Lever - Pick-up Spring	5-54
A422 1032	Lever - Pick-up Solenoid	5-53
A422 1033	Pick-up Solenoid Bracket	5-56
A422 1040	Feed-in Solenoid Lever	5- 18
A422 1041	Gear - 27T	5-48
A422 1042	Idle Gear - 22Z	5-37
A422 1044	Idle Shaft	5-35
A422 1045	Pull-out Roller	5-45
A422 1046	Pick-up Roller	5-38
A422 1047	Set Sensor Bracket	5-27
A422 1048	Pick-up Shaft	5-39
A422 1049	Gear - 27T	5-61
A422 1050	Gear - 29T	5-62
A422 1051	Gear - 23T	5-34
A422 1056	Gear - 19T	3-45

Part No.	Description	Page and Index No.
A422 1063	Seal - 0.7x13x20	5- 6
A422 1064	Hinge - Pull-out	5- 7
A422 1066	Stopper	3-65
A422 1067	Relay Roller Shaft	5- 14
A422 1068	Relay Roller	5- 13
A422 1069	Friction Roller MB2 (OBS)	5-72
A422 1071	Pull-out Lever	5- 12
A422 1072	Front Side Plate	5-25
A422 1073	Release Spring	5-24
A422 1074	Shoulder Screw - M4x2.5 MB5	5-21
A422 1075	Feed-in Unit Release Lever MB5	5-22
A422 1078	Bushing - 6x12x4mm	3-25
A422 1078	Bushing - 6x12x4mm	5-33
A422 1078	Bushing - 6x12x4mm	7-34
A422 1079	Bushing - 8x16x5mm	7-41
A422 1080	Pulse Generator	5- 15
A422 1082	Pick-up Spring	5-55
A422 1086	Pull-out Spring	5- 5
A422 1087	Shoulder Screw - M3x3	5- 9
A422 1093	Sensor Bracket	5-31
A422 1103	Rear Frame	3-44
A422 1106	Stay	3-36
A422 1107	Stay - Belt Support Roller	3-39
A422 1108	Stopper	3-24
A422 1112	Belt Tension Spring	3-33
A422 1114	Driven Roller - Transport Belt	3-35
A422 1120	Left Bracket - Right Hinge	7- 3
A422 1121	Right Bracket - Right Hinge	7- 2
A422 1130	Reflector Plate	3-56
A422 1176	Set Sensor Actuator Bracket	5-74
A422 1177	Indication Bracket	5-77
A422 1183	ø/ø MB24	3-
A422 1185	Belt Guide - Front Left	3-28
A422 1186	Belt Guide - Rear Left	3-43
A422 1187	Belt Guide - Front Right	3-29

Part No.	Description	Page and Index No.
A422 1188	Belt Guide - Rear Right	3-42
A422 1216	Inverter Support Roller	7-39
A422 1217	Pressure Lever	7-47
A422 1218	Pressure Lever Shaft	7-46
A422 1219	Pressure Lever Spring	7-48
A422 1225	Inverter Guide Plate	7- 13
A422 1226	Spring - Inverter Guide Plate	7-29
A422 1230	Inverter Pawls	7-37
A422 1231	Inverter Gate Spring	7-32
A422 1232	Inverter Solenoid Bracket	7-22
A422 1234	Front Lever	7-33
A422 1235	Rear Lever	7-25
A422 1240	Upper Exit Roller	7-31
A422 1245	Upper Exit Roller Ass'y	7-45
A422 1249	Upper Exit Roller	7-51
A422 1251	Bracket - Exit Sensor	7- 19
A422 1255	Inverter Guide Plate	7-50
A422 1257	Antistatic Brush	7-49
A422 1260	Front Side Plate	7- 14
A422 1261	Rear Side Plate	7-21
A422 1265	Gear - 46T	7- 18
A422 1270	Timing Belt - 81xl	7-42
A422 1275	Front Side Plate - Feed-out	7-36
A422 1276	Rear Side Plate - Feed-out	7-40
A422 1290	Front Guide Plate	5-66
A422 1291	Rear Guide Plate	5-65
A422 1295	Set Sensor Actuator	5-73
A422 1323	x/o MB15	3-
A422 1335	Magnet - Original Table	3- 2
A422 1351	Seal - 0.5x37x71 mm	5-67
A422 1352	x/x MB20	5-
A422 1355	Friction Belt Spring	5-71
A422 1356	Pin - 3x26mm	5-70
A422 1358	Friction Belt	5-69
A422 1360	Friction Belt Holder	5-68

Part No.	Description	Page and Index No.
A422 1361	Rack-SideGuide	3- 7
A422 1366	Front Side Guide	3- 6
A422 1376	RearSideGuide	3- 4
A422 1381	Shoulder Screw - M4	3- 19
A422 1385	OriginalExitGuide	3- 14
A422 1390	EntranceSeal	5- 75
A422 1396	Mylar - 0.125x14x45.5	5- 86
A422 1475	Main Board Cover	3- 51
A422 1501	Gear-20T	5- 82
A422 1503	Idle Shaft	5- 36
A422 1504	Shaft/Gear - 16T	5- 78
A422 1505	Gear - 57T	5- 59
A422 1506	Gear-25T	5- 79
A422 1507	Feed-in Motor Bracket	5- 81
A422 1600	Pick-upLever	5- 51
A422 1601	Pick-up Shaft	5- 52
A422 1602	Pick-up Lever Plate	5- 50
A422 1603	Seal-2x8x14	3- 57
A422 1603	Seal-2x8x14	5- 87
A422 1604	Cushion-8x15x25	3- 58
A422 2030	Decal - Inverter Guide Plate	7- 6
A422 5201	Interface Harness	5- 16
A422 5202	x/o MB9	5-
A422 5203	Feed-outSensor Harness	7- 44
A422 5204	o/o MB7	5-
A422 5207	Harness-Registration	5- 29
A422 5208	Harness-PaperSize	5- 30
A422 5212	GroundingWire MB9 (OBS)	5- 88
A422 5252	Solenoid - DC24V	5- 26
A422 5255	Solenoid -DC24V(Invertor)	5- 58
A422 5255	Solenoid-DC24V(I nvertor)	7- 24
A422 5270	Photosensor	5- 28
A422 5270	Photosensor	7- 16
A422 5300	o/o MB6	5-
A422 5300	o/o MB5	5-

Part No.	Description	Page and Index No.
A422 5310	Feed-out Motor - DC1 OW	7- 26
A422 5350	IC - HCTL-3	9- 1
A437 1026	Upper Guide Plate	5- 17
A437 1065	Lower Guide Plate	5- 11
A437 1115	Drive Roller - Transport Belt	3-41
A437 1120	Bracket - Belt Tension Spring	3-32
A437 1178	DF Harness Bracket	3- 17
A437 1190	Grounding Plate	3-47
A456 5140	IC - D27128A-2	9 - 2
A465 0656	Original TableAss'y - LT	3-59
A465 0657	Original Table Ass'y - A4	3-59
A465 1027	Guide Plate - Paper Feed	5-200
A465 1057	x/o MB22	5-
A465 1066	Mylar - 0.1x21x58	5-98
A465 1067	Mylar - 0.1x14.5x44	5-99
A465 1068	Cushion - 2.5x14x43	5-93
A465 1069	Harness Cover	5-96
A465 1070	Lever Spring	5-201
A465 1072	Lock Spring	5-92
A465 1073	Pin - 4x76.5	5-91
A465 1074	Pin - 4x77.5	5-90
A465 1075	shaft - 3x25	5-89
A465 1076	Release Lever Knob	5-95
A465 1077	Release Lever	5-94
A465 1080	Fixing Plate - Feed-in Unit	5-97
A465 1110	Magnet Catch Spacer	3-55
A465 1118	Belt Support Roller	3-37
A465 1125	x/o MB17	3-
A465 1126	Grounding Plate	7-52
A465 1127	Transport Belt	3-34
A465 1179	DF Bracket	3-60
A465 1195	Mounting Bracket MB1O (OBS)	3- 18
A465 1337	Decal - Original Table - LT	3- 1
A465 1338	Decal - Original Table - A4	3- 1
A465 1389	Spacer - 0.2mm	3-54

Part No.	Description	Page and Index No.
A465 1393	Left Hinge	7- 4
A465 1397	Spacer - 0.5mm	3-53
A465 1398	Lift Switch Actuator	3- 16
A465 1499	Right Hinge	7- 1
A465 2010	Misfeed Removal Decal - English	3- 13
A465 2025	Original Limit Decal	3- 3
A465 2031	Decal - Set	3-64
A465 2050	Misfeed Removal Decal - Multi	3- 13
A465 5175	x/o MB18	7-
A465 5175	x/o MB18	9-
A465 5176	x/o MB26	7-
A465 5176	x/o MB26	9-
A465 5177	DF Main Board	7- 9
A465 5177	DF Main Board	9- *
A465 5180	x/o MB18	9-
A465 5187	x/o MB26	9-
A465 5190	o/o MB5	7-
A465 5190	o/o MB5,MB6	9-
A465 5210	Fiber Connector - 2P	9- 3
A465 5213	Grounding Wire	7-53
A465 5260	Indication Board	5-76
A465 5260	Indication Board	11- *
A497 1015	Gear - 45Z	5-85
A497 1024	Guide Mylar	5-203
	MB20 (ADDED)	5-
A497 1034	Feed Roller	5-47
A497 1052	Pull-out Bracket	5- 3
A497 1077	Mylar - 18x306	5- 1
A497 1101	Belt Pressure Roller	3-40
A497 1152	Magnet - APS	3-61
A497 1170	x/x MB20	5-
A497 1500	x/o MB14	7-
A497 2024	Paper Guide Mylar	7- 12
A497 2025	Cushion - 5x5x3	3-63
A497 2090	Inverter Roller	7-38

Part No.	Description	Page and Index No.
	o/o MB25	7-
A497 5202	Harness - Pulse Generator	5- 10
5053 0447	Bushing - 6mm	7-28
5205 5250	LED Sensor Type - S	5- 8
5219 1957	Stepped Screw - M4 MB5	5-23
5219 1957	Stepped Screw - M4	7-55
5413 3903	Pin - Transfer Guide Plate	5- 4
5443 2657	Gear - 28Z	3- 10
5443 2660	Spacer - 6x22x0.5mm	3- 12
5443 2712	Cork Pad	3- 9
5443 2713	Wave Washer	3- 11
5446 2824	Screw - Duplex Guide Plate	7-35
5446 4577	Spring - Turn Plate MB5	5-20
5447 3655	Bushing - 4mm	3-30
5875 2088	Shoulder Screw - M4	3-22
5875 2088	Shoulder Screw - M4	5-32
5875 2088	Shoulder Screw - M4	7- 8
5894 2176	Spring - Detent Arm	5-64
5894 2229	Solenoid Pin	5-57
5894 2229	Solenoid Pin	7-23
5894 2747	Mylar - Original Guides	3- 5
5918 2163	Clutch Spring	5-41
5918 2164	Clutch Sleeve	5-42
5936 2480	Magnet CatchAss'y	3-20
5936 5221	Heat Sink	9- 4
5936 5348	Thin Original Feed Switch	3-38
5936 7901	Decal - English	3-52

Part No.	Description	Page and Index No.
0313 0040W	Philips Pan Head Screw - M3x4	5-105
0313 0040W	Philips Pan Head Screw - M3x4	7-107
0313 0050W	Philips Pan Head Screw - M3x5	3-116
0313 0060W	Philips Pan Head Screw - M3x6	5-101
0313 0060W	Philips Pan Head Screw - M3x6	7-106
0313 0120W	Philips Pan Head Screw - M3x12	5-104
0313 0140W	Philips Pan Head Screw - M3x14	7-103
0314 0050	Philips Pan Head Screw - M4x5	3-121
0314 0060W	Philips Pan Head Screw - M4x6	3-100
0314 0060W	Philips Pan Head Screw - M4x6	5-100
0314 0060W	Philips Pan Head Screw - M4x6	7-102
0314 0060W	Philips Pan Head Screw - M4x6	7-104
0315 0100w	Philips Pan Head Screw - M5x10 x/o MB8	3-
0315 0120W	Philips Pan Head Screw - M5x12	3-122
0344 0060W	Philips Truss Head Screw - M4x6	3-107
0344 0600D	Philips Truss Head Screw - M4x6	3-115
0353 0050W	Tapping Screw - M3x5	3-101
0354 0060W	Philips Truss Head Screw - M4x6	5-115
0413 0082W	Tapping Screw - M3x8	3-102
0573 0030E	Hexagon Headless Set Screw - M3x3	5-113
0573 0060E	Hexagon Headless Set Screw - M3x6	5-114
0584 0103W	Hexagon With Flange Screw - M4x10	3-104
0632 0080B	Parallel Key - 2x8mm	7-116
0632 0080G	Parallel Key - 2x8mm	5-112
0632 0100G	Pin - 2x10mm	3-114
0632 0100G	Pin - 2x10mm	5-110
0632 0100G	Pin - 2x10mm	7-114
0632 0140G	Parallel Pin	5-111
0633 0120G	Parallel Pin - 3x12	7-115
0701 0040	Flat Washer - M4	7-117
0701 0060B	Flat Washer - M6	3-112
0704 0040G	Toothed Washer - M4	7-113
0720 0025C	Retaining Ring - M2.5	7-112
0720 0025E	Retaining Ring - M2.5	5-109
0720 0030E	Retaining Ring - M3	3-111

Part No.	Description	Page and Index No.
0720 0030E	Retaining Ring - M3	5-123
0720 0030E	Retaining Ring - M3	7-110
0720 0040E	Retaining Ring - M4	3-109
0720 0040E	Retaining Ring - M4	5-107
0720 0040E	Retaining Ring - M4	7-109
0720 0050E	Retaining Ring - M5	3-110
0720 0060E	Retaining Ring - M6	5-108
0720 0060E	Retaining Ring - M6	7-111
0741 3505	Ball Bearing - 5x10x4	5-119
0741 3505W	Ball Bearing - 5x10x4	7-125
0741 3506	Ball Bearing - 6x12x4mm	5-120
0741 3806	Ball Bearing - 6x 13x5mm	3-118
0742 3905	Ball Bearing - 5x13x4mm	7-124
0742 3906	Ball Bearing - 6mm	3-117
0801 1185	Philips Truss Head Screw - M4x8	3-108
0801 1185M	Philips Truss Head Screw - M4x8	7-101
0805 3383	Bushing - M5	5-121
0950 4006	hilips Screw With Lock Washer - M4x6	7-126
0950 4006W	Philips Screw With Lock Washer- M4x6	5-122
0951 3004W	Philips Screw with Flat Washer - M3x4	5-106
0951 3006B	Philips Screw with Flat Washer - M3x6	3-106
0951 3006W	Philips Screw With Flat Washer- M3x6	7-105
0951 3010E	Philips Screw With Flat Washer- M3x10	7-108
0951 3010W	Philips Screw With Flat Washer- M3x10	5-102
0951 4005W	Philips Screw With Flat Washer- M4x5	3-103
0951 4005W	Philips Screw With Flat Washer- M4x5	5-124
0951 4006	Philips Screw With Flat Washer- M4x6	7-100
0951 4006W	Philips Screw With Flat Washer- M4x6	3-105
0951 4006W	Philips Screw With Flat Washer- M4x6	5-103
1005 0843	Heat Sink - OSH2425SP	9-101
1100 0051	Connector	15-101
1100 0340	Closed Terminal	3-120
1100 0340	Closed Terminal	13-101
1100 1169	Fastening Receptacle	13-102
1100 1190	Socket - Mate-N-Lock	15-102

Part No.	Description	Page and Index No.
1100 1253	Pin - Mate-N-Lock	13-103
1100 1259	Socket-Mate-N-Lock	15-107
1100 1306	Terminal	11-101
1100 1327	Contact	13-104
1100 1328	Contact	11-102
1100 1330	Socket Contact	15-109
1100 1348	Pin Contact	13-105
1100 1447	Socket-Mate-N-Lock	15-103
1101 0328	Connector Pin Contact	9-102
1102 0958	Connector-2P	9-103
1102 1089	Connector-3P	15-106
1102 1374	Connector-4P	15-104
1102 1408	Connector-1P	13-106
1102 1517	Connector-4P	15-105
1102 1756	Connector-2P	13-107
1102 1805	Connector-4P	11-103
1102 1910	Connector-2P	13-108
1102 1911	Connector-3P	13-109
1102 1912	Connector-4P	13-110
1102 1914	Connector-6P	13-111
1102 1924	Connector-2P	13-112
1102 1925	Connector-3P	13-113
1102 1938	Connector-2P	13-114
1102 1939	Connector-3P	13-115
1102 1967	Connector-6P	11-104
1102 2025	Pin Housing-3P	15-108
1102 2966	Connector - HIF3BA-34PA	9-104
1103 0659	Connector-34P	13-116
1103 0881	Connector-4P	9-105
1103 1726	Connector-4P	9-106
1103 1729	Connector-7P	9-107
1103 1878	Connector-2P	9-108
1104 0271	LSI Socket - 28P	9-110
1104 0333	Fuse Holder	9-111
1105 0008	Nylon Clip - 2N	5-117

Part No.	Description	Page and Index No.
1105 0009	Nylon Clip - 5N	5-118
1105 0009	Nylon Clip - 5N	7-118
1105 0034	x/o MB11	7-
1105 0199	Clamp	5-116
1105 0199	Clamp	7-121
1105 0372	Nylon Clip - 7N	7-119
1106 0222	Cord Clamp	3-119
1106 0430	Bushing- 13mm	7-120
1107 0413	Fuse-3A 125V	7-123
1107 0413	Fuse - 3A 125V	9-112
1204 0883	DIP Switch	9-113
1204 1319	Microswitch	7-122
1204 1385	Push Switch	9-114
1401 0282	Transistor-2SB1020	9-115
1401 0329	TransistorArray- MP4503	9-116
1401 0832	Diode - DSA1A1	9-117
1403 0236	L.E.D. - MU02-520	11-105
1403 0237	L.E.D. - MU20-220	11-106
1403 0308	LED-TLR-102A	9-118
1403 0388	Photocoupler - ON3111 o/o MB2 1	9-
1403 0784	Photocoupler - ON3 131	9-119
1407 0602	IC - TC4040BP	9-120
1407 0604	IC - TC4049BP	9-121
1407 1026	IC-SN74LS373N	9-122
1407 1334	IC - μ PD7810G	9-123
1407 1348	IC - TD62304AP	9-124
1407 1535	IC - TD62308AP	9-125
1408 0076	IC - UPC14312H	9-126
1408 0408	IC - PST518A	9-127
1408 0521	IC - M51971L	9-128
1408 0578	IC - HA17339	9-129
1503 0070	Ceramic Oscillator - 10MHz	9-130
1600 0239	Resistor - 0.47 Ω $\pm$ 5% 1W	9-131
1600 0544	Resistor - 1k Ω $\pm$ 10% 1W	9-132
1600 0576	Resistor - 33 Ω $\pm$ 10% 5W	9-133

Part No.	Description	Page and Index No.
1601 1732	Resistor - 390 Ω $\pm 5\%$ 1W	9-134
1601 7326	Resistor Array - 10k Ω	9-135
1601 8145	Variable Resistor - 5k Ω 0.5W	9-136
1601 8147	Variable Resistor - 10k Ω 0.5W	9-137
1601 8148	Variable Resistor - 20k Ω 0.5W	9-138
1602 0953	Coil - 800 μ H 2.5A	9-139
1604 1358	Capacitor - 1000 μ F 10V	9-140
1604 1378	Capacitor - 1 μ F 50V	9-141
1604 1379	Capacitor - 2.2 μ F $\pm 20\%$ 50V	9-142
1604 1380	Capacitor - 3.3 μ F 50V	9-143
1604 1381	Capacitor - 4.7 μ F 50V	9-144
1604 1382	Capacitor - 10 μ F 50V	9-145
1604 1383	Capacitor - 22 μ F 50V	9-146
1604 1386	Capacitor - 100 μ F $\pm 20\%$ 50V	9-147
1604 1390	Capacitor - 1000 μ F 50V	9-148
1605 0141	Capacitor - 4700PF 50V	9-150
1606 0658	Capacitor - 0.1 μ F 50V	9-151
1606 1308	Capacitor - 27pF 50V	9-152
1606 1326	Capacitor - 100pF 50v $\pm 10\%$	9-153
1606 1348	Capacitor - 0.022 μ F 50V	9-154
1606 1451	Capacitor - 0.1 μ F 50V	9-155
1606 1452	Capacitor - 0.01 μ F 50V	9-156
1607 0116	Ferrite Core	13-119
1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	9-157
1610 0047	Resistor - 330 Ω 1/8W $\pm 5\%$	9-158
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	9-159
1610 0057	Resistor - 1.5k Ω 1/8W $\pm 5\%$	9-160
1610 0065	Resistor - 3.3K Ω 1/8W $\pm 5\%$	9-161
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	9-162
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	9-163
1610 0073	Resistor - 12K Ω 1/8W $\pm 5\%$	9-164
1610 0079	Resistor - 22k Ω 1/8W $\pm 5\%$	9-165
1610 0107	Resistor - 1M Ω 1/8W $\pm 5\%$	9-166
1610 0286	Capacitor - 100pF 50V $\pm 10\%$	9-167
1611 4103	Resistor - 10k Ω 1/4T $\pm 5\%$	9-168

Part No.	Description	Page and Index No.
1611 4121	Resistor - 120 Ω 1/4T $\pm 5\%$	9-169
1611 4229	Resistor - 2.2 Ω 1/4W $\pm 5\%$	9-170
1611 4272	Resistor - 2.7k Ω 1/4T $\pm 5\%$	9-171
1611 4393	Resistor - 39k Ω 1/4T $\pm 5\%$	9-172
1611 4472	Resistor - 4.7k Ω $\pm 5\%$ 1/4W	9-173
1611 4563	Resistor - 56k Ω 1/4T $\pm 5\%$	9-174