

**INTERFACE BOARD**

**(5924)**

1. Interface Board (5924) .....	2
<b>Parts Index</b> .....	<b>5</b>

# 1. INTERFACE BOARD (5924)

April 1,'87

SYMBOL NO. : PRINTED NUMBER ON THE BOARD  
 INDEX No. : REFERENCE NUMBER OF NEXT PAGE

## CAPACITOR

SYMBOL NO.	INDEX NO.
C801	124
C802	124
C803	123
C804	125
C805	123
C806	122
C807	125
C808	123
C809	121
C810	124

SYMBOL NO.	INDEX NO.
C811	122
C812	124
C813	123
C814	123
C815	121

## CONNECTOR

SYMBOL NO.	INDEX NO.
CN801	105
CN802	102
CN803	104
CN804	103
CN806	2
CN807	3

## DIP SW.

SYMBOL NO.	INDEX NO.
DPS801	107

## IC

SYMBOL NO.	INDEX NO.
IC801	1
SOCKET	106
IC802	110
IC803	113
IC804	111
IC805	114
IC806	112
IC807	115
IC808	114
IC809	114

## OSCILLATOR

SYMBOL NO.	INDEX NO.
OSC801	116

## PHOTOCOUPLER

SYMBOL NO.	INDEX NO.
PC180	109

## RC ARRAY

SYMBOL NO.	INDEX NO.
HB801	120
HB802	120

## RESISTOR

SYMBOL NO.	INDEX NO.
R801	128
R802	126
R803	126
R804	127
R805	127
R806	128

## RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY801	118
RAY802	118
RAY803	118
RAY804	117
RAY805	119

## TEST PIN

SYMBOL NO.	INDEX NO.
TP801	101
TP802	101
TP803	101

## ZENER DIODE

SYMBOL NO.	INDEX NO.
ZD801	108



# PARTS INDEX

Parts No.	Description	Page and Index No.
5924 5103	IC - $\mu$ PD8041AC	3 - 1

Parts No.	Description	Page and Index No.
5918 5711	Fiber Output Connector	3 - 2
5918 5712	Fiber Input Connector	3 - 3

Parts No.	Description	Page and Index No.
1101 0328	Connector Pin Contact	3-101
1103 1177	Connector - 26P	3-102
1103 1733	Connector - 11P	3-103
1103 3019	Connector - 16P	3-104
1103 3036	Connector - 26P	3-105
1104 0338	IC Socket - 40P	3-106
1204 1326	Dip Switch	3-107
1402 0269	Zener Diode - RD39F	3-108
1403 0317	Photocoupler - ON3112	3-109
1407 0423	IC - SN7473N	3-110
1407 0975	IC - HD7407P	3-111
1407 1016	IC - $\mu$ PD8255AC-5	3-112
1407 1348	IC - TD62304P	3-113
1407 1535	IC - TD62308AP	3-114
1408 0099	IC - HA17901P	3-115
1503 0062	Ceramic Oscillator - 6MHz	3-116
1601 7352	Resistor Array - 4.7KOHM	3-117
1601 7374	Resistor Array - 4.7KOHM	3-118
1601 7381	Resistor Array - 68KOHM	3-119
1602 0934	RC Array - CR01-R	3-120
1604 1383	Capacitor - 22 $\mu$ F 50V	3-121
1604 1386	Capacitor - 100 $\mu$ F 50V	3-122
1606 0998	Capacitor - 0.01 $\mu$ F 50V	3-123
1606 0999	Capacitor - 0.1 $\mu$ F 25V	3-124
1606 1129	Capacitor - 30pF 50V	3-125
1611 4102	Resistor - 1KOHM 1/4T $\pm$ 5%	3-126
1611 4103	Resistor - 10KOHM 1/4T $\pm$ 5%	3-127
1611 4181	Resistor - 180OHM 1/4T	3-128

Parts No.	Description	Page and Index No.