

PT270 (A898)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.1 Bin Tray unit (A898).....	2
PARTS INDEX	5

1.1 Bin Tray unit (A898)



1.1 Bin Tray unit (A898)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A898 2611	Tray Exit	1
2	A898 2615	Guide Tray Exit	1
3	A898 2612	Tray Exit Auxiliary	1
4	A898 2622	Film Guide Uppre	1
5	A898 2621	Guide Tray Exit Upper	1
6	A898 1321	Cover Drive	1
7	A898 1131	Frame Lower	1
8	A898 1331	Pulley - 22/31Z	2
9	AA04 3522	Timing Belt - B30S3M189	1
10	A898 1231	Pulley - 15Z	1
11	AA06 3341	Compression Spring	2
12	A898 1221	Exit Roller Drive	1
13	AA12 0094	Antistatic Brush	1
14	5447 2681	Snap Ring	1
15	A898 1121	Frame Upper	1
16	A898 1151	Roller Driven Entrance	4
17	AA06 6317	Torsion Spring	1
18	A898 1421	LED Harness	1
19	A629 5110	Paper Indicator Board	1
20	AW01 0088	Sensor GP2A200LCS - Assembly	1
21	A898 1161	Exit Roller Driven	1
22	AA08 0232	Bushing - M4	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0805 3480	Bushing - 6mm	
103	0451 3008B	Tapping Screw - M3x8	

PARTS INDEX

Part No.	Description	Page and Index No.
A898 1121	Frame Upper	3- 15
A898 1131	Frame Lower	3- 7
A898 1151	Roller Driven Entrance	3- 16
A898 1161	Exit Roller Driven	3- 21
A898 1221	Exit Roller Drive	3- 12
A898 1231	Pulley - 15Z	3- 10
A898 1321	Cover Drive	3- 6
A898 1331	Pulley - 22/31Z	3- 8
A898 1421	LED Harness	3- 18
A898 2611	Tray Exit	3- 1
A898 2612	Tray Exit Auxiliary	3- 3
A898 2615	Guide Tray Exit	3- 2
A898 2621	Guide Tray Exit Upper	3- 5
A898 2622	Film Guide Uppre	3- 4

Part No.	Description	Page and Index No
AA04 3522	Timing Belt - B30S3M189	3- 9
AA06 3341	Compression Spring	3- 11
AA06 6317	Torsion Spring	3- 17
AA08 0232	Bushing - M4	3- 22
AA12 0094	Antistatic Brush	3- 13
AW01 0088	Sensor GP2A200LCS - Assembly	3- 20

Part No.	Description	Page and Index No.
A629 5110	Paper Indicator Board	3- 19

Part No.	Description	Page and Index No.
5447 2681	Snap Ring	3- 14

Part No.	Description	Page and Index No.
0450 3008B	Tapping Screw - M3x8	3-101
0451 3008B	Tapping Screw - M3x8	3-103
0805 3480	Bushing - 6mm	3-102

Part No.	Description	Page and Index No.