

SR400 (A379)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

1. Exterior (A379)	2
2. Transport Section 1(A379)	4
3. Transport Section 2(A379)	6
4. Stapler Unit 1(A379)	8
5. Stapler Unit2(A379)	10
6. Stapler Unit3(A379)	12
7. Paper Exit Section (A379)	14
8. Shift Tray Section (A379)	16
9. Drive and Electrical Section 1(A379)	18
10. Drive and Electrical Section2(A379)	20
11. Frame Section (A379)	22
12. Main Board (A379)	24
13. Decal and Document (A379)...	28
Parts Index	31

1. EXTERIOR (A379)




1. EXTERIOR (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 3451	Small Shift Tray	1
2	A379 6251	Upper Left Cover	1
3	A379 3491	Shift Tray Shaft	2
4	A379 3411	Large Shift Tray	1
5	A379 3551	Rear Tray Cover	1
6	A379 6211	Top Cover	1
7	A379 6311	Rear Cover	1
8	A379 6111	Front Door	1
9	A353 4311	Safety Switch Actuator	1
10	A379 6121	Upper Hinge	1
11	A379 6131	Lower Hinge	1
12	A379 6171	Lower Front Cover	1
13	A379 6151	Upper Inner Cover	1
14	A379 3511	Front Tray Cover	1
15	A379 6411	Lower Left Cover	1
16	A377 1187	Rear Joint Bracket	1
18	A377 1186	Front Joint Bracket	1
19	A379 2329	Entrance Guide	1
20	A379 4921	Lower Cushion - 5x10x637	1
21	A379 4711	Decal - Misfeed Removal	1
22	5316 3062	Cushion - Cutter	1
23	A379 4922	Upper Cushion - 5x10x125	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0414 0082B	Binding Self Tapping Screw - M4x8	
104	0314 0120B	Philips Pan Head Screw - M4x12	
105	0344 0080F	Philips Truss Head Screw- M4x8	

2. TRANSPORT SECTION 1 (A379)




2. TRANSPORT SECTION 1 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 2523	Exit Guide Mylar	1
2	A379 2521	Exit Guide Plate	1
3	A379 2311	Upper Guide Plate	1
4	A379 2318	Upper Magnet Sheet	2
5	AF02 0305	Transport Roller	5
6	A300 3155	Stepped Screw-M25x32	1
7	A379 2711	Junction Gate	1
8	AB03 0374	Timing Pulley-20Z	2
9	A379 2323	Upper Support Plate	1
10	A458 2479	Lock Pin Spring	12
11	AA08 0034	Bushing - 4x5x7	12
12	AF02 2075	Driven Roller	6
13	AG07 0004	Magnetic Catch	5
14	5409 1855	Mounting Pin	11
15	A379 2322	Entrance Guide	1
16	A379 2326	Supporting Entrance Guide	1
17	A353 2243	Lever Knob	1
18	A353 2265	Decal - R1	1
19	A379 5915	Spring Plate	1
20	A300 3153	Safety Switch Bracket	1
21	A379 2525	Exit Guide Mylar-2	1
22	5053 0447	Bushing - 6mm	2
23	AA14 3215	Screw - M5x6	1
24	A379 4751	Decal - R1	1
25	A379 5712	Safety Switch Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082B	Binding Self Tapping Screw - M4x8	
102	0720 0040B	Retaining Ring - M4	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0805 0088	Retaining Ring - M6	
105	0802 5210	Tapping Screw - M3x8	
106	0353 0060F	Philips Truss Head Screw - M3x6	
107	0353 0040B	Screw - M3x4	
108	1204 2188	Interlock Switch	

3. TRANSPORT SECTION 2 (A379)




3. TRANSPORT SECTION 2 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 2411	Lower Entrance Guide	1
2	A377 2121	Relay Guide	1
3	AW02 0049	Photointerruptor - OS - 580213-703	3
4	A379 2416	Entrance Sensor Bracket	1
5	A458 2479	Lock Pin Spring	12
6	AA08 0034	Bushing - 4x5x7	12
7	AF02 2075	Driven Roller	6
8	5409 1855	Mounting Pin	11
9	A379 2431	Transport Guide	1
10	A300 3244	Spring Plate	1
11	A300 3233	Transport Guide Knob	1
12	A379 2421	Vertical Transport Guide	1
13	AA14 3059	Pin - 6x16	4
14	AF02 0305	Transport Roller	5
15	5447 2681	Snap Ring	2
16	AB03 0374	Timing Pulley - 20Z	2
17	AG07 0004	Magnetic Catch	5
18	5053 0447	Bushing - 6mm	13
19	A379 4752	Decal - R2	1
20	A351 3143	Bushing - EO-12N 22mm	2
21	A379 2425	Exit Lower Guide	2
22	A379 2426	2nd Exit Lower Guide	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0720 0040B	Retaining Ring - M4	

4. STAPLER UNIT 1 (A379)




4. STAPLER UNIT 1 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A300 3544	Upper Cover	1
2	A300 3543	Exit Cover	2
3	A300 3812	Spacer - 6x22x1.5	9
4	AB03 0229	Timing Pulley - 20Z	3
5	A379 4127	Middle Guide Seal	2
6	A379 4259	Positioning Fence Mylar	2
7	A300 3533	Upper Stay	1
8	AA04 3100	Timing Belt-900P2M4	2
9	A300 3635	Belt Clamp	2
10	5053 0447	Bushing - 6mm	13
11	A379 4131	Jogger Fence Slider	2
12	A028 7535	Antistatic Brush	3
13	5201 2722	Bushud Roller	2
16	A300 3626	Lower Guide Seal	2
17	AW02 0013	Inlet Sensor	1
18	A300 3621	Rear Jogger Fence	1
19	A300 3611	Front Jogger Fence	1
20	A379 4256	Rear Stapler Positioning Fence	1
21	A300 3757	Pad - 56x2.5x1	2
22	AB03 0030	Pulley - 17Z	1
23	AW01 0025	Photosensor - No2530	1
24	A422 1078	Bushing - 6x12x4mm	1
25	A300 3661	Slider Guide Rod	2
26	A379 4251	Slide Holder	2
27	A300 3759	Spring	2
28	A300 3545	Lower Cover	1
29	A300 3813	Shaft - 6x21.5	2
30	A379 4331	Paper Feed Guide Plate	1
31	A300 3816	Timing Belt -900 S2M14	1
32	A300 3641	Fixing Plate	1
33	A300 3815	Spring Plate	1
34	A300 3646	Jogger Idler Bracket	2
35	A379 4261	Positioning Guide Plate	1
36	A300 3841	Position Sensor Bracket	1
37	AB03 0227	Pulley - 32Z	2

Index No.	Part No.	Description	Q'ty Per Assembly
38	A379 4255	Front Stapler Positioning Fence	1
39	A300 3618	Antistatic Guide Seal	2
40	A300 3634	Spring Plate - Timing Belt	2
41	A379 4335	Cushion - 2x35x165	2
42	A379 4401	Upper Exit Shaft	1
43	5875 2088	Shoulder Screw - M4	2
102	0313 0060W	Philips Pan Head Screw - M3x6	
103	0313 0100W	Philips Pan Head Screw - M3x10	
104	0313 0140B	Philips Pan Head Screw - M3x14	
105	0314 0060W	Philips Pan Head Screw - M4x6	
106	0344 0060F	Philips Truss Head Screw - M4x6	
107	0623 0120E	Spring Pin - M3x12	
108	0951 4006W	Philips Screw With Flat Washer-M4x6	
109	0951 4008W	Philips Screw With Flat Washer-M4x8	
110	0720 0040E	Retaining Ring - M4	
111	0741 3506	Ball Bearing - 6x12x4 mm	

5. STAPLER UNIT 2 (A379)




5. STAPLER UNIT 2 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A300 3733	Stapler Guide Rod	1
2	A300 3812	Spacer - 6x22x1.5	2
3	A300 3717	Slide Belt Holder - Stapler	1
4	A379 4211	Stapler Slide Holder	1
5	AB03 0227	Pulley - 32Z	2
6	A300 3736	Lift Up Spring	1
7	A300 3537	Slide Rail - Center	1
8	A300 2132	Guide Roller	1
9	A300 3731	Slide Supporter	4
10	A300 3746	Stapler Lock Shaft	1
11	A300 3747	Pick - Off Lever	1
12	A300 3721	Staplr Holder	1
13	A409 1234	Exit Motor - DC 9W	1
14	A300 5541	Stapler Harness -2	1
15	A300 3743	Spring Plate	1
16	A300 3741	Stapler Lock Arm	1
17	A300 3521	Rear Frame	1
18	AB01 0055	Gear - 46Z/13Z	1
19	A300 3822	Spacer - 11x15x1	1
20	AA04 3104	Timing Belt -219 P3M4	1
21	A300 3539	Mounting Shaft	1
22	AX06 0089	Stepping Motor - DC4.5W	2
23	AB03 0382	Timing Pulley - 24Z	1
24	A379 4155	Jogger Motor Bracket	1
25	A499 5501	Stapler Harness -1	1
26	A300 3511	Front Frame	1
27	AB03 3028	Pulley - 32Z/31Z	1
28	AB01 1085	Gear -14Z/31Z	1
29	A379 4271	Slide Motor Bracket	1
30	AB01 1141	Gear - 14Z	1
31	A300 3551	Grip Stapler Unit	1
32	A300 5521	Stapler Tray Harness	1
33	A300 3732	Stapler Guide Rail	1
34	AW02 0006	Photointerruptor - EE-SX460-P2	4
35	A300 3638	Jogger Sensor Bracket	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	A379 4225	Stapler Cover	1
37	A300 3531	Lower Left Plate	1
38	AA04 3100	Timing Belt -900 P2M4	2
39	A379 4221	Stapler Stand	1
40	A379 4222	Stapler Connector Bracket	1
41	A300 3646	Jogger Idler Bracket	2
42	AJ01 1007	Stapler - EH-5RR4	1
43	A379 4226	Guide Sheet	1
44	5409 1855	Mounting Pin	11
101	0313 0060W	Philips Pan Head Screw - M3x6	
102	0313 0080W	Philips Pan Head Screw - M3x8	
103	0314 0060W	Philips Pan Head Screw - M4x6	
104	0574 0040E	Hexagon Headless Set Screw - M4x4	
105	0584 0061W	Hexagon Bolt - M4x6	
106	0720 0040E	Retaining Ring - M4	
107	0720 0060E	Retaining Ring - M6	
108	0740 3008	Ball Bearing - 8x22x7	
109	0951 4006W	Philips Screw With Flat Washer-M4x6	
110	0951 4008W	Philips Screw With Flat Washer-M4x8	
111	0313 0140B	Philips Pan Head Screw - M3x14	
112	1105 0005	Nylon Clip - 3N	
113	0803 0017	Knob Screw - M4x6.5	
114	1105 0234	Clamp	
115	1105 0200	Clamp	
116	0951 3008W	Philips Screw With Flat Washer-M3x8	

6. STAPLER UNIT 3 (A379)




6. STAPLER UNIT 3 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5919 2132	Positioning Roller Belt	1
2	A300 3856	Positioning Roller Shaft	1
3	5919 2127	Positioning Roller Pulley	1
4	5053 0447	Bushing - 6mm	13
5	A379 2811	Positioning Roller Arm	1
6	AA06 0557	Positioning Roller Spring	1
7	AA16 1099	Lever Cushion	1
8	A300 3851	Positioning Roller Bracket	1
9	5206 2671	Positioning Roller	1
10	5447 2681	Snap Ring	2
11	A379 2610	Exit Transport Roller	1
12	A300 3271	Positioning Brush	1
13	A300 3272	Rear Positioning Brush	1
14	A379 2610	Paddle Roller	4
15	A379 2610	Exit Transport Roller	2
16	AA12 0027	Antistatic Brush	2
17	A028 7535	Antistatic Brush	3
18	A379 2512	Supporting Lower Guide	1
19	A458 2479	Lock Pin Spring	12
20	AA08 0034	Bushing - 4x5x7	12
21	AF02 2075	Driven Roller	6
22	A379 2511	Lower Guide Plate	1
23	5920 2144	Spring - Lock	2
24	AA08 0071	Bushing -6x10x6	6
25	AB03 0374	Timing Pulley - 20Z	1
26	AB03 0340	Brush Roller Pulley	1
27	A379 4761	Decal -R2 19x29	1
28	AA14 3215	Screw - M5x6	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0623 0120E	Spring Pin - M3x12	
102	0720 0040B	Retaining Ring - M4	
103	0414 0082B	Binding Self Tapping Screw - M4x8	
104	0314 0050B	Philips Pan Head Screw - M4x5	
105	0314 0060B	Philips Pan Head Screw - M4x6	

7. PAPER EXIT SECTION (A379)




7. PAPER EXIT SECTION (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A353 3171	Upper Sensor Actuator	1
2	A353 3172	Actuator Bracket	1
3	A353 3173	Pressure Spring	1
4	A379 1211	Upper Exit Stay	1
5	A353 3181	Exit Sensor Bracket	1
6	AW02 0006	Photointerruptor - EE-SX460-P2	4
7	A379 5716	Paper Sensor Harness	1
8	A379 2115	Reverse Roller	1
9	A353 3192	Front Arm	2
10	A353 3201	Exit Roller	4
11	A379 2112	Exit Roller Ring	4
12	AA04 3181	Timing Belt - B40S2M80	1
13	AB03 0378	Timing Pulley - 20Z	1
14	AB03 0377	Timing Pulley - 28Z	1
15	A353 3197	Rear Arm	1
16	5420 4860	Bushing - 8mm	2
17	AB01 3712	Gear - 52Z	1
18	AB03 0375	Timing Pulley - 30Z	2
19	A379 1636	Pulley Flange - 8x35x1	1
20	A379 2111	Exit Roller Shaft	1
21	A379 3731	Lift Drive Shaft	1
22	A379 2221	Lower Exit Guide	1
23	AA12 0027	Antistatic Brush	2
24	A028 7535	Antistatic Brush	3
25	A379 2213	Exit Guide Bracket	1
26	A353 3354	Driven Roller Holder	1
27	A010 5700	Sensor	1
28	A379 5719	Exit Sensor Harness	1
29	A379 2215	Exit Mylar	1
30	A379 2211	Exit Guide	1
31	A379 2212	Driven Roller Shaft	1
32	A353 3351	Exit Driven Roller	2
33	A300 2752	Spacer 8x12x12	1
34	AA14 3215	Screw - M5x6	4
35	5053 0447	Bushing - 6mm	13

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0951 4006B	Philips Screw With Washer - M4x6	
103	1105 0200	Clamp	
104	1105 0328	Harness Clamp - ES-0505	
105	0805 0088	Retaining Ring - M6	
106	0633 0120G	Parallel Pin - 3x12	
107	0633 0140G	Parallel Pin - 3x14	
108	0720 0060B	Retaining Ring - M6	
109	0720 0040B	Retaining Ring - M4	
110	0414 0082B	Binding Self Tapping Screw - M4x8	
111	0313 0100B	Philips Pan Head Screw - M3x10	

8. SHIFT TRAY SECTION (A379)




8. SHIFT TRAY SECTION (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 6161	Front Supporting Cover	1
2	A379 3133	Switch Lever	1
3	A379 3132	Switch Bracket	1
4	A353 3231	Bushing-4x6x9mm	1
5	A379 3141	End Fence	1
6	A379 3111	Shift Tray Guide	2
7	A379 3131	Exit Roller Cover	1
8	A379 3121	Exit Stay	2
9	A379 3351	Safety Switch Bracket	1
10	A379 3341	Shift Tray Holder	1
11	A379 3711	Timing Belt Stopper	2
12	A379 3321	Rear Shift Guide	1
13	A379 3331	Shift Tray Base	1
14	A353 3271	Tray Shift Shaft	2
15	AA13 2024	Spacer-M6	5
16	A353 3272	Guide Roller	4
17	A379 3311	Front Shift Guide	1
18	A379 3191	End Fence Cover	2
20	A353 3341	Shift Drive Cam	2
21	A379 5718	Upper Limit Sensor Harness	1
22	A353 3151	Tighter Bracket	2
23	A379 3811	Shift Drive Bracket	1
24	A353 3346	Shift Drive Shaft	1
25	AX05 0055	DC Motor -DC 9W	1
26	AW02 0049	Photointerruptor - OS - 580213-703	3
27	A353 3347	Shift Sensor Bracket	1
28	A379 5717	Shift Sensor Harness	1
29	C101 1327	Timing Belt - PX146P2M	1
30	AB03 0381	Timing Pulley -262	1
31	A379 3316	Shift Guide Roller	4
32	AB03 0376	Timing Pulley -302	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0313 0060B	Philips Pan Head Screw - M3x6	
103	0720 0040B	Retaining Ring - M4	
104	0806 5019	Timing Belt - 1005XL	
105	0951 4006B	Philips Screw With Washer- M4x6	
106	0720 0060B	Retaining Ring - M6	
107	1105 0200	Clamp	
108	1105 0283	Clamp	
109	1204 1081	Microswitch	
110	0314 0120B	Philips Pan Head Screw - M4x12	

9. DRIVE AND ELECTRICAL SECTION 1 (A379)




9. DRIVE AND ELECTRICAL SECTION 1 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C101 2445	Presuer Spring	1
2	AX10 0021	Junction Gate Solenoid	1
3	A379 2715	Solenoid Bracket	1
4	5940 2641	Feed-in Solenoid Spring	1
5	AA06 0092	Release Spring	3
6	AB03 0455	Tightener Pulley - 8X20X13	3
7	A379 1621	Tightener	1
8	AB03 3060	Timing Pulley - 18/33Z	2
9	AA04 3237	Timing Belt - B40S3M483	1
10	A379 6225	Cover Angle	3
11	A300 3151	Support Bracket	5
12	A379 2820	Positioning Roller Solenoid	1
13	5446 5832	Connector Guide Pin	2
14	A300 3865	Release Spring	1
15	A300 3858	Stepped Screw - M4	1
16	A379 1171	Lower Joint Bracket	1
17	A379 5714	Stapler Main Harness	1
18	AG07 0004	Magnetic Catch	5
19	A379 1172	Upper Joint Bracket	1
20	A377 2221	Tightener	2
21	AA04 3236	Timing Belt - B40S3M600	1
22	AA06 3068	Spring Connector	2
23	AB03 0278	Idler -202	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 0088	Retaining Ring - M6	
102	0951 4006B	Philips Screw With Washer - M4x6	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	1106 0383	Supportor - P.C.B.	
105	1105 0159	Pcb Stud	
106	0313 0050B	Philips Pan Head Screw- M3x5	
107	0623 0120E	Spring Pin - M3x12	
108	1105 0200	Clamp	
109	1105 0310	Wire Clamp	

10. DRIVE AND ELECTRICAL SECTION 2 (A379)




10. DRIVE AND ELECTRICAL SECTION 2 (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 5912	I/F Cover	1
2	A379 1610	Main Motor - DC 15W	1
3	AB03 0454	Timing Pulley - 20Z	1
4	AA04 3361	Timing Belt - B40S3M633	1
5	AB03 0223	Pulley - 48Z	1
6	AA04 3054	Timing Belt -142 P2M4	1
7	A379 3611	Lift Drive Bracket	1
8	A300 2726	Worm Gear Shaft	1
9	AB01 3709	Worm Gear	1
10	AX05 0058	DC Motor - 24V 9W	1
11	AB01 3809	Worm Wheel - 44z	1
12	AB01 3857	Gear-18Z	1
13	AB01 3710	Gear - 40Z	1
14	A353 3113	Pressure Spring	1
15	AX05 0057	Stepping Motor - DC24V 3.84W	1
16	AB03 0216	Pulley - 15Z	1
17	A379 1711	Motor Bracket	1
18	A379 5720	Grounging Harness	1
19	AA04 3238	Timing Belt - B40S2M206	1
20	A379 6321	Rear Supporting Cover	1
21	A379 5911	Upper Harness Bracket	1
22	A379 5601	Main Control Board	1
23	A379 5651	IC - AM27C256-200DC	1
24	AW02 0012	Photointerruptor	1
25	A379 5713	I/F harness	1
26	A379 5711	Main Harness	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0574 0040E	Hexagon Headless Set Screw - M4x4	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	1107 0752	Fuse - 5A 250V	
104	0720 0060B	Retaining Ring - M6	
105	0807 5056	Washer -8.1 mm	
106	0720 0040B	Retaining Ring - M4	
107	0313 0060B	Philips Pan Head Screw - M3x6	
108	0741 3506	Ball Bearing - 6x12x4 mm	
109	0314 0080B	Philips Pan Head Screw - M4x8	
110	0313 0050B	Philips Pan Head Screw - M3x5	
111	1105 0291	Wire Saddle	
112	1105 0310	Wire Clamp	
113	1106 0383	Supportor - P.C.B.	
114	1105 0159	Pcb Stud	

11. FRAME SECTION (A379)



11. FRAME SECTION (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A379 1141	Right Stay	4
2	AA07 0024	Slide Rail	1
3	A379 1161	Left Stay	1
4	A379 1311	Joint Stay	1
5	A377 1182	Joint Lever	1
6	5413 1882	Stepped Screw	2
7	AH01 2010	Caster - 50m	4
8	AW02 0049	Photointerruptor - OS - 580213-703	3
9	A379 2441	Exit Sensor Bracket	1
10	A379 5714	Stapler Main Harness	1
11	A377 5495	Grounding Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0344 0060F	Philips Truss Head Screw - M4x6	
103	0315 0080B	Philips Pan Head Screw - M5x8	
104	1105 0200	Clamp	
105	0950 4008B	Philips Screw With Spring Washer- M4x8	

12. MAIN BOARD (A379)

CAPACITOR

SYMBOL NO.	INDEX NO.
C 1	150
C 2	151
C 3	146
C 4	156
C 5	156
C 6	151
C 7	147
C 8	148
C 9	151
C10	151

SYMBOL NO.	INDEX NO.
C11	151
C12	149
C13	154
C14	152
C15	154
C16	152
C17	152
C18	154
C19	152
C20	152

SYMBOL NO.	INDEX NO.
C21	152
C22	152
C23	152
C24	152
C25	152
C26	152
C27	152
C28	152
C29	152
C30	154

SYMBOL NO.	INDEX NO.
C31	152
C32	154
C33	152
C34	152
C35	152
C36	152
C37	152
C38	152
C39	152
C40	152

SYMBOL NO.	INDEX NO.
C41	154
C42	152
C43	152
C44	152
C45	155
C46	152
C47	152
C48	152
C49	152
C50	152

SYMBOL NO.	INDEX NO.
C51	152
C52	152
C53	152
C54	152
C55	152
C56	153
C57	152
C58	152
C59	152
C60	154

SYMBOL NO.	INDEX NO.
C61	154
C62	152
C63	152
C64	152
C65	152
C66	152
C67	152
C68	152
C69	152
C70	179

CONNECTOR

SYMBOL NO.	INDEX NO.
C71	152
C72	152
C73	152
C74	152
C75	152
C76	180
C78	179

SYMBOL NO.	INDEX NO.
CN101	103
CN102	106
CN103	102
CN104	187
CN105	187
CN106	111
CN107	110
CN108	107
CN109	188
CN110	104

SYMBOL NO.	INDEX NO.
CN111	109
CN112	188
CN113	189
CN114	105
CN115	190
CN116	190

DI

SYMBOL NO.	INDEX NO.
D101	186
D102	186

FUSE

SYMBOL NO.	INDEX NO.
FUSE1 (Socket)	114 112

DIODE

SYMBOL NO.	INDEX NO.
D1	123
D2	121
D3	121
D4	121
D5	121

IC

SYMBOL NO.	INDEX NO.
IC 1	
IC 2	
IC 3	
IC 4	
IC 5	132
IC 6	128
IC 7	125
IC 8	127
IC 9	141
IC10	139

SYMBOL NO.	INDEX NO.
IC11 (Socket)	1 113
IC12	135
IC13	131
IC14	135
IC15	138
IC16	137
IC17	129
IC18	130
IC19	134
IC20	130

12. MAIN BOARD (A379)

IC

SYMBOL NO.	INDEX NO.
IC21	126
IC22	133

PC

SYMBOL NO.	INDEX NO.
PC1	124
PC2	124

RESISTOR

SYMBOL NO.	INDEX NO.
R 1	144
R 2	157
R 3	144
R 4	160
R 5	159
R 6	158
R 7	169
R 8	169
R 9	169
R10	168

SYMBOL NO.	INDEX NO.
R11	168
R12	168
R13	161
R14	173
R15	173
R17	173
R18	169
R19	168
R20	169

SYMBOL NO.	INDEX NO.
R21	168
R22	173
R23	173
R24	172
R25	163
R26	163
R27	163
R28	173
R29	173
R30	173

SYMBOL NO.	INDEX NO.
R31	173
R32	173
R33	173
R34	173
R35	173
R36	163
R37	163
R38	163
R39	163
R40	163

SYMBOL NO.	INDEX NO.
R41	163
R42	163
R43	163
R44	163
R45	163
R46	163
R47	163
R48	163
R49	163
R50	162

LED

SYMBOL NO.	INDEX NO.
LED21	122
LED22	122

REG

SYMBOL NO.	INDEX NO.
REG1	136

SYMBOL NO.	INDEX NO.
R51	162
R52	162
R53	162
R54	162
R55	162
R56	162
R57	162
R58	162
R59	162
R60	162

SYMBOL NO.	INDEX NO.
R61	162
R62	163
R63	163
R64	162
R65	162
R66	162
R67	162
R68	169
R69	171
R70	171

SYMBOL NO.	INDEX NO.
R71	169
R72	168
R73	168
R74	163
R75	163
R76	168
R77	168
R78	168
R79	168
R80	168

SYMBOL NO.	INDEX NO.
R81	168
R82	168
R83	169
R84	169
R85	169
R86	169
R87	169
R88	169
R89	169
R90	173

SYMBOL NO.	INDEX NO.
R 91	162
R 92	173
R 93	163
R 94	161
R 95	169
R 96	168
R 97	173
R 98	173
R 99	169
R100	168

SYMBOL NO.	INDEX NO.
R101	175
R102	178
R103	173
R104	173
R105	173
R106	173
R107	162
R108	162
R109	162
R110	162

SYMBOL NO.	INDEX NO.
R111	168
R112	169
R113	178
R114	176
R115	173
R116	163
R117	168
R118	173
R119	161
R120	163

12. MAIN BOARD (A379)

SYMBOL NO.	INDEX NO.
R121	163
R122	163
R123	163
R124	163
R125	163
R126	163
R127	167
R129	167
R130	173

SYMBOL NO.	INDEX NO.
R131	173
R132	177
R133	173
R134	170
R135	173
R136	173
R137	174
R138	164
R139	166
R140	164

SYMBOL NO.	INDEX NO.
R141	173
R142	166
R143	168
R144	169
R145	164
R147	164
R148	173
R150	167

SYMBOL NO.	INDEX NO.
R151	167
R152	184
R153	165
R154	185
R155	173
R156	173
R157	173
R158	173
R159	175
R160	165

SYMBOL NO.	INDEX NO.
R161	176
R162	173
R163	173
R164	173
R165	173
R166	169
R167	168
R168	163
R169	162
R170	173

SYMBOL NO.	INDEX NO.
R171	163
R172	181
R173	167
R175	182
R176	182
R177	161
R178	183
R179	183
R180	183
R181	183

SW

SYMBOL NO.	INDEX NO.
SN101	115
SN102	115

TEST POINT

SYMBOL NO.	INDEX NO.
TP3	101

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q1	116
Q2	116
Q3	118
Q4	120
Q5	119
Q7	117
Q8	116

VR

SYMBOL NO.	INDEX NO.
VR1	145

XTL

SYMBOL NO.	INDEX NO.
XTL1	142
XTL2	143

12. MAIN BOARD (A379)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A379 5601	Main Control Board	1
1	A379 5651	IC - AM27C256-200DC	1
2	A377 5150	IC - TC110G03AF-0071	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1101 0328	Connector Pin Contact	
102	1102 0958	Connector - 2P	
103	1102 1048	Pin Housing - Mate-n-lock - 3P	
104	1102 4205	CT Header-6P	
105	1102 4211	CT Header- 12P	
106	1102 5003	Connector - 2P	
107	1102 5345	Connector - 18P	
108	1103 1768	Connector - 2P	
109	1103 1771	Connector - 5P	
110	1103 1772	Pin Header - 6P	
111	1103 1778	Pin Header - 12P	
112	1104 0333	Fuse Holder	
113	1104 0413	Connector - 28P	
114	1107 0752	Fuse - 5A 250V	
115	1204 1385	Push Switch	
116	1400 0072	Transistor - 2SC372Y	
117	1400 0423	Transistor - 2SA1121C	
118	1400 0486	Transistor - 2SA1020	
119	1401 0200	Transistor - 2SD633	
120	1401 0282	Transistor - 2SB1020	
121	1402 0780	Diode -11ES2	
122	1402 0783	Red LED - GL3PR8	
123	1402 0874	Diode - RL2Z	
124	1403 0519	Photocoupler - TLP621	
125	1407 1882	IC - 74LS373	
126	1407 2054	IC - TD62308F	
127	1407 2057	IC - 82C55AFP-5	
128	1407 2058	IC - 82C54FP-6	
129	1407 2089	IC - TC4024BF	
130	1407 2218	IC - SN74LS06NS	
131	1407 3321	IC - MC74HC00AF	
132	1407 3492	CPU -78C10AGF	
133	1407 4145	IC - HD74LS07PF	
134	1408 0397	Comparator - NJM2901M	
135	1408 0398	IC - NJ2903M	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1408 0538	IC - SI8301L	
137	1408 0598	Ic - MB3773PF	
138	1408 0599	Ic - M51971EP	
139	1408 0827	IC - TA8429H	
140	1408 1050	IC - STK6712 BMK4	
141	1408 0840	IC - HR052	
142	1503 0333	Ceramic Oscillator - 6.0mg	
143	1503 0347	Oscillator - 12MHz	
144	1600 1354	Resistor Array -1K OHM 1W	
145	1601 8148	Variable Resistor - 20K OHM 0.5W	
146	1604 1360	Capacitor - 3300µF 10V	
147	1604 1378	Capacitor - 1µF 50V	
148	1604 1380	Capacitor - 3.3µF 50V	
149	1604 1382	Capacitor - 10µF 50V	
150	1604 1390	Capacitor - 1000µF 50V	
151	1604 2563	Capacitor - 100µF 50V	
152	1605 0216	Capacitor - 0.01µF	
153	1605 0326	Capacitor - 0.33µF	
154	1605 0636	Capacitor - 0.1µF	
155	1606 1208	Capacitor - 100PF ±5% 50V	
156	1606 1348	Capacitor - 0.02µF 50V	
157	1611 4121	Resistor -120 OHM 1/4T ±5%	
158	1611 4151	Resistor -150 OHM 1/4W ±5%	
159	1611 4241	Resistor -240 OHM 1/4W	
160	1611 4330	Resistor -330 OHM 1/4T ±5%	
161	1630 3101	Resistor - 100 OHM - 1/10W	
162	1630 3102	Resistor -1K OHM 1/10W ±5%	
163	1630 3103	Resistor - 10K OHM 1/10W ±5%	
164	1630 3152	Resistor - 1.5K OHM - 1/10W	
165	1630 3201	Resistor -200 OHM 1/10W ±5%	
166	1630 3202	Resistor - 2K OHM -1/10W	
167	1630 3222	Resistor - 2.2K OHM 1/10W ±5%	
168	1630 3223	Resistor - 22K OHM - 1/10W	
169	1630 3302	Resistor - 3K OHM - 1/10W	
170	1630 3333	Resistor - 33K OHM ±5% 1/10W	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1630 3392	Resistor - 3.9K OHM - 1/10W	
172	1630 3470	Resistor - 47 OHM 1/10W ±5%	
173	1630 3472	Resistor - 4.7K OHM 1/10W ±5%	
174	1630 3473	Resistor - 47K OHM 1/10W ±5%	
175	1630 3511	Resistor - 510 OHM 1/10W ±5%	
176	1630 3562	Resistor - 5.6K OHM ±5% 1/10W	
177	1630 3753	Resistor - 75K OHM - 1/10W	
178	1630 3822	Resistor - 8.2K OHM 1/10W ±5%	
179	1606 1136	Capacitor - 1000PF	
180	1605 0288	Capacitor - 4700PF ±5%	
181	1630 3821	Resistor - 820 OHM 1/10W	
182	1630 3560	Resistor - 56 OHM ±5% 1/10W	
183	1630 3330	Resistor - 33 OHM ±5% 1/10W	
184	1630 3431	Resistor - 430 OHM ±5% 1/10W	
185	1630 3682	Resistor - 6.8K OHM 1/10W	
186	1204 1422	Dip Switch -51D-0401	
187	1102 4202	Connector - 3P	
188	1102 4206	Connector - 7P	
189	1102 4208	Connector - 9P	
190	1102 4201	Connector - 2P	

The diagram shows a 5x2 grid of rooms. The rooms are numbered 1 through 5 in the top-left corner of each room's panel.

- Room 1:** Contains a circular table labeled **R1**.
- Room 2:** Contains a vertical strip of six small diagrams showing a person using a device. Below these is a large rectangular area with a grid of small squares, some containing letters or symbols. At the bottom of this area are two small diagrams: one showing a person sitting at a desk and another showing a person standing at a desk.
- Room 3:** Contains a circular table labeled **R1**.
- Room 4:** Contains a circular table labeled **R2**.
- Room 5:** Contains a rectangular table labeled **R2** with an arrow pointing to the right.

Index No.	Part No.	Description	Q'ty Per Assembly
1	A353 2265	Decal - R1	1
2	A379 4711	Decal - Misfeed Removal	1
3	A379 4751	Decal - R1	1
4	A379 4752	Decal - R2	1
5	A379 4761	Decal - R2 -19x29	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Part No.	Description	Page and Index No.
A379 1141	Right Stay	23- 1
A379 1161	Left Stay	23- 3
A379 1171	Lower Joint Bracket	19- 16
A379 1172	Upper Joint Bracket	19- 19
A379 1211	Upper Exit Stay	15- 4
A379 1311	Joint Stay	23- 4
A379 1610	Main Motor - DC 15W	21- 2
A379 1621	Tightener	19- 7
A379 1636	Pulley Flange - 8x35x1	15- 19
A379 1711	Motor Bracket	21- 17
A379 2111	Exit Roller Shaft	15-20
A379 2112	Exit Roller Ring	15- 11
A379 2115	Reverse Roller	15- 8
A379 2211	Exit Guide	15-30
A379 2212	Driven Roller Shaft	15-31
A379 2213	Exit Guide Bracket	15-25
A379 2215	Exit Mylar	15-29
A379 2221	Lower Exit Guide	15-22
A379 2311	Upper Guide Plate	5- 3
A379 2318	Upper Magnet Sheet	5- 4
A379 2322	Entrance Guide	5- 15
A379 2323	Upper Support Plate	5- 9
A379 2326	Supporting Entrance Guide	5-16
A379 2329	Entrance Guide	3- 19
A379 2411	Lower Entrance Guide	7- 1
A379 2416	Entrance Sensor Bracket	7- 4
A379 2421	Vertical Transport Guide	7- 12
A379 2425	Exit Lower Guide	7-21
A379 2426	2nd Exit Lower Guide	7-22
A379 2431	Transport Guide	7- 9
A379 2441	Exit Sensor Bracket	23- 9
A379 2511	Lower Guide Plate	13-22
A379 2512	Supporting Lower Guide	13- 18
A379 2521	Exit Guide Plate	5- 2
A379 2523	Exit Guide Mylar	5- 1

Part No.	Description	Page and Index No.
A379 2525	Exit Guide Mylar -2	5-21
A379 2610	Exit Transport Roller	13- 11
A379 2610	Paddle Roller	13- 14
A379 2610	Exit Transport Roller	13- 15
A379 2711	Junction Gate	5- 7
A379 2715	Solenoid Bracket	19- 3
A379 2811	Positioning Roller Arm	13- 5
A379 2820	Positioning Roller Solenoid	19- 12
A379 3111	Shift Tray Guide	17- 6
A379 3121	Exit Stay	17- 8
A379 3131	Exit Roller Cover	17- 7
A379 3132	Switch Bracket	17- 3
A379 3133	Switch Lever	17- 2
A379 3141	End Fence	17- 5
A379 3191	End Fence Cover	17- 18
A379 3311	Front Shift Guide	17- 17
A379 3316	Shift Guide Roller	17-31
A379 3321	Rear Shift Guide	17- 12
A379 3331	Shift Tray Base	17- 13
A379 3341	Shift Tray Holder	17- 10
A379 3351	Safety Switch Bracket	17- 9
A379 3411	Large Shift Tray	3- 4
A379 3451	Small Shift Tray	3- 1
A379 3491	Shift Tray Shaft	3- 3
A379 3511	Front Tray Cover	3- 14
A379 3551	Rear Tray Cover	3- 5
A379 3611	Lift Drive Bracket	21- 7
A379 3711	Timing Belt Stopper	17- 11
A379 3731	Lift Drive Shaft	15-21
A379 3811	Shift Drive Bracket	17- 23
A379 4127	Middle Guide Seal	9- 5
A379 4131	Jogger Fence Slider	9- 11
A379 4155	Jogger Motor Bracket	11-24
A379 4211	Stapler Slide Holder	11- 4
A379 4221	Stapler Stand	11- 39

Part No.	Description	Page and Index No.
A379 4222	Stapler Connector Bracket	11- 40
A379 4225	Stapler Cover	11-36
A379 4226	Guide Sheet	11-43
A379 4251	Slide Holder	9-26
A379 4255	Front Stapler Positioning Fence	9-38
A379 4256	Rear Stapler Positioning Fence	9-20
A379 4259	Positioning Fence Mylar	9- 6
A379 4261	Positioning Guide Plate	9-35
A379 4271	Slide Motor Bracket	11-29
A379 4331	Paper Feed Guide Plate	9-30
A379 4335	Cushion - 2x35x165	9-41
A379 4401	Upper Exit Shaft	9-42
A379 4711	Decal - Misfeed Removal	3-21
A379 4711	Decal - Misfeed Removal	29- 2
A379 4751	Decal - R1	5-24
A379 4751	Decal - R1	29- 3
A379 4752	Decal - R2	7- 19
A379 4752	Decal - R2	29- 4
A379 4761	Decal - R2 19x29	13-27
A379 4761	Decal - R2 -19x29	29- 5
A379 4921	Lower Cushion - 5x10X637	3-20
A379 4922	Upper Cushion - 5x10x125	3-23
A379 5601	Main Control Board	21-22
A379 5601	Main Control Board	27- *
A379 5651	IC - AM27C256-200DC	21-23
A379 5651	IC - AM27C256-200DC	27- 1
A379 5711	Main Harness	21-26
A379 5712	Safety Switch Harness	5-25
A379 5713	I/F harness	21-25
A379 5714	Stapler Main Harness	19- 17
A379 5714	Stapler Main Harness	23- 10
A379 5716	Paper Sensor Harness	15- 7
A379 5717	Shift Sensor Harness	17- 28
A379 5718	Upper Limit Sensor Harness	17-21
A379 5719	Exit Sensor Harness	15-28

Part No.	Description	Page and Index No.
A379 5720	Grounding Harness	21- 18
A379 5911	Upper Harness Bracket	21-21
A379 5912	I/F Cover	21- 1
A379 5915	Spring Plate	5- 19
A379 6111	Front Door	3- 8
A379 6121	Upper Hinge	3- 10
A379 6131	Lower Hinge	3- 11
A379 6151	Upper Inner Cover	3- 13
A379 6161	Front Supporting Cover	17- 1
A379 6171	Lower Front Cover	3- 12
A379 6211	Top Cover	3- 6
A379 6225	Cover Angle	19- 10
A379 6251	Upper Left Cover	3- 2
A379 6311	Rear Cover	3- 7
A379 6321	Rear Supporting Cover	21-20
A379 6411	Lower Left Cover	3- 15

Part No.	Description	Page and Index No.
AA04 3054	Timing Belt -142 P2M4	21- 6
AA04 3100	Timing Belt -900 P2M4	9- 8
AA04 3100	Timing Belt -900 P2M4	11-38
AA04 3104	Timing Belt -219 P3M4	11-20
AA04 3181	Timing Belt - B40S2M80	15- 12
AA04 3236	Timing Belt - B40S3M600	19-21
AA04 3237	Timing Belt - B40S3M483	19- 9
AA04 3238	Timing Belt - B40S2M206	21- 19
AA04 3361	Timing Belt - B40S3M633	21- 4
AA06 0092	Release Spring	19- 5
AA06 0557	Positioning Roller Spring	13- 6
AA06 3068	Spring Connector	19-22
AA07 0024	Slide Rail	23- 2
AA08 0034	Bushing - 4x5x7	5- 11
AA08 0034	Bushing - 4x5x7	7- 6
AA08 0034	Bushing - 4x5x7	13-20
AA08 0071	Bushing -6x10x6	13-24
AA12 0027	Antistatic Brush	13- 16
AA12 0027	Antistatic Brush	15-23
AA13 2024	Spacer - M6	17- 15
AA14 3059	Pin - 6x16	7- 13
AA14 3215	Screw - M5x6	5-23
AA14 3215	Screw - M5x6	13-28
AA14 3215	Screw - M5x6	15-34
AA16 1099	Lever Cushion	13- 7
AB01 0055	Gear - 46Z/13Z	11- 18
AB01 1085	Gear - 14Z/31Z	11-28
AB01 1141	Gear - 14Z	11-30
AB01 3709	Worm Gear	21- 9
AB01 3710	Gear - 40Z	21- 13
AB01 3712	Gear - 52Z	15- 17
AB01 3809	Worm Wheel -442	21- 11
AB01 3857	Gear - 18Z	21- 12
AB03 0030	Pulley - 17Z	9-22
AB03 0216	Pulley - 15Z	21- 16

Part No.	Description	Page and Index No.
AB03 0223	Pulley - 48Z	21- 5
AB03 0227	Pulley - 32Z	9-37
AB03 0227	Pulley -32Z	11- 5
AB03 0229	Timing Pulley - 20Z	9- 4
AB03 0278	Idler - 20Z	19-23
AB03 0340	Brush Roller Pulley	13-26
AB03 0374	Timing Pulley - 20Z	5- 8
AB03 0374	Timing Pulley - 20Z	7- 16
AB03 0374	Timing Pulley - 20Z	13-25
AB03 0375	Timing Pulley - 30Z	15- 18
AB03 0376	Timing Pulley - 30Z	17-32
AB03 0377	Timing Pulley - 28Z	15- 14
AB03 0378	Timing Pulley - 20Z	15- 13
AB03 0381	Timing Pulley - 26Z	17-30
AB03 0382	Timing Pulley - 24Z	11-23
AB03 0454	Timing Pulley - 20Z	21- 3
AB03 0455	Tightener Pulley - 8X20X13	19- 6
AB03 3028	Pulley - 32Z/31Z	11-27
AB03 3060	Timing Pulley - 18/33Z	19- 8
AF02 0305	Transport Roller	5- 5
AF02 0305	Transport Roller	7- 14
AF02 2075	Driven Roller	5- 12
AF02 2075	Driven Roller	7- 7
AF02 2075	Driven Roller	13-21
AG07 0004	Magnetic Catch	5- 13
AG07 0004	Magnetic Catch	7- 17
AG07 0004	Magnetic Catch	19- 18
AH01 2010	Caster - 50m	23- 7
AJ01 1007	Stapler - EH-5RR4	11-42
AW01 0025	Photosensor - No2530	9-23
AW02 0006	Photointerruptor - EE-SX460-P2	11-34
AW02 0006	Photointerruptor - EE-SX460-P2	15- 6
AW02 0012	Photointerruptor	21-24
AW02 0013	Inlet Sensor	9- 17
AW02 0049	Photointerruptor -OS -580213-703	7- 3

Part No.	Description	Page and Index No.
AW02 0049	Photointerruptor - OS - 580213-703	17-26
AW02 0049	Photointerruptor - OS - 580213-703	23- 8
AX05 0055	DC Motor -DC 9W	17-25
AX05 0057	Stepping Motor - DC24V 3.84W	21- 15
AX05 0058	DC Motor - 24V 9W	21- 10
AX06 0089	Stepping Motor- DC4.5W	11-22
AX10 0021	Junction Gate Solenoid	19- 2
A010 5700	Sensor	15-27
A028 7535	Antistatic Brush	9- 12
A028 7535	Antistatic Brush	13- 17
A028 7535	Antistatic Brush	15-24
A300 2132	Guide Roller	11- 8
A300 2726	Worm Gear Shaft	21- 8
A300 2752	Spacer 8x12x12	15-33
A300 3151	Support Bracket	19- 11
A300 3153	Safety Switch Bracket	5-20
A30031 55	Stepped Screw - M25x32	5- 6
A300 3233	Transport Guide Knob	7- 11
A300 3244	Spring Plate	7- 10
A300 3271	Positioning Brush	13- 12
A300 3272	Rear Positioning Brush	13- 13
A300 3511	Front Frame	11- 26
A300 3521	Rear Frame	11- 17
A300 3531	Lower Left Plate	11- 37
A300 3533	Upper Stay	9- 7
A300 3537	Slide Rail - Center	11- 7
A300 3539	Mounting Shaft	11- 21
A300 3543	Exit Cover	9- 2
A300 3544	Upper Cover	9- 1
A300 3545	Lower Cover	9- 28
A300 3551	Grip Stapler Unit	11- 31
A300 3611	Front Jogger Fence	9- 19
A300 3618	Antistatic Guide Seal	9-39
A300 3621	Rear Jogger Fence	9- 18
A300 3626	Lower Guide Seal	9- 16

Part No.	Description	Page and Index No.
A300 3634	Spring Plate - Timing Belt	9-40
A300 3635	Belt Clamp	9- 9
A300 3638	Jogger Sensor Bracket	11-35
A300 3641	Fixing Plate	9-32
A300 3646	Jogger Idler Bracket	9-34
A300 3646	Jogger Idler Bracket	11-41
A300 3661	Slider Guide Rod	9-25
A300 3717	Slide Belt Holder - Stapler	11- 3
A300 3721	Stapler Holder	11- 12
A300 3731	Slide Supporter	11- 9
A300 3732	Stapler Guide Rail	11-33
A300 3733	Stapler Guide Rod	11- 1
A300 3736	Lift Up Spring	11- 6
A300 3741	Stapler Lock Arm	11- 16
A300 3743	Spring Plate	11- 15
A300 3746	Stapler Lock Shaft	11- 10
A300 3747	Pick - Off Lever	11- 11
A300 3757	Pad - 56x2.5x1	9-21
A300 3759	Spring	9-27
A300 3812	Spacer - 6x22x1.5	9- 3
A300 3812	Spacer - 6x22x1.5	11- 2
A300 3813	Shaft - 6x21.5	9-29
A300 3815	Spring Plate	9-33
A300 3816	Timing Belt -900 S2M14	9-31
A300 3822	Spacer - 11x15x1	11- 19
A300 3841	Position Sensor Bracket	9-36
A300 3851	Positioning Roller Bracket	13- 8
A300 3856	Positioning Roller Shaft	13- 2
A300 3858	Stepped Screw - M4	19- 15
A300 3865	Release Spring	19- 14
A300 5521	Stapler Tray Harness	11-32
A300 5541	Stapler Harness -2	11- 14
A351 3143	Bushing - EO-12N 22mm	7-20
A353 2243	Lever Knob	5- 17
A353 2265	Decal - R1	5- 18

Part No.	Description	Page and Index No.
A353 2265	Decal - RI	29- 1
A353 3113	Pressure Spring	21- 14
A353 3151	Tighter Bracket	17-22
A353 3171	Upper Sensor Actuator	15- 1
A353 3172	Actuator Bracket	15- 2
A353 3173	Pressure Spring	15- 3
A353 3181	Exit Sensor Bracket	15- 5
A353 3192	Front Arm	15- 9
A353 3197	Rear Arm	15- 15
A353 3201	Exit Roller	15- 10
A353 3231	Bushing-4x6x9mm	17- 4
A353 3271	Tray Shift Shaft	17- 14
A353 3272	Guide Roller	17- 16
A353 3341	Shift Drive Cam	17-20
A353 3346	Shift Drive Shaft	17-24
A353 3347	Shift Sensor Bracket	17- 27
A353 3351	Exit Driven Roller	15-32
A353 3354	Driven Roller Holder	15-26
A353 4311	Safety Switch Actuator	3- 9
A377 1182	Joint Lever	23- 5
A377 1186	Front Joint Bracket	3- 18
A377 1187	Rear Joint Bracket	3- 16
A377 2121	Relay Guide	7- 2
A377 2221	Tightener	19- 20
A377 5150	IC - TC110G03AF-0071	27- 2
A377 5495	Grounding Harness	23- 11
A409 1234	Exit Motor - DC 9W	11- 13
A422 1078	Bushing - 6x12x4mm	9-24
A458 2479	Lock Pin Spring	5- 10
A458 2479	Lock Pin Spring	7- 5
A458 2479	Lock Pin Spring	13- 19
A499 5501	Stapler Harness -1	11-25
C101 1327	Timing Belt - PX146P2M	17- 29
C101 2445	Presuer Spring	19- 1
5053 0447	Bushing - 6mm	5-22

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7- 18
5053 0447	Bushing - 6mm	9- 10
5053 0447	Bushing - 6mm	13- 4
5053 0447	Bushing - 6mm	15-35
5201 2722	Bushud Roller	9- 13
5206 2671	Positioning Roller	13- 9
5316 3062	Cusion - Cutter	3-22
5409 1855	Mounting Pin	5- 14
5409 1855	Mounting Pin	7- 8
5409 1855	Mounting Pin	11-44
5413 1882	Stepped Screw	23- 6
5420 4860	Bushing - 8mm	15- 16
5446 5832	Connector Guide Pin	19- 13
5447 2681	Snap Ring	7- 15
5447 2681	Snap Ring	13- 10
5875 2088	Shoulder Screw - M4	9-43
5919 2127	Positioning Roller Pulley	13- 3
5919 2132	Positioning Roller Belt	13- 1
5920 2144	Spring - Lock	13-23
5940 2641	Feed-in Solenoid Spring	19- 4

Part No.	Description	Page and Index No.
0313 0050B	Philips Pan Head Screw - M3x5	19-106
0313 0050B	Philips Pan Head Screw - M3x5	21-110
0313 0060B	Philips Pan Head Screw - M3x6	17-102
0313 0060B	Philips Pan Head Screw - M3x6	21-107
0313 0060W	Philips Pan Head Screw - M3x6	9-102
0313 0060W	Philips Pan Head Screw - M3x6	11-101
0313 0080W	Philips Pan Head Screw - M3x8	11-102
0313 0100B	Philips Pan Head Screw - M3x10	15-111
0313 0100W	Philips Pan Head Screw - M3x10	9-103
0313 0140B	Philips Pan Head Screw - M3x14	9-104
0313 0140B	Philips Pan Head Screw - M3x14	11-111
0314 0050B	Philips Pan Head Screw - M4x5	13-104
0314 0060B	Philips Pan Head Screw - M4x6	3-102
0314 0060B	Philips Pan Head Screw - M4x6	5-103
0314 0060B	Philips Pan Head Screw - M4x6	7-101
0314 0060B	Philips Pan Head Screw - M4x6	13-105
0314 0060B	Philips Pan Head Screw - M4x6	15-101
0314 0060B	Philips Pan Head Screw - M4x6	17-101
0314 0060B	Philips Pan Head Screw - M4x6	19-103
0314 0060B	Philips Pan Head Screw - M4x6	21-102
0314 0060B	Philips Pan Head Screw - M4x6	23-101
0314 0060W	Philips Pan Head Screw - M4x6	9-105
0314 0060W	Philips Pan Head Screw - M4x6	11-103
0314 0080B	Philips Pan Head Screw - M4x8	21-109
0314 0120B	Philips Pan Head Screw - M4x12	3-104
0314 0120B	Philips Pan Head Screw - M4x12	17-110
0315 0080B	Philips Pan Head Screw - M5x8	23-103
0344 0060F	Philips Truss Head Screw - M4x6	3-101
0344 0060F	Philips Truss Head Screw - M4x6	9-106
0344 0060F	Philips Truss Head Screw - M4x6	23-102
0344 0080F	Philips Truss Head Screw - M4x8	3-105
0353 0040B	Screw - M3x4	5-107
0353 0060B	Philips Pan Head Screw - M3x6	7-102
0353 0060F	Philips Truss Head Screw - M3x6	5-106
0414 0082B	Binding Self Tapping Screw - M4x8	3-103

Part No.	Description	Page and Index No.
0414 0082B	Binding Self Tapping Screw - M4x8	5-101
0414 0082B	Binding Self Tapping Screw - M4x8	13-103
0414 0082B	Binding Self Tapping Screw - M4x8	15-110
0574 0040E	Hexagon Headless Set Screw - M4x4	11-104
0574 0040E	Hexagon Headless Set Screw - M4x4	21-101
0584 0061W	Hexagon Bolt - M4x6	11-105
0623 0120E	Spring Pin - M3x12	9-107
0623 0120E	Spring Pin - M3x12	13-101
0623 0120E	Spring Pin - M3x12	19-107
0633 0120G	Parallel Pin - 3x12	15-106
0633 0140G	Parallel Pin - 3x14	15-107
0720 0040B	Retaining Ring - M4	5-102
0720 0040B	Retaining Ring - M4	7-103
0720 0040B	Retaining Ring - M4	13-102
0720 0040B	Retaining Ring - M4	15-109
0720 0040B	Retaining Ring - M4	17-103
0720 0040B	Retaining Ring - M4	21-106
0720 0040E	Retaining Ring - M4	9-110
0720 0040E	Retaining Ring - M4	11-106
0720 0060B	Retaining Ring - M6	15-108
0720 0060B	Retaining Ring - M6	17-106
0720 0060B	Retaining Ring - M6	21-104
0720 0060E	Retaining Ring - M6	11-107
0740 3008	Ball Bearing - 8x22x7	11-108
0741 3506	Ball Bearing - 6x12x4 mm	9-111
0741 3506	Ball Bearing - 6x12x4 mm	21-108
0802 5210	Tapping Screw - M3x8	5-105
0803 0017	Knob Screw - M4x6.5	11-113
0805 0088	Retaining Ring - M6	5-104
0805 0088	Retaining Ring - M6	15-105
0805 0088	Retaining Ring - M6	19-101
0806 5019	Timing Belt - 1005XL	17-104
0807 5056	Washer - 8.1 mm	21-105
0950 4008B	Philips Screw With Spring Washer - M4x8	23-105
0951 3008W	Philips Screw With Flat Washer-M3x8	11-116

Part No.	Description	Page and Index No.
0951 4006B	Philips Screw With Washer - M4x6	15-102
0951 4006B	Philips Screw With Washer - M4x6	17-105
0951 4006B	Philips Screw With Washer - M4x6	19-102
0951 4006W	Philips Screw With Flat Washer-M4x6	9-108
0951 4006W	Philips Screw With Flat Washer-M4x6	11-109
0951 4008W	Philips Screw With Flat Washer-M4x8	9-109
0951 4008W	Philips Screw With Flat Washer-M4x8	11-110
1101 0328	Connector Pin Contact	27-101
1102 0958	Connector - 2P	27-102
1102 1048	Pin Housing - Mate-n-lock - 3P	27-103
1102 4201	Connector - 2P	27-190
1102 4202	Connector - 3P	27-187
1102 4205	CT Header-6P	27-104
1102 4206	Connector - 7P	27-188
1102 4208	Connector - 9P	27-189
1102 4211	CT Header - 12P	27-105
1102 5003	Connector - 2P	27-106
1102 5345	Connector - 18P	27-107
1103 1768	Connector - 2P	27-108
1103 1771	Connector - 5P	27-109
1103 1772	Pin Header - 6P	27-110
1103 1778	Pin Header - 12P	27-111
1104 0333	Fuse Holder	27-112
1104 0413	Connector - 28P	27-113
1105 0005	Nylon Clip - 3N	11-112
1105 0159	Pcb Stud	19-105
1105 0159	Pcb Stud	21-114
1105 0200	Clamp	11-115
1105 0200	Clamp	15-103
1105 0200	Clamp	17-107
1105 0200	Clamp	19-108
1105 0200	Clamp	23-104
1105 0234	Clamp	11-114
1105 0283	Clamp	17-108
1105 0291	Wire Saddle	21-111

Part No.	Description	Page and Index No.
1105 0310	Wire Clamp	19-109
1105 0310	Wire Clamp	21-112
1105 0328	Harness Clamp - ES-0505	15-104
1106 0383	Supportor - P.C.B.	19-104
1106 0383	Supportor - P.C.B.	21-113
1107 0752	Fuse - 5A 250V	21-103
1107 0752	Fuse - 5A 250V	27-114
1204 1081	Microswitch	17-109
1204 1385	Push Switch	27-115
1204 1422	Dip Switch -51D-0401	27-186
1204 2188	Interlock Switch	5-108
1400 0072	Transistor - 2SC372Y	27-116
1400 0423	Transistor - 2SA1121C	27-117
1400 0486	Transistor - 2SA1020	27-118
1401 0200	Transistor - 2SD633	27-119
1401 0282	Transistor - 2SB1020	27-120
1402 0780	Diode - 11ES2	27-121
1402 0783	Red LED - GL3PR8	27-122
1402 0874	Diode - RL2Z	27-123
1403 0519	Photocoupler - TLP621	27-124
1407 1882	IC - 74LS373	27-125
1407 2054	IC - TD62308F	27-126
1407 2057	IC - 82C55AFP-5	27-127
1407 2058	IC - 82C54FP-6	27-128
1407 2089	IC - TC4024BF	27-129
1407 2218	IC - SN74LS06NS	27-130
1407 3321	IC - MC74HC00AF	27-131
1407 3492	CPU - 78C10AGF	27-132
1407 4145	IC - HD74LS07PF	27-133
1408 0397	Comparator - NJM2901M	27-134
1408 0398	IC - NJ2903M	27-135
1408 0538	IC - S18301L	27-136
1408 0598	IC - MB3773PF	27-137
1408 0599	IC - M51971EP	27-138
1408 0827	IC - TA8429H	27-139

Part No.	Description	Page and Index No.
1408 0840	IC - HR052	27-141
1408 1050	IC - STK6712 BMK4	27-140
1503 0333	Ceramic Oscillator- 6.0mg	27-142
1503 0347	Oscillator - 12MHz	27-143
1600 1354	Resistor Array -1 K OHM 1W	27-144
1601 8148	Variable Resistor - 20K OHM 0.5W	27-145
1604 1360	Capacitor - 3300µF 10V	27-146
1604 1378	Capacitor - 1µF 50V	27-147
1604 1380	Capacitor - 3.3µF 50V	27-148
1604 1382	Capacitor - 10µF 50V	27-149
1604 1390	Capacitor - 1000µF 50V	27-150
1604 2563	Capacitor - 100µF 50V	27-151
1605 0216	Capacitor - 0.01µF	27-152
1605 0288	Capacitor - 4700PF ±5%	27-180
1605 0326	Capacitor - 0.33µF	27-153
1605 0636	Capacitor - 0.1µF	27-154
1606 1136	Capacitor - 1000PF	27-179
1606 1208	Capacitor - 100PF ±5% 50V	27-155
1606 1348	Capacitor - 0.022µF 50V	27-156
1611 4121	Resistor -120 OHM 1/4T ±5%	27-157
1611 4151	Resistor -150 OHM 1/4W ±5%	27-158
1611 4241	Resistor -240 OHM 1/4W	27-159
1611 4330	Resistor -330 OHM 1/4T ±5%	27-160
1630 3101	Resistor -100 OHM - 1/10W	27-161
1630 3102	Resistor -1K OHM 1/10W ±5%	27-162
1630 3103	Resistor - 10K OHM 1/10W ±5%	27-163
1630 3152	Resistor - 1.5K OHM - 1/10W	27-164
1630 3201	Resistor - 200 OHM 1/10W ±5%	27-165
1630 3202	Resistor - 2K OHM -1/10W	27-166
1630 3222	Resistor - 2.2K OHM 1/10W ±5%	27-167
1630 3223	Resistor - 22K OHM - 1/10W	27-168
1630 3302	Resistor - 3K OHM - 1/10W	27-169
1630 3330	Resistor - 33 OHM ±5% 1/10W	27-183
1630 3333	Resistor - 33K OHM ±5% 1/10W	27-170
1630 3392	Resistor - 3.9K OHM - 1/10W	27-171

Part No.	Description	Page and Index No.
1630 3431	Resistor - 430 OHM ±5% 1/10W	27-184
1630 3470	Resistor - 47 OHM 1/10W ±5%	27-172
1630 3472	Resistor - 4.7K OHM 1/10W ±5%	27-173
1630 3473	Resistor - 47K OHM 1/10W ±5%	27-174
1630 3511	Resistor -510 OHM 1/10W ±5%	27-175
1630 3560	Resistor - 56 OHM ±5% 1/10W	27-182
1630 3562	Resistor - 5.6K OHM ±5% 1/10W	27-176
1630 3682	Resistor - 6.8K OHM 1/10W	27-185
1630 3753	Resistor - 75K OHM - 1/10W	27-177
1630 3821	Resistor - 820 OHM 1/10W	27-181
1630 3822	Resistor - 8.2K OHM 1/10W ±5%	27-178