



Introduction 3

1. Using PostScript3

Setting up Options 5

Job Type 5

Collate..... 13

Duplex Printing 14

Color Mode..... 16

Staple 17

Paper Selection 19

Paper Size 19

Media Type..... 20

Paper source..... 21

Destination Tray 21

Resolution 22

Gradation 22

Color Profile 23

Color Setting..... 24

Dithering 26

Gray Reproduction 27

Black Over Print 28

Toner Saver 29

Color Control..... 29

User Code 30

Options 31





2. Printer Utility for Mac

Installing Printer Utility for Mac	34
Starting Printer Utility for Mac	35
Printer Utility for Mac Functions	36
Downloading PS Fonts.....	37
Displaying Printer's Fonts.....	39
Deleting Fonts.....	39
Initializing the Printer Disk.....	40
Page Setup.....	41
Printing Font Catalog.....	41
Printing Font Sample.....	41
Renaming the Printer.....	42
Restarting the Printer.....	43
Downloading PostScript Files.....	43
Selecting the Zone.....	44
Displaying the Printer Status.....	45
Launching the Dialogue Console.....	45
INDEX	47





To get maximum versatility from this machine all operators should carefully read and follow the instructions in this manual. Please keep this manual in a handy place near the printer.

Please read the Safety Information before using this printer. It contains important information related to USER SAFETY and PREVENTING EQUIPMENT PROBLEMS.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Trademarks

Microsoft[®], Windows[®] and Windows NT[®] are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe[®] and PostScript[®] are registered trademarks of Adobe Systems Incorporated.

Appletalk, Apple, Macintosh, Mac OS, Mac OS X is a registered trademark of Apple Computer, Incorporated.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.


The proper names of the Windows operating systems are as follows:

- The product name of Windows[®] 95 is Microsoft[®] Windows 95.
- The product name of Windows[®] 98 is Microsoft[®] Windows 98.
- The product name of Windows[®] Me is Microsoft[®] Windows Millennium Edition (Windows Me).
- The product names of Windows[®] XP are as follows:
 - Microsoft[®] Windows[®] XP Professional
 - Microsoft[®] Windows[®] XP Home Edition

- The product names of Windows[®] 2000 are as follows:
Microsoft[®] Windows[®] 2000 Advanced Server
Microsoft[®] Windows[®] 2000 Server
Microsoft[®] Windows[®] 2000 Professional
- The product names of Windows NT[®] 4.0 are as follows:
Microsoft[®] Windows NT[®] Server 4.0
- Microsoft[®] Windows NT[®] Workstation 4.0

Notes:

Certain options might not be available in some countries. For details, please contact your local dealer.





1. Using PostScript3

Setting up Options

This documentation describes the specific printer functions and menus that are added by installing the PPD file. For more information about the functions and menus of the Windows 95/98/Me PostScript printer driver, see the printer driver's Help.

Preparation

On a Macintosh, Mac OS 8.6 or later (Mac OS X Classic environment is supported.) or Mac OS X 10.1 or later is required.

Limitation

- If you use Mac OS X, the following functions cannot be used:
 - Sample Print
 - Locked Print
 - User Code


Job Type

Use this to select the type of print job.

The following table shows the tabs or menus where you can select this function.

Windows 95/ 98/ Me	[Job Type] on the [Setup] tab.
Windows 2000, Windows XP	[Job Type] on the [Job/ Log] tab in the Printing Preferences dialog box.
Windows NT 4. 0	[Job Type] on the [Job/ Log] tab in the Document Defaults dialog box.
Mac OS	[Job Type] on [Job Log] in the print dialog box.
Mac OS X	This function is not available.

You can select the following items:




❖ Normal

Select this for normal printing. The print job starts immediately after the print command is given.

 **Note**

- Under Windows 95/98/Me, if you want to use an User ID, click the **[Detail]** button.

❖ Sample Print

Use this function to print only one set of a multiple print jobs.

The other sets are saved in the machine. The saved job can be printed from the machine's control panel. You can also delete the saved job.

 **Limitation**

- To use this function, the optional Hard Disk Drive must be installed on the printer.

 **Note**

- The "User ID" can consist of up to eight alphanumeric (a- z, A- Z, 0- 9) characters.
- Entering the "User ID" helps you to distinguish the print job from others.

 **Reference**

For more information about how to use Sample Print, see [p.7 "How to Use Sample Print"](#).


❖ Locked Print

Use this function to save documents in the machine memory with a password, and then edit and print them as you want.

 **Limitation**

- To use this function, the optional Hard Disk Drive must be installed on the printer.

 **Note**

- The "User ID" can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters. The "Password" must be four digits.
- 



Reference

For more information about how to use Locked Print, see [p.10 "How to Use Locked Print"](#).

How to Use Sample Print

Follow the procedures to print a document using the "Sample Print" function.



Note

- If the application has a collate option, make sure that it is not selected before sending a print job. By default, sample print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.


Windows 95/98/Me

- 1 From an application, select the menu command to print.**

The print dialog box appears.
- 2 Open the Printer Properties to set Sample Print.**
- 3 Click to select the [Setup] tab.**
- 4 Select [Sample Print] in [Job Type].**
- 5 Click [Details...].**
- 6 Enter the "User ID" in [User ID]. This can consist of up to eight alphanumeric (a- z, A- Z, 0- 9) characters.**



Note

- Select this to identify the user associated with the job.
- 



7 Click [OK].

Windows 2000, Windows XP, Windows NT 4.0

1 From an application, select the menu command to print.

The print dialog box appears.

2 Open the Printer Properties to set Sample Print.

3 Click to select the [Job/ Log] tab.

4 Select [Sample Print] in [Print Job].

5 Enter the "User ID" in [User ID]. This can consist of up to eight alphanumeric (a- z, A- Z, 0- 9) characters.

 **Note**

Select this to identify the user associated with the job.

6 Click [OK] to close the Printer Properties.


7 Start printing from the application's print dialog box.

The Sample Print job is sent to the machine and one set is printed.

8 Check the sample print to confirm that the settings are correct.

If the settings are correct, see "*Printing the Remaining Sets*" in the Client Reference.

If not, you can delete the saved job. See "*Deleting a Sample Print File*" in the Client Reference.



Mac OS

1 From an application, select the menu command to print.

The print dialog box appears.

2 Click to select **[Job Log]** from the pop up menu.

3 Select **[Sample Print]** in **[Job Type]**, and then select the appropriate setting.

4 Enter the "User ID" in **[User ID]**. This can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters.

 **Note**

- This is used to identify the user associated with a job.
- The "User ID" can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters.

5 After making all of the settings you want, click **[Print]**.

The Sample Print job is sent to the machine and one set is printed.

6 Check the sample print to confirm that the settings are correct.

If the settings are correct, see "*Printing the Remaining Sets*" in the Client Reference.

If not, you can delete the saved job. See "*Deleting a Sample Print File*" in the Client Reference.



How to Use Locked Print

Follow the procedures to print a document using the "Locked Print" function.

 **Note**

- If the application has a collate option, make sure that it is not selected before sending a print job. By default, locked print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.

Windows 95/98/Me

1 From an application, select the menu command to print.

The print dialog box appears.

2 Open the Printer Properties to set Locked Print.

3 Click to select the [Setup] tab.

4 Select [Locked Print] in [Job Type].

5 Click [Details...].

6 Enter the "User ID" in [User ID]. This can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters. Then enter a password in [Password], up to four digits.

 **Note**

- Select this to identify the user associated with the job.

7 Click [OK].

Windows 2000, Windows XP, Windows NT 4.0

1 From an application, select the menu command to print.

The print dialog box appears.

2 Open the Printer Properties to set Locked Print.

3 Click to select the [Job/ Log] tab.

4 Select [Locked Print] in [Print Job].

5 Enter the "User ID" in [User ID]. This can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters. Then enter a password in [Password], up to four digits.

 **Note**

- Use this to identify the user associated with the job.

6 Click [OK] to close the Printer Properties.

7 Start printing from the application's print dialog box.

The Locked Print job is sent to the machine.

Mac OS

1 From an application, select the menu command to print.

The print dialog box appears.

2 Click to select **[Job Log]** from the pop up menu.

3 Select **[Locked Print]** in **[Job Type]**, and then select the appropriate setting.

4 Enter the “User ID” in **[User ID]**. This can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters. Then enter a password in **[Password]**, up to four digits.

 **Note**

- This is used to identify the user associated with a job.

Collate

Use this function to enable collation. With this feature, the printer can efficiently print collated sets of multiple-page documents.

! Limitation

- To use this function, a Memory Unit of at least 128MB or Hard Disk Drive must be installed on the printer.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Collate] on the [Setup] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Collate:] on [Printer Specific Options] in the print dialog box.
Mac OS X	The [Collated] check box on [Copies & Pages] in the print dialog box.

Duplex Printing

Use this function to select duplex printing.

❗ Limitation

To use this function, the optional Duplex Unit must be installed on the printer.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Duplex] on the [Setup] tab.
Windows 2000, Windows XP	[Print on Both Sides (Duplex)] on the [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Print on Both Sides (Duplex Printing)] on the [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Print on Both Sides] on [Layout] in the print dialog box.
Mac OS X	The [Print on both Sides] check box on [Duplex] in the print dialog box.

You can select the following items. The following items may vary depending on the operating system you are using.

Windows 95/98/Me

❖ Off

Disables Duplex Printing.

❖ Open to Left

Prints output so that you can open it to the left.


❖ Open to Top

Prints output so that you can open it to the top.

Windows 2000, Windows XP, Mac OS, Mac OS X

 Note

- If you use a Macintosh, click to select the button that means **[Flip on Long Edge]** or **[Flip on Short Edge]**.

❖ None

Disables Duplex Printing.

❖ Flip on Short Edge

Prints output so that you can open it to the short edge when bound along the short edge.

❖ Flip on Long Edge

Prints output so that you can open it to the long edge when bound along the long edge.

Windows NT 4.0

❖ None


Disables Duplex Printing.

❖ Short Side

Prints output so that you can open it to the short edge when bound along the short edge.

❖ Long Side

Prints output so that you can open it to the long edge when bound along the long edge.



Color Mode

Use this to select whether the document is printed in color or black and white.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Color/Black and White] on the [Setup] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Color Mode:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Color Mode] on the [Features 1] tab on [Printer Features] in the print dialog box.

Note

- If you use Windows 95/98/Me, this mode is called "Color/Black and White".

You can select the following items:

Color

Prints color documents in full color.

Note

- Color images will be printed using CMYK toner, Cyan, Magenta, Yellow and Black. CMYK are three primary subtractive colors.
- If you want to adjust the print color, adjust the settings in the Advanced dialog box accessed from the Advanced button on the **[Print Quality]** tab.

❖ Black and White

Prints everything, including color documents, in black and white. Black and White printing is faster than Color printing. To stop black and white areas being printed with CMYK toner, select **[Black and White]** in the printer driver as well as in the application.

Staple

Use this function to have the output stapled. When you turn Staple on, the printed document is collated automatically. You should switch off Collate from the Print window of your application to prevent the entire job from being stapled together.

🔴 Limitation

To use this function, the Finisher must be installed on the printer.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Staple] on the [Setup] tab.
Windows 2000	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences Properties.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab.
Mac OS	[Staple:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Staple] on the [Features 3] tab on [Printer Features] in the print dialog box.

You can select the following items. The following items may vary depending on the operating system you are using.

Windows 95/98/Me

❖ Off

Disables stapling.

❖ Top Left

Staple marks print on the top left side. The staple is placed parallel to the left side.

❖ Top Right

Staple marks print on the top right side. The staple is placed parallel to the right side.

Windows 2000, Windows XP, Windows NT 4.0, Mac OS, Mac OS X

❖ Off

Disables stapling.

❖ Top Left

Staple marks print on the top left side. The staple is placed parallel to the left side.

❖ Top Right


Staple marks print on the top right side. The staple is placed parallel to the right side.

❖ Bottom Left

Staple marks print on the bottom left side. The staple is placed parallel to the left side.

❖ Bottom Right

Staple marks print on the bottom right side. The staple is placed parallel to the right side.



Paper Selection

Paper Sources and Output Tray Tabs

Use this to select the media type, input tray, and output tray.

Limitation

- This function is for Windows 95/98/Me only.

Reference

For more information about the **[Paper Sources and Output Tray]** tabs. See the printer driver's Help.

Paper Size

Use this to select the size of paper you want to use.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Size:] on the [Paper] tab.
Windows 2000, Windows XP	[Paper/Output] on [Advanced...] on the [Paper/Quality] tab in the Printing Preference dialog box.
Windows NT 4.0	[Paper Size:] on the [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Paper:] on the [Page Attributes] tab in the Page Setup dialog box.
Mac OS X	[Paper Size:] in the Page Setup dialog box.

Reference

For more information about the paper sizes supported by this printer, see "*Paper and Other Media Supported by This Printer*" in the Maintenance Guide 2.

Media Type

Use this to select the paper type.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Type:] on [All Pages] on the [Paper] tab.
Windows 2000, Windows XP	[Media:] on the [Paper/Quality] tab in the Printing Preference dialog box.
Windows NT 4.0	[Paper/Output] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Paper Type:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Paper Type] on the [Features 2] tab on [Printer Features] in the print dialog box.

Reference

For more information about the media type supported by this printer, see "*Types of Paper and Other Media*" in the Maintenance Guide 1.

Paper source

Use this to select the paper sources.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[All Pages] on the [Paper] tab.
Windows 2000, Windows XP	The [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	The [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Paper Source:] on [General] in the print dialog box.
Mac OS X	[Paper Feed] in the print dialog box.

Destination Tray

Use this to select the output tray.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Destination] on the [Paper] tab.
Windows 2000	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences Properties.
Windows NT 4.0	[Printer features] on [Document Options] on the [Advanced] tab.
Mac OS	[Destination:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Destination] on the [Features 3] tab on [Printer Features] in the print dialog box.

Resolution

Use this to set the resolution to **[600dpi]**.

Limitation

- The resolution option is only set to **[600dpi]**.

Gradation

Use this to select a type of gradation based on your purpose.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Gradation:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Gradation] on the [Features 1] tab on [Printer Features] in the print dialog box.

You can select the following items:

❖ Standard

Prints with good quality of gradation.

❖ Fast

Prints quickly while gradation loses some smoothness.



Color Profile

Use this to select the color profile pattern.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	The [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Color Profile:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Color Profile] on the [Features 2] tab on [Printer Features] in the print dialog box.

You can select the following items:

Important

- If you use Windows 95/98/Me, you can configure **[Color Profile]** in **[Advanced]** by selecting **[Manual]** from the **[Color]** setting. **[Automatic]** sets the printer to "Presentation".

❖ Photographic

Use this setting to enhance the reproduction of photos and graphics that include midtones.

❖ Presentation

Use this setting to enhance the reproduction of documents that contain text and graphics. This CRD is best for printing colored charts, graphs, presentation materials and so on. If you use this CRD for printing photographs, the color or gradations might not be reproduced well.

❖ Solid Color

Use this setting to print specific colors, logos and so on.

Note

- Use this to select a color rendering dictionary (CRD). The CRD is referred to color matching, so you should select the appropriate CRD for the document you are printing. The selected CRD is also referred to when **[Fine]** or **[Super Fine]** is selected for "Color Setting". The following items are available: **[Auto]**, **[Photographic]**, **[Presentation]** and **[Solid Color]**.

Color Setting

Use this to select the correction method used for color conversion.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Advanced] on the [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Color Setting:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Color Setting] on the [Features 1] tab on [Printer Features] in the print dialog box.

Important

- If you use Windows 95/98/Me, you can configure **[Color Setting]** in **[Advanced]** by selecting **[Manual]** from the **[Color]** setting. **[Automatic]** sets the printer to "Super Fine".

 **Note**

The color rendering dictionary that is selected in the "Color Profile" setting is used.

You can select the following items:

❖ Off

No modification to the color setting.

❖ Fine

Select this setting to perform color matching based on one of the printer's built-in color rendering dictionaries and perform CMYK conversion. This setting performs the printing which output target is Monitor $\gamma = 1.8$.

❖ Super Fine

Select this setting to use a color rendering dictionary as in the "Fine" setting but produce output that is more vivid. Use this setting to emphasize light colors. This setting performs the printing which output target is Monitor $\gamma = 2.2$.

 **Note**

Use this to select a color rendering dictionary (CRD). The CRD is referred to color matching, so you should select the appropriate CRD for the document you are printing. The selected CRD is also referred to when **[Fine]** or **[Super Fine]** is selected for "Color Setting". The following items are available: **[Auto]**, **[Photographic]**, **[Presentation]** and **[Solid Color]**.

Dithering

Use this to set the Image Rendering mode.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Advanced] on the [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Dithering] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Dithering] on the [Features 2] tab on [Printer Features] in the print dialog box.

Important

- If you use Windows 95/98/Me, you can configure **[Dithering]** in **[Advanced]** by selecting **[Manual]** from **[Color]** setting. **[Automatic]** sets the printer to "Photographic".

You can select the following items:

❖ Photographic

Performs dithering using an appropriate pattern for photographs.

❖ Text

Performs dithering using an appropriate pattern for text.

❖ Graphics

Use this setting to perform dithering using a pattern appropriate for graphics such as tables and graphs.

Gray Reproduction

Use this to select the Black Color mode for text and line art.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Advanced] on the [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Black Text/Graphics] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Black Text/Graphics] on the [Features 2] tab on [Printer Features] in the print dialog box.

Important

- If you use Windows 95/98/Me, you can configure **[Gray Reproduction]** in **[Advanced]** by selecting **[Manual]** from the **[Color]** setting. **[Automatic]** sets the printer to "Pure Black Text".

Note

- If you use Windows 2000, Windows XP, Windows NT 4.0, Mac OS or Mac OS X, this function is called "Black Text/Graphics".

You can select the following items:

❖ Pure Black Text

Select this setting to use a black toner.

Note

- If you use Windows 2000, Windows XP, Windows NT 4.0, Mac OS or Mac OS X,, this mode is called "K".

❖ CMY+K

Select this setting to use all toners.

Black Over Print

Select whether or not to apply a black color over any other colors when printing.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Advanced] on the [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Black Over Print:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Black Over Print] on the [Features 2] tab on [Printer Features] in the print dialog box.

Important

- If you use Windows 95/98/Me, you can configure **[Black Over Print]** in **[Advanced]** by selecting **[Manual]** from the **[Color]** setting.

Toner Saver

Use this function to reduce the amount of toner used when printing.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Toner Saver] on the [Print Quality] tab.
Windows 2000, Windows XP	[Printer Features] on [Advanced...] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Toner Saver:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Toner Saver] on the [Features 1] tab on [Printer Features] in the print dialog box.

Color Control

Use this to select whether or not you want the colors in the documents to be adjusted before printing so that the printed page matches closer to the colors on the screen.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	The [Print Quality] tab.
Windows 2000, Windows XP	[Image Color Management] on [Graphic] on [Advanced] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	This function is not available.
Mac OS	[Print Color] on the [Color Matching] tab in the print dialog box.
Mac OS X	This function is not available.

Note

- If you use Windows 2000 or Windows XP, this function is called "Image Color Management".
- If you use Windows NT 4.0, this function can not be configured.
- If you use Mac OS, this function is called "Color Matching".

Image Color Control

Display the Image Color Matching dialog box, click this button to specify exactly how you want the colors on your screen adjusted before printing.

User Code

Use this to set a user code for print logging.

Enter a user code using up to eight digits. A user code identifies a group of users and allows you to check the number of sheets printed under each code with SmartNetMonitor for Admin.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[User Code] on the [Statistics] tab.
Windows 2000, Windows XP	[User Code] on the [Job Log] tab in the Printing Preferences dialog box.
Windows NT 4.0	[User Code] on the [Job Log] tab in the Document Defaults dialog box.
Mac OS	[User Code] on [Job Log] in the print dialog box.
Mac OS X	This function is not available.

Reference

For more information about using SmartNetMonitor for Admin, see Help.

Options

See “Setting Up Options” in the Client Reference or the Administrator Reference for the installation method appropriate to your printing environment.

The following table shows the tabs or menus where you can select this function.

Windows 95/98/Me	[Option] on the [Accessories] tab.
Windows 2000, Windows XP	[Option] on the [Device Setting] tab.
Windows NT 4.0	[Installable Option] on the [Device Setting] tab in the Document Defaults dialog box.
Mac OS	[Chooser] on the Apple Menu.
Mac OS X	This function is not available.

❖ Tray 2

- You can select the tray with the following menu for PAPER FEED UNIT Type 5000:
Paper Source⇒ [p.21](#)

❖ Tray 3

- You can select the other tray with the following menu for an additional PAPER FEED UNIT Type 5000:
Paper Source⇒ [p.21](#)

❖ Duplex Unit

- You can use the following function with Duplex Unit Type 5000:
Duplex Printing⇒ [p.14](#)

❖ Hard Disk

- You can use the following function with Printer Hard Disk Type 5000:
Collate⇒ [p.13](#)
Staple⇒ [p.17](#)



Note

- ❑ The optional Finisher must be installed on the printer.
Job Type⇒ [p.5](#)

❖ Mailbox



Note

- ❑ It is impossible to install the optional Mailbox and Finisher at the same time.
- You can use the following function with Mail Bin Type 5000:
Destination⇒ [p.21](#)

❖ Finisher



Note

- ❑ It is impossible to install the optional Mailbox and Finisher at the same time.
- The following functions are available with SR780:
Destination⇒ [p.21](#)
Staple⇒ [p.17](#)



Note

- ❑ The optional Memory Unit of at least 128MB or the optional Hard Disk Drive must be installed on the printer.

❖ Total Memory

- You can use the following function with Memory Unit Type C (64/ 128/ 256 MB):
Collate⇒ [p.13](#)

Note

- The optional Memory Unit of at least 128MB must be installed on the printer.
- This function is for Windows 95/ 98/ Me only.

2. Printer Utility for Mac

By using Printer Utility for Mac, you can download fonts, change the name of the printer and so on.

Limitation

- If a Macintosh and printer are connected by USB, you cannot use Printer Utility for Mac.

Note

- Printer Utility for Mac is included on the CD-ROM labeled “Printer Drivers and Utilities”.
- Printer Utility for Mac requires Mac OS 8.1 or later. (Mac OS X Classic environment is supported.)
- Printer Utility for Mac cannot use Mac OS X (native environment).

Installing Printer Utility for Mac

Follow these steps to install Printer Utility for Mac on the machine.

1 Start the Macintosh.

2 Insert the CD-ROM into the CD-ROM drive.

The CD-ROM icon appears.

3 Double-click the icon of hard disk to open it.

4 Double-click the CD-ROM icon.

The contents of the CD-ROM appear.

5 Double-click the [Mac OS] folder.

6 Double-click the [PS Utility] folder on the CD-ROM, and then drag the [Printer Utility for Mac] file, and then drop it into the Macintosh hard disk.

7 Drag the CD-ROM icon and drop it into [Trash] to eject the CD-ROM.

Printer Utility for Mac is installed.

Starting Printer Utility for Mac

The following instructions describe how to start Printer Utility for Mac.

Important

- Before starting Printer Utility for Mac, confirm that the printer is selected with **[Chooser]** on the Apple menu.

1 Double-click the **Printer Utility for Mac icon**.

The Printer Utility for Mac dialog box appears.

2 Click **[OK]**.

Printer Utility for Mac will take a few seconds to start.

Reference

For more information, see [“Printer Utility for Mac Functions”](#).

Printer Utility for Mac Functions

Printer Utility for Mac functions are described below.

❖ File menu

- **[Download PS Fonts...]**
Download fonts (PostScript Type 1) to the printer. See [p.37 “Downloading PS Fonts”](#).
- **[Display Printer's Fonts...]**
Display and delete the fonts in printer memory and the printer's hard disk drive. See [p.39 “Displaying Printer's Fonts”](#).
- **[Initialize Printer's Disk...]**
Initialize the printer's hard disk drive. See [p.40 “Initializing the Printer Disk”](#).
- **[Page Setup...]**
Set up the paper size to print “Printer Font Catalog” and “Printer Font Sample”. See [p.41 “Page Setup”](#).
- **[Print Font Catalog...]**
Print the names of available fonts. See [p.41 “Printing Font Catalog”](#).
- **[Print Font Sample...]**
Print a sample of fonts. See [p.41 “Printing Font Sample”](#).
- **[Rename Printer...]**
Change the printer's name when viewed via Appletalk. See [p.42 “Renaming the Printer”](#).
- **[Restart Printer]**
Restart the printer. See [p.43 “Restarting the Printer”](#).

❖ Utility menu

- **[Download PostScript File...]**
Download a PostScript File. See [p.43 “Downloading PostScript Files”](#).
- **[Select Zone...]**
Change the zone to which the printer belongs to via Appletalk. See [p.44 “Selecting the Zone”](#).
- **[Display Printer Status...]**
Display the status of the printer. See [p.45 “Displaying the Printer Status”](#).
- **[Launch Dialogue Console...]**
Create and edit a PostScript file, and then download it to the printer. See [p.45 “Launching the Dialogue Console”](#).

Downloading PS Fonts

You can download the PS fonts to the printer's memory or hard disk drive.

Important

- The following procedures to download the fonts assume that you are a system administrator. If you are not, be sure to consult your system administrator.
- If the printer restarts, all the printer settings return to their defaults.
- Confirm that a Macintosh and the printer are connected with Appletalk.

Note

- Some fonts cannot be downloaded.
- Before downloading, read the documentation about the fonts you want to use.

1 Select **[Download PS Fonts...]** on the **[File]** menu.



2 Click **[Add to list]**.

The dialog box to select fonts appears.

3 Click to select the desired font files, and then click **[Open]**.

The list of selectable font names appears.

4 After adding all the fonts you want to download, click **[OK]**.

The dialog box of selected fonts to download appears.

5 Click **[Download]**.

The fonts begin to download, and the download status is shown.

 **Important**

- During the download, do not turn off the power switch, operate the panel or open or close the cover.

6 When the completion message appears, click **[OK]**.

7 Click **[Cancel]**.



Displaying Printer's Fonts

You can display the available fonts currently downloaded to the printer. Fonts in the printer's memory and hard disk drive can be displayed.

Note

- The fonts displayed in italics are the default fonts.

1 Select **[Display Printer's Fonts...]** on the **[File]** menu.

A dialog box appears.

2 Select **[Printer's memory]** or **[Printer's disk]**.

3 Click **[OK]**.

Deleting Fonts

You can delete fonts from the printer's memory or hard disk drive.

1 Select **[Display Printer's fonts]** on the **[File]** menu.

A dialog box appears.

2 Select **[Printer's memory]** or **[Printer's disk]**.


3 Select the fonts you want to delete.

Limitation

- You cannot delete the fonts displayed in italic.

4 Click **[Delete]**.

A confirmation message appears.



- 5** Confirm the fonts you want to delete and the printer name from which you want to delete the fonts.
- 6** Click **[Continue]**, and then click **[OK]**.
- 7** Click **[OK]**.

Initializing the Printer Disk

When initializing the printer's hard disk, all the fonts downloaded to the printer's hard disk drive are deleted. Before initializing, be sure to check the fonts on the hard disk drive.

Important

- When initializing the printer's hard disk drive from the operation panel, all of the data on the printer's hard disk drive is deleted. Before initializing, be sure to check the data on the hard disk drive.

1 Select **[Initialize Printer's Disk...]** on the **[File]** menu.

The confirmation message appears.

Note

- To cancel initialization, click **[Cancel]**.

2 Click **[Execute]**.

Initializing starts.

Important

- Do not turn off the power switch until initializing is completed, otherwise the hard disk drive might be damaged.

3 When the completion message appears, click **[OK]**.



Page Setup

You can set the paper size on which to print “Print Fonts Catalogue” and “Prints Fonts Sample”.

1 Select **[Page Setup...]** on the **[File]** menu.

2 Choose the paper size.

Printing Font Catalog

Print the names of fonts available on the printer.

 **Note**

The paper selected under **[Page Setup]** is used.

1 Select **[Print Fonts Catalogue]** on the **[File]** menu.

2 Click **[Print]**.

Printing Font Sample

You can print samples of fonts downloaded to the hard disk drive or memory.

 **Note**

Print by using the paper selected on **[Page Setup]**.

1 Select **[Print Fonts Sample...]** on the **[File]** menu.

2 Click **[Print]**.



Renaming the Printer

You can change the printer's name displayed under Appletalk. If you connect several printers on the network, assign different names so you can identify them. If several printers have the same name, a digit appears next to the printer name in **[Chooser]**.

1 Select **[Rename Printer...]** on the **[File]** menu.

2 Type a new name in the **[New Name:]** field.

 **Limitation**

- You can enter up to 31 digits and letters.
- Do not use symbols, for example “*”, “.”, “=”, “@”, “~”.

3 Click **[Rename]**.

The printer name is changed.

4 Press **[OK]**.

5 Select **[Chooser]** on the **Apple** menu.

6 Click the **[AdobePS]** icon.

7 Click to select the printer name renamed in step **2**, and then close **[Chooser]**.

 **Note**

- If there are several Appletalk zones, select the zone to which the printer belongs to.

Restarting the Printer

You can restart the printer.

- 1** Select **[Restart Printer]** on the **[File]** menu.
- 2** Confirm the message that appears on the screen, and then click **[Restart]**.

The printer restarts.

 **Note**

- The fonts that you downloaded in the printer's memory will be deleted.
- If the printer restarts, all the printer settings return to their defaults.

Downloading PostScript Files

You can download a Postscript file to the printer.

- 1** Select **[Download PostScript File...]** on the **[Utility]** menu.
- 2** Select the file name to download and click the file name, and then click **[Open]**.
- 3** Type the log file name, and then click **[Save]**.

The selected file is downloaded.

 **Note**

- Errors are recorded in the log file.

Selecting the Zone

You can change the zone to which the printer belongs to via Appletalk.

Important

- Confirm that the printer and a Macintosh are connected in an Appletalk environment.

1 Select **[Select Zone...]** on the **[Utility]** menu.

The zone to which the printer belongs to and the available zone list appear.

2 Select the zone to which you want to switch the printer, and then click **[Change]**.

A confirmation message appears.

3 Click **[Continue]**.

A confirmation message appears.

4 Press **[OK]**.

5 Select **[Chooser]** on the **Apple** menu.

6 Click the **[AdobePS]** icon.

7 Select the zone selected in step **2** on the **[Appletalk zone:]** list.

8 Click to select the printer you want to use on the **[Select a PostScript Printer:]** list.

9 Close **[Chooser]**.

Displaying the Printer Status

You can display and confirm the current status of the printer.

1 Select **[Display Printer Status...]** on the **[Utility]** menu.

The current status of the printer appears.

2 Confirm the current status of the printer.

You can confirm the memory capacity, the VM (Virtual Memory) space, the hard disk drive status and available space on the hard disk drive. You can also confirm the zone to which the printer belongs to.

3 Click **[OK]**.

Launching the Dialogue Console

You can create and edit a PostScript file for printing, and then download it to the printer.

 **Important**

- “Launch Dialogue Console” is recommended for users with an understanding of PostScript.
- Do not download any file other than PostScript files to the printer.
- “Launch Dialogue Console” must be used at your own responsibility.

1 Select **[Launch Dialogue Console...]** on the **[Utility]** menu.

Open the editing screen. The Dialogue Console menu bar appears.



2 Type the PostScript command in the editor screen.

 **Note**

- To edit a PostScript file, select **[Open]** on the **[File]** menu to open it.
- You can search or replace a character string by using the **[Search]** menu.

3 After editing the PostScript file, select **[Download Top Window]** on **[Console]** menu to start printing.

The PostScript file is sent to the printer.

 **Note**

- The **[Reply from Printer]** box opens, depending on the PostScript file you sent.

4 Select **[Return To Main Menu]** on the **[Console]** menu to close the PostScript file.



B

Black Over Print, 28

C

Collate, 13
Color Control, 29
Color Mode, 16
Color Profile, 23
Color Setting, 24

D

Deleting Fonts, 39
Destination Tray, 21
Displaying Printer's Fonts, 39
Displaying the Printer Status, 45
Dithering, 26
Downloading PostScript Files, 43
Downloading PS Fonts, 37
Duplex Printing, 14

F

Functions
Printer Utility for Mac, 36

G

Gradation, 22
Gray Reproduction, 27

I

Initializing Printer Disk, 40
Installing, 34
Printer Utility for Mac, 34

J

Job Type, 5

L

Launching the Dialogue Console, 45

M

Media Type, 20

O

Options, 31

P

Page Setup, 41
Paper Selection, 19
Paper Size, 19
Paper source, 21
Printer Utility for Mac, 34
Functions, 36
Printing Font Catalog, 41
Printing Font Sample, 41



R

- Renaming the Printer, 42
- Resolution, 22
- Restarting the Printer, 43

S

- Selecting the Zone, 44
- Setting up Options, 5
- Staple, 17

T

- Toner Saver, 29

U

- User Code, 30







EE (GB)
UE (USA) G071-7529A