

Test and Measurement Division

Release Notes

International Keyboards

for R&S Spectrum Analyzer/ Signal Analyzer

	R&S FSV	1307.9002.xx
>	R&S FSL	1300.2502.xx
>	R&S FSP(XP)	1164.4391.xx
>	R&S FSU(XP)	1166.1660.xx
	R&S FSQ(XP)	1155.5001.xx
>	R&S FSG(XP)	1309.0002.xx
	R&S FMU	1303.3500.02

New Features:

Installation of the German, Spanish, French, Italian and Portuguese keyboard support

Release Note Revision: 3

Printed in the Federal Republic of Germany

Contents

History	. 2
General Topics	. 2
Installation of the international keyboard support	. 2
Known Problems	. 4

History

Date	Rel Note Rev	Changes
02.05.2007	1	First revision
21.05.2008	2	Pictures and instrument R&S FSG added.
22.08.2011	3	Instrument R&S FSV added.

General Topics


This update will enhance the embedded XP operating system of the following keyboard layouts:

- > German Keyboards
- Spanish Keyboards
- > French Keyboards
- > Italian Keyboards
- Portuguese Keyboards


Installation of the international keyboard support

For the installation of the German keyboard support, proceed with the following steps:

- 1) Copy the file **FsxInternationalKeyboards.msi** onto USB stick for floppy disk.
- 2) Connect keyboard and mouse to the analyzer.
- 3) Switch the analyzer on and wait until the boot process is finished.
- 4) Terminate the analyzer firmware by pressing <ALT> <F4>.
- 5) Start Windows Explorer
- 6) Start the installation procedure with double click onto the file FsxInternationalKeyboards.msi.
- 7) Reboot the analyzer.
- 8) Now open the windows start menu by pressing the windows key or <CTRL> <ESC>.
- 9) Select Settings Control Panel Reginal and Language Options Languages.




10) Select Details.



11) Select *Add*, choose one of the available input languages and confirm with OK and the dialog will be close.

3 E-2

12) Now change the Default input language as needed and close all open dialogs with OK.



13) Reboot the analyzer.

Known Problems

For FSP/FSU/FSQ: A base system firmware 4.3x (for FSG: V4.39 SP1) or newer is required to support the international keyboard driver. In older versions some of the front panel keys will not work properly.

For FSV: A base system Firmware 1.61Sp2 or newer is required to support the international keyboard driver. In older versions some of the front panel keys will not work properly

4 E-2