

**1** All Measures on screen

TV on screen

Extended Dynamic Margin

Normal Dynamic Margin

ANALYZER

BER

MPEG

Normal Analyzer

ANALYZER

Zoom

**2** SATELLITE

TERRESTRIAL

**2** FM

TER

SAT

**3** COMBO

TV

COMBO

**3** TV

COMBO

**4** ANALOGIC

DIGITAL

**4** A/D Auto

DVBS

DVBS2

BER measure

ANALYZER

**5** MEMORIES

Direct access: MACROS, DATALOGS, GRAPHS and SD

**5** SCAN&LOG

**6** Search next channel

Satellite identification

ANALYZER

**6** Search previous channel 1

**7** Monitor Parameters

**7** Aim Antenna ON/OFF

**8** ILOG

Save Graphs

ANALYZER

**8** DISEqC

**9** Energy Management

Direct access: AUTO Suspend, AUTO Shutdown

**9** Force / Stop battery charge

**0** Channel Mode

Manual Channel Tune

**0** Select Channel Plan

**MHz** Frequency Mode

Manual Frequency Tune

**MHz** Real Frequency

## 2 QUALITY CHECK MARKS CUSTOMIZATION

### R&S®EFL Suite

Manage Quality Profiles

### R&S®EFL Suite

Download Profiles

Upload Profiles

### R&S®EFL240/EFL340

Select the Quality Profile

### R&S®EFL240/EFL340

All measures show the quality indicator

## 3 MEASURES

### SCAN&LOG

Search, analyze and measure channels automatically

### MEMORIES AND MACROS

Save memories and save measures with each macro execution

### INSTANT LOG (ILOG)

Save all measures on screen

### DATALOGS

Visualize all saved measures in R&S®EFL240/EFL340

### Download the measures into the PC with R&S®EFL Suite

### SCAN007

## 4 R&S®EFL Suite

### Manage Measures

### Manage Graphs

### Manage Quality Profiles

- Channel Plan Editor
- R&S®EFL240/EFL340 Backups
- Show Updates
- Export data