



- TIS 88
- BF 167
- BC 107B
- BC 108B
- BC 109
- BC 177A
- RCA 40349
- MM 4000
- B 170007
- BD 106A

- 12 ○ NOT USED
- 11 ○ EXTERNAL LOUDSPEAKER
- 10 ○
- 9 ○
- 8 ○ LF TO TRANSMITTER
- 7 ○ NOT USED
- 6 ○ LOUDSPEAKER ON/OFF
- 5 ○ BLOCKING BIAS
- 4 ○ COMMON RELAYS
- 3 ○ NOT USED
- 2 ○ POWER SUPPLY
- 1 ○

Dette skema omfatter SAILOR 56 T, serie A
 Dieses Schaltschema betrifft SAILOR 56 T, Serie A
 This diagram refers to SAILOR 56 T, series A
 Ce schéma s'étend au SAILOR 56 T, série A
 Este diagrama comprende SAILOR 56 T, serie A