

## 6. Exploded View and its Parts List

---


**6-1 Fixed Phone Exploded View**

**6-2 Fixed Phone Parts List**

**6-3 Rapid Charger Exploded View**

**6-4 Cradle Dummy Ass'y & Cigar Lighter Adapter**


## 6-1 Fixed Phone Exploded View



**6-2 Fixed Phone Parts List**


NO	DESCRIPTION	SEC. CODE				REMARK
		Black	Blue	Red	Dark Gray	
1	Front Window	GH72-41404A				
2	Front Cover Ass'y	GH75-11129A	GH75-11129B	GH75-11129C	GH75-11129D	
3	Earphone Dummy	GH73-40624A				
4	Volume Key	GH72-40626A				
5	Key Pad	GH72-41317B				
6	Antenna	GH42-10511A				
7	Motor Ass'y	GH96-01029A				
8	Rear Case	GH75-11130A				
9	Screw	6001-001046				
10	Key Pad Ass'y	GH59-10020A				
11	Shield Can	GH72-41445A				
12	Main PBA	GH72-41406A				
13	Battery	GH94-00791A			GH43-10307A GH43-10062A	Medium Extended-life

### 6-3 Rapid Charger Exploded View



SEC.CODE : GH96-01053A

## 6-4 Cradle Dummy Ass'y & Cigar Lighter Adapter



SEC.CODE : GH75-11215A

# MEMO