


# 1. Exploded View and Parts List

## 1-1 Main Exploded View



## 1-2 Main Exploded View Parts List

No.	Description	SEC Code			Remark
		Dark Gray	Deep Blue	Stone Gray	
1	WINDOW	GH72-41659A	GH72-41659C	GH72-41659B	
		GH72-41659D	GH72-41659F	GH72-41659Z	CHINA
2	REFLECTOR-LED	GH72-41653A	GH72-41653A	GH72-41653A	
3	FRONT COVER	GH75-11254A	GH75-11254B	GH75-11254C	
4	VIBRATOR	GH59-10069A	GH59-10069A	GH59-10069A	
5	FLIP DUMMY-L/R	GH72-41455G/H	GH72-41455J/K	GH72-41455E/F	
6	SPONGE BUMPER	GH74-10717A	GH74-10717A	GH74-10717A	
7	SCREW-MACHINE(M1.4/L3.5)	6001-001155	6001-001155	6001-001155	
8	FLIP DUMMY(RUBBER)	GH73-40658A	GH73-40658E	GH73-40658F	
9	ANTENNA BRACKET	GH71-10713A	GH71-10713A	GH71-10713A	
10	MAIN B'D	GH94-00809A	GH94-00809A	GH94-00809A	
		GH92-00737A	GH92-00737A	GH92-00737A	CHINA
11	SHIELD-MAIN	GH72-41657A	GH72-41657A	GH72-41657A	
12	MEMORY B'D	GH94-00854A	GH94-00854A	GH94-00854A	
		GH92-00738A	GH92-00738A	GH92-00738A	CHINA
13	SHIELD-LOGIC	GH72-41658A	GH72-41658A	GH72-41658A	
14	ANTENNA	GH42-00001A	GH42-00001A	GH42-00001A	
		GH42-00011A	GH42-00011A	GH42-00011A	CHINA
15	REAR COVER	GH72-41662A	GH72-41662A	GH72-41662A	
16	SCREW-MACHINE(L2/L3.5)	6001-001149	6001-001149	6001-001149	
17	BATTERY LOCKER	GH72-41663A	GH72-41663A	GH72-41663A	
18	CARD HOLDER	GH72-41664A	GH72-41664A	GH72-41664A	
19	FLIP BRACKET-L/R	GH75-11146A/B	GH75-11146A/B	GH75-11146A/B	
20	KEYPAD	GH72-41661A	GH72-41661A	GH72-41661A	
21	MIC HOLDER	GH72-41656A	GH72-41656A	GH72-41656A	
22	BUZZER HOLDER	GH73-40694A	GH73-40694A	GH73-40694A	
23	SCREW-TAPTIGHT(M1.4x4)	6003-001049	6003-001049	6003-001049	
24	SCREW-MACHINE(M2/L5)	6001-001148	6001-001148	6001-001148	
25	BATTERY	GH43-10091A	GH43-10089A	GH43-10101A	Slim(600 mA)
		GH43-10093A	GH43-10090A	GH43-10097A	Middle(900 mA)
		GH43-10328A	GH43-10327A	GH43-10329A	Long(1600 mA)
26	FLIP WINDOW	GH72-41660A	GH72-41660C	GH72-41660B	
		GH72-41660D	GH72-41660F	GH72-41660E	CHINA
27	FLIP UPPER	GH72-41654A	GH72-41654B	GH72-41654C	
28	FLIP LOWER	GH72-41655A	GH72-41655B	GH72-41655C	
29	FLIP LABEL	GH68-31050D	GH68-31050E	GH68-31050F	
30	SPEAKER	3009-001024	3009-001024	3009-001024	
31	FLIP ASS'Y	GH97-00838A	GH97-00838B	GH97-00838C	