


LASER PRINTER

ML-1650 / ML-1651N

SERVICE Manual

LASER PRINTER



CONTENTS

- 1. Precautions
- 2. Specifications
- 3. Disassembly and Reassembly
- 4. Troubleshooting
- 5. Exploded Views and Parts List
- 6. Block Diagram
- 7. Connection Diagram



This service manual is also provided on the web, the ITSELF system f Samsung Electronics Co., Ltd. "http://itself.sec.samsung.co.kr"

© Samsung Electronics Co.,Ltd. July 2002 Printed in Korea.

VERSION NO.: 2.04 CODE: JC-0055A

 This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable international and/or domestic law.

This manual is stated and provided for service description.

All rights reserved. Any parts of the information in this manual are prohibited from free duplication, use or translation without prior written approval except in cases allowed by the Copyright Act. Specifications are subject to change without prior notice.

Samsung Electronics Digital Printing CS Group Copyright (c) 2002. 4.