




CP-1 BOARD (PW-A) POWER SUPPLY




PW-1 BOARD POWER SUPPLY




CP-1 BOARD (VD-A) VIDEO (VHR-266SP & VHR-276SP)




CP-1 BOARD (VD-A) VIDEO (VHR-246IR)




CP-1 BOARD (VD-A) VIDEO (VHR-276IR & VHR-286IR)




VP-1 BOARD VIDEO PRE-AMP




TM-9 BOARD PDC/VPS (VHR-286IR)




TM-7 BOARD PDC (OPTION FOR VHR-276IR)




TM-8 BOARD VPS (OPTION FOR VHR-286SP & VHR-276SP)



CP-1 BOARD (SY-A) SYSTEM CONTROL




AD-A
A1-15570/PP2-SP3




CP-1 BOARD (AD-A) AUDIO (VHR-2461R, VHR-2761R & VHR-2861R)

AD-A
A1-15560-992-64




CP-1 BOARD (SV-A) SERVO



TM-1 BOARD OPERATION KEY & DISPLAY

TM-1

T1-15504/PP2L-E




DIODE : 1SS133 or GMA01

SW : 1AV4S10B1470J or
1AV4S10B0840J or
4231V69100 or
1AC4S11A00300 or
1AV4S10B01100

IR711 : 1AV4U20B07000
OR
1AC4U20A01300 or
1AV4U20B07500

RR711	
PARTS No.	INDICATE OF THE CIRCUIT DIAGRAM
613 129 0938	1AC4U20A01300
645 008 7875	1AV4U20B07500
645 006 8720	1AV4U20B07000


TB-1 BOARD TERMINAL & INPUT/OUTPUT SELECTION (VHR-266SP & VHR-276SP)



TB-1
V3-19521/PP2-5P

VOLTAGE - REC(PB) MODE
*REC MODE... (M) MODE-SCRAMBLE SIG.

CP-1 BOARD (TN-A) TUNER IF CONNECTION (EXCEPT VHR-276SP)



CP-1 BOARD (TN-A) TUNER IF CONNECTION (VHR-276SP)

(3 in 1 TUNER)

