

**Product Manual** 

# NL35 Series® 7200.2 Serial ATA

ST3500841NS ST3500641NS

Copyright © 2006-2007 Seagate Technology LLC. All rights reserved. Printed in USA

Publication number: 100390104, Rev. C

August 2007

Seagate, Seagate Technology and the Wave logo are registered trademarks of Seagate Technology LLC in the United States and/or other countries. NL35 Series, SeaTools and SeaTDD are either trademarks or registered trademarks of Seagate Technology LLC or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners.

One gigabyte, or GB, equals one billion bytes when referring to hard drive capacity. Accessible capacity may vary depending on operating environment and formatting. Seagate reserves the right to change, without notice, product offerings or specifications.

# **Contents**

1.0	Introd	luction	1				
	1.1	About the Serial ATA interface	2				
2.0	Drive	Drive specifications					
	2.1	Formatted capacity*					
		2.1.1 LBA mode					
	2.2	Default logical geometry	3				
	2.3	Recording and interface technology					
	2.4	Physical characteristics					
	2.5	Seek time	4				
	2.6	Start/stop times					
	2.7	Power specifications	5				
		2.7.1 Power consumption	5				
		2.7.2 Conducted noise	6				
		2.7.3 Voltage tolerance	6				
		2.7.4 Power-management modes	7				
	2.8	Environmental specifications	8				
		2.8.1 Ambient temperature	8				
		2.8.2 Temperature gradient					
		2.8.3 Humidity					
		2.8.4 Altitude					
		2.8.5 Shock					
		2.8.6 Vibration					
	2.9	Acoustics					
	2.10	Electromagnetic immunity					
	2.11	Reliability					
	2.12	Agency certification					
		2.12.1 Safety certification					
		2.12.2 Electromagnetic compatibility					
		2.12.3 FCC verification					
	2.13	Environmental protection					
		2.13.1 European Union Restriction of Hazardous Substances (RoHS)					
	2.14	Corrosive environment					
3.0	Confi	guring and mounting the drive					
	3.1	Handling and static-discharge precautions	. 15				
	3.2	Configuring the drive					
	3.3	Serial ATA cables and connectors	. 16				
	3.4	Drive mounting	. 17				
4.0	Serial	ATA (SATA) interface	. 19				
	4.1	Hot-Plug compatibility					
	4.2	Serial ATA device plug connector pin definitions.					
	4.3	Supported ATA commands					
	٦.٥	4.3.1 Identify Device command					
		4.3.2 Set Features command					
		4.3.3 S.M.A.R.T. commands					
<b>-</b> -	•						
5.0	Seaga	ate Technology support services	. 29				

# **List of Figures**

Figure 1.	Typical 12V startup and operation current profile	6
Figure 2.	Jumper options	16
Figure 3.	Attaching SATA cabling	16
Figure 4.	Mounting dimensions—top, side and end view	17

## 1.0 Introduction

This manual describes the functional, mechanical and interface specifications for the following Seagate NL35 Series 7200.2 Serial ATA model drives:

### NL35 Series 7200.2 Serial ATA

- ST3500841NS
- ST3500641NS

These drives provide the following key features:

- 7,200 RPM spindle speed.
- 8 Mbyte buffer on ST3500841NS drives
   16 Mbyte buffer on ST3500641NS drives
- · High instantaneous (burst) data-transfer rates.
- Tunneling Magnetoresistive (TMR) recording heads.
- State-of-the-art cache and on-the-fly error-correction algorithms.
- Native Command Queueing with command ordering to increase performance in demanding applications.
- Full-track multiple-sector transfer capability without local processor intervention.
- · Quiet operation.
- 350 Gs nonoperating shock.
- SeaTools diagnostic software performs a drive self-test that eliminates unnecessary drive returns.
- Support for S.M.A.R.T. drive monitoring and reporting.
- · Supports latching SATA cables and connectors.
- Supports hotplug operation per SATA II specification.
- Supports S.M.A.R.T. Command Transport (SCT) to provide enterprise-like features in an industry-accepted transport mechanism. See Section 4.3.3.1 for additional information about SCT.
- Supports the Write Same command to allow large writes without host interface overhead.
- Supports Error Recovery Control to allow the host to put a soft time limit on read and write commands.
- One-Step Microcode Download which allows enterprise clients to download new drive code with a single download command using the host download utility.
- Workload management features to manage drive temperature and activity. This optimizes drive reliability in nearline environments with no user intervention required.

#### 1.1 About the Serial ATA interface

The Serial ATA interface provides several advantages over the traditional (parallel) ATA interface. The primary advantages include:

- Easy installation and configuration with true plug-and-play connectivity. It is not necessary to set any jumpers or other configuration options.
- Thinner and more flexible cabling for improved enclosure airflow and ease of installation.
- Scalability to higher performance levels.

In addition, Serial ATA makes the transition from parallel ATA easy by providing legacy software support. Serial ATA was designed to allow you to install a Serial ATA host adapter and Serial ATA disc drive in your current system and expect all of your existing applications to work as normal.

The Serial ATA interface connects each disc drive in a point-to-point configuration with the Serial ATA host adapter. There is no master/slave relationship with Serial ATA devices like there is with parallel ATA. If two drives are attached on one Serial ATA host adapter, the host operating system views the two devices as if they were both "masters" on two separate ports. This essentially means both drives behave as if they are Device 0 (master) devices.

**Note.** The host adapter may, optionally, emulate a master/slave environment to host software where two devices on separate Serial ATA ports are represented to host software as a Device 0 (master) and Device 1 (slave) accessed at the same set of host bus addresses. A host adapter that emulates a master/slave environment manages two sets of shadow registers. This is not a typical Serial ATA environment.

The Serial ATA host adapter and drive share the function of emulating parallel ATA device behavior to provide backward compatibility with existing host systems and software. The Command and Control Block registers, PIO and DMA data transfers, resets, and interrupts are all emulated.

The Serial ATA host adapter contains a set of registers that shadow the contents of the traditional device registers, referred to as the Shadow Register Block. All Serial ATA devices behave like Device 0 devices. For additional information about how Serial ATA emulates parallel ATA, refer to the "Serial ATA: High Speed Serialized AT Attachment" specification. The specification can be downloaded from www.serialata.org.

# 2.0 Drive specifications

Unless otherwise noted, all specifications are measured under ambient conditions, at 25°C, and nominal power. For convenience, the phrases *the drive* and *this drive* are used throughout this manual to indicate ST3500841NS and ST3500641NS models.

#### 2.1 Formatted capacity\*

Model	Formatted capacity	Guaranteed sectors	Bytes per sector
ST3500641NS and ST3500841NS	500 Gbytes	976,773,168	512

<sup>\*</sup>One Gbyte equals one billion bytes when referring to hard drive capacity. Accessible capacity may vary depending on operating environment and formatting.

#### 2.1.1 LBA mode

When addressing these drives in LBA mode, all blocks (sectors) are consecutively numbered from 0 to n–1, where n is the number of guaranteed sectors as defined above.

See Section 4.3.1, "Identify Device command" (words 60-61 and 100-103) for additional information about 48-bit addressing support of drives with capacities over 137 Gbytes.

#### 2.2 Default logical geometry

Cylinders	Read/write heads	Sectors per track
16,383	16	63

#### LBA mode

When addressing these drives in LBA mode, all blocks (sectors) are consecutively numbered from 0 to n–1, where n is the number of guaranteed sectors as defined above.

# 2.3 Recording and interface technology

Interface	Serial ATA (SATA)
Recording method	16/17 EPRML
Recording density BPI (bits/inch max)	790.7k
Track density TPI (tracks/inch avg)	134.4k
Areal density (Gbits/inch <sup>2</sup> avg)	106.35
Spindle speed (RPM) (± 0.2%)	7,200
Internal data transfer rate (Mbits/sec max)	754
Sustained transfer rate (Mbytes/sec)	65
I/O data-transfer rate (Mbytes/sec max)	300
Interleave	1:1
Cache buffer	8 Mbytes (8,192 kbytes) on ST3500841NS drives 16 Mbytes (16,384 kbytes) on ST3500641NS drives.

# 2.4 Physical characteristics

Maximum height (mm) (inches)	26.11 1.028
Maximum width (mm) (inches)	101.85 4.010
Maximum length (mm) (inches)	146.99 5.787
Maximum weight (grams) (pounds)	710 1.57

# 2.5 Seek time

Seek measurements are taken with nominal power at 25°C ambient temperature. All times are measured using drive diagnostics. The specifications in the table below are defined as follows:

- Track-to-track seek time is an average of all possible single-track seeks in both directions.
- Average seek time is a true statistical random average of at least 5,000 measurements of seeks between random tracks, less overhead.

Typical seek times (msec)	Read	Write
Track-to-track	0.8	1.0
Average	8.0	9.0
Average latency:	4.16	4.16

**Note.** These drives are designed to consistently meet the seek times represented in this manual. Physical seeks, regardless of mode (such as track-to-track and average), are expected to meet the noted values. However, due to the manner in which these drives are formatted, benchmark tests that include command overhead or measure logical seeks may produce results that vary from these specifications.

#### 2.6 Start/stop times

Power-on to Ready (sec)	10 (max)
Standby to Ready (sec)	10 (max)
Ready to spindle stop (sec)	12 (max)

## 2.7 Power specifications

The drive receives DC power (+5V or +12V) through a native SATA power connector. See Figure 3 on page 16.

#### 2.7.1 Power consumption

Power requirements for the drives are listed in the table on page 9. Typical power measurements are based on an average of drives tested, under nominal conditions, using 5.0V and 12.0V input voltage at 25°C ambient temperature.

#### Spinup power

Spinup power is measured from power-on to the time that the drive spindle reaches operating speed.

#### Seek mode

During seek mode, the read/write actuator arm moves toward a specific position on the disc surface and does not execute a read or write operation. Servo electronics are active. Seek mode power represents the worst-case power consumption, using only random seeks with read or write latency time. This mode is not typical and is provided for worst-case information.

#### Read/write power and current

Read/write power is measured with the heads on track, based on a 16-sector write followed by a 32-msec delay, then a 16-sector read followed by a 32-msec delay.

#### Operating power and current

Operating power is measured using 40 percent random seeks, 40 percent read/write mode (1 write for each 10 reads) and 20 percent drive idle mode.

#### · Idle mode power

Idle mode power is measured with the drive up to speed, with servo electronics active and with the heads in a random track location.

# · Standby mode

During Standby mode, the drive accepts commands, but the drive is not spinning, and the servo and read/write electronics are in power-down mode.

Table 1: DC power requirements

Power dissipation	Average (25° C)
Spinup	2.9 Amps
Idle*	10.40 watts
Operating (40% r/w, 40% seek, 20% inop.)	13.00 watts
Seeking (random, 20% idle)	12.60 watts
Standby	0.80 watts
Sleep	0.80 watts

<sup>\*</sup>During periods of drive idle, some offline activity may occur according to the S.M.A.R.T. specification, which may increase acoustic and power to operational levels.

# 2.7.1.1 Typical current profile




Figure 1. Typical 12V startup and operation current profile

# 2.7.2 Conducted noise

Input noise ripple is measured at the host system power supply across an equivalent 80-ohm resistive load on the +12 volt line or an equivalent 15-ohm resistive load on the +5 volt line.

- Using 12-volt power, the drive is expected to operate with a maximum of 120 mV peak-to-peak square-wave injected noise at up to 10 MHz.
- Using 5-volt power, the drive is expected to operate with a maximum of 100 mV peak-to-peak square-wave injected noise at up to 10 MHz.

**Note.** Equivalent resistance is calculated by dividing the nominal voltage by the typical RMS read/write current.

## 2.7.3 Voltage tolerance

Voltage tolerance (including noise):

5V ± 5% 12V ± 10%

## 2.7.4 Power-management modes

The drive provides programmable power management to provide greater energy efficiency. In most systems, you can control power management through the system setup program. The drive features the following power-management modes:

Power modes	Heads	Spindle	Buffer
Active	Tracking	Rotating	Enabled
Idle	Tracking	Rotating	Enabled
Standby	Parked	Stopped	Enabled
Sleep	Parked	Stopped	Disabled

#### Active mode

The drive is in Active mode during the read/write and seek operations.

#### Idle mode

The buffer remains enabled, and the drive accepts all commands and returns to Active mode any time disc access is necessary.

#### · Standby mode

The drive enters Standby mode when the host sends a Standby Immediate command. If the host has set the standby timer, the drive can also enter Standby mode automatically after the drive has been inactive for a specifiable length of time. The standby timer delay is established using a Standby or Idle command. In Standby mode, the drive buffer is enabled, the heads are parked and the spindle is at rest. The drive accepts all commands and returns to Active mode any time disc access is necessary.

#### Sleep mode

The drive enters Sleep mode after receiving a Sleep command from the host. In Sleep mode, the drive buffer is disabled, the heads are parked and the spindle is at rest. The drive leaves Sleep mode after it receives a Hard Reset or Soft Reset from the host. After receiving a reset, the drive exits Sleep mode and enters Standby mode with all current translation parameters intact.

#### Idle and Standby timers

Each time the drive performs an Active function (read, write or seek), the standby timer is reinitialized and begins counting down from its specified delay times to zero. If the standby timer reaches zero before any drive activity is required, the drive makes a transition to Standby mode. In both Idle and Standby mode, the drive accepts all commands and returns to Active mode when disc access is necessary.

# 2.8 Environmental specifications

#### 2.8.1 Ambient temperature

Ambient temperature is defined as the temperature of the environment immediately surrounding the drive. Actual drive case temperature should not exceed 69°C (156°F) within the operating ambient conditions.

Above 1,000 feet (305 meters), the maximum temperature is derated linearly to 112°F (44°C) at 10,000 feet (3,048 meters).

Operating:	0° to 60°C (32° to 140°F)
Nonoperating:	-40° to 70°C (-40° to 158°F)

# 2.8.2 Temperature gradient

Operating:	20°C per hour (68°F per hour max), without condensation
Nonoperating:	30°C per hour (86°F per hour max)

#### 2.8.3 Humidity

### 2.8.3.1 Relative humidity

Operating:	5% to 90% noncondensing (30% per hour max)
Nonoperating:	5% to 95% noncondensing (30% per hour max)

#### 2.8.3.2 Wet bulb temperature

Operating:	37.7°C (99.9°F max)
Nonoperating:	40°C (104°F max)

#### 2.8.4 Altitude

Operating:	-60.96 m to 3,048 m (-200 ft. to 10,000+ ft.)
Nonoperating:	-60.96 m to 12,192 m (-200 ft. to 40,000+ ft.)

#### 2.8.5 Shock

All shock specifications assume that the drive is mounted securely with the input shock applied at the drive mounting screws. Shock may be applied in the X, Y or Z axis.

# 2.8.5.1 Operating shock

These drives comply with the performance levels specified in this document when subjected to a maximum operating shock of 63 Gs based on half-sine shock pulses of 2 msec. Shocks should not be repeated more than two times per second.

#### 2.8.5.2 Nonoperating shock

The nonoperating shock level that the drive can experience without incurring physical damage or degradation in performance when subsequently put into operation is 350 Gs based on a nonrepetitive half-sine shock pulse of 2 msec duration.

#### 2.8.6 Vibration

All vibration specifications assume that the drive is mounted securely with the input vibration applied at the drive mounting screws. Vibration may be applied in the X, Y or Z axis.

## 2.8.6.1 Operating vibration

The maximum vibration levels that the drive may experience while meeting the performance standards specified in this document are specified below.

5–22 Hz	0.25 Gs (Limited displacement)	
23–350 Hz	0.50 Gs	
351–500 Hz	0.25 Gs	

# 2.8.6.2 Nonoperating vibration

The maximum nonoperating vibration levels that the drive may experience without incurring physical damage or degradation in performance when subsequently put into operation are specified below.

5–22 Hz	0.25 Gs (Limited displacement)	
23–350 Hz	5.0 Gs	
351–500 Hz	1.0 Gs	

#### 2.9 Acoustics

Drive acoustics are measured as overall A-weighted acoustic sound power levels (no pure tones). All measurements are consistent with ISO document 7779. Sound power measurements are taken under essentially free-field conditions over a reflecting plane. For all tests, the drive is oriented with the cover facing upward.

**Note.** For seek mode tests, the drive is placed in seek mode only. The number of seeks per second is defined by the following equation:

(Number of seeks per second = 0.4 / (average latency + average access time)

Table 2: Fluid Dynamic Bearing (FDB) motor acoustics

Idle*	Quiet seek
2.8 bels (typ)	2.9 bels (typ)
2.86 bels (max)	2.93 bels (max)

<sup>\*</sup>During periods of drive idle, some offline activity may occur according to the S.M.A.R.T. specification, which may increase acoustic and power to operational levels.

# 2.10 Electromagnetic immunity

When properly installed in a representative host system, the drive operates without errors or degradation in performance when subjected to the radio frequency (RF) environments defined in the following table:

Table 3: Radio frequency environments

Test	Description	Performance level	Reference standard	
Electrostatic discharge	Contact, HCP, VCP: ± 4 kV; Air: ± 8 kV	В	EN 61000-4-2: 95	
Radiated RF immunity	80 to 1,000 MHz, 3 V/m, 80% AM with 1 kHz sine 900 MHz, 3 V/m, 50% pulse modulation @ 200 Hz		EN 61000-4-3: 96 ENV 50204: 95	
Electrical fast transient	± 1 kV on AC mains, ± 0.5 kV on external I/O	В	EN 61000-4-4: 95	
Surge immunity	mmunity ± 1 kV differential, ± 2 kV common, AC mains		EN 61000-4-5: 95	
Conducted RF immunity 150 kHz to 80 MHz, 3 Vrms, 80% AM with 1 kHz sine		А	EN 61000-4-6: 97	
Voltage dips, interrupts	0% open, 5 seconds 0% short, 5 seconds 40%, 0.10 seconds 70%, 0.01 seconds	СССВ	EN 61000-4-11: 94	

# 2.11 Reliability

Nonrecoverable read errors	1 per 10 <sup>14</sup> bits read, max	
Annualized Failure Rate (AFR)	0.34% (nominal power, 25°C ambient temperature)	
Contact start-stop cycles	50,000 cycles (at nominal voltage and temperature, with 60 cycles per hour and a 50% duty cycle)	
Warranty	5 years on distribution units.  To determine the warranty for a specific drive, use a web browser to access the following web page:  www.seagate.com/support/service/  From this page, click on the "Verify Your Warranty" link. You will be asked to provide the drive serial number, model number (or part number) and country of purchase. The system will display the warranty information for your drive.	
Preventive maintenance	None required.	

# 2.12 Agency certification

## 2.12.1 Safety certification

The drives are recognized in accordance with UL 1950 and CSA C22.2 (950) and meet all applicable sections of IEC950 and EN 60950 as tested by TUV North America.

#### 2.12.2 Electromagnetic compatibility

Hard drives that display the CE mark comply with the European Union (EU) requirements specified in the Electromagnetic Compatibility Directive (89/336/EEC). Testing is performed to the levels specified by the product standards for Information Technology Equipment (ITE). Emission levels are defined by EN 55022, Class B and the immunity levels are defined by EN 55024.

Seagate uses an independent laboratory to confirm compliance with the EC directives specified in the previous paragraph. Drives are tested in representative end-user systems. Although CE-marked Seagate drives comply with the directives when used in the test systems, we cannot guarantee that all systems will comply with the directives. The drive is designed for operation inside a properly designed enclosure, with properly shielded I/O cable (if necessary) and terminators on all unused I/O ports. Computer manufacturers and system integrators should confirm EMC compliance and provide CE marking for their products.

#### Korean RRL

If these drives have the Korea Ministry of Information and Communication (MIC) logo, they comply with paragraph 1 of Article 11 of the Electromagnetic Compatibility control Regulation and meet the Electromagnetic Compatibility (EMC) Framework requirements of the Radio Research Laboratory (RRL) Ministry of Information and Communication Republic of Korea.

These drives have been tested and comply with the Electromagnetic Interference/Electromagnetic Susceptibility (EMI/EMS) for Class B products. Drives are tested in a representative, end-user system by a Korean-recognized lab.

EUT name (model numbers): ST3500641NS and ST3500841NS

• Certificate numbers: ST3500641NS E-H011-05-3453 (B)

ST3500841NS E-H011-05-3453 (B)

· Trade name or applicant: Seagate Technology

Manufacturing date: October 2005

Manufacturer/nationality: Singapore and China

#### Australian C-Tick (N176)

If these models have the C-Tick marking, they comply with the Australia/New Zealand Standard AS/NZS3548 1995 and meet the Electromagnetic Compatibility (EMC) Framework requirements of the Australian Communication Authority (ACA).

#### 2.12.3 FCC verification

These drives are intended to be contained solely within a personal computer or similar enclosure (not attached as an external device). As such, each drive is considered to be a subassembly even when it is individually marketed to the customer. As a subassembly, no Federal Communications Commission verification or certification of the device is required.

Seagate Technology LLC has tested this device in enclosures as described above to ensure that the total assembly (enclosure, disc drive, motherboard, power supply, etc.) does comply with the limits for a Class B computing device, pursuant to Subpart J, Part 15 of the FCC rules. Operation with noncertified assemblies is likely to result in interference to radio and television reception.

**Radio and television interference.** This equipment generates and uses radio frequency energy and if not installed and used in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception.

This equipment is designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television, which can be determined by turning the equipment on and off, you are encouraged to try one or more of the following corrective measures:

- · Reorient the receiving antenna.
- Move the device to one side or the other of the radio or TV.
- · Move the device farther away from the radio or TV.
- Plug the computer into a different outlet so that the receiver and computer are on different branch outlets.

If necessary, you should consult your dealer or an experienced radio/television technician for additional suggestions. You may find helpful the following booklet prepared by the Federal Communications Commission: *How to Identify and Resolve Radio-Television Interference Problems*. This booklet is available from the Superintendent of Documents, U.S. Government Printing Office, Washington, DC 20402. Refer to publication number 004-000-00345-4.

#### 2.13 Environmental protection

Seagate designs its products to meet environmental protection requirements worldwide, including regulations restricting certain chemical substances.

#### 2.13.1 European Union Restriction of Hazardous Substances (RoHS)

# **Compliance statement**

The European Union Restriction of Hazardous Substances (RoHS) Directive restricts the presence of chemical substances, including Lead (Pb), in electronic products effective July 2006.

A number of parts and materials in Seagate products are procured from external suppliers. We rely on the representations of our suppliers regarding the presence of RoHS substances in these parts and materials. Our supplier contracts require compliance with our chemical substance restrictions, and our suppliers document their compliance with our requirements by providing material content declarations for all parts and materials for the disc drives documented in this publication. Current supplier declarations include disclosure of the inclusion of any RoHS-regulated substance in such parts or materials.

Seagate also has internal systems in place to ensure ongoing compliance with the RoHS Directive and all laws and regulations which restrict chemical content in electronic products. These systems include standard operating procedures that ensure that restricted substances are not utilized in our manufacturing operations, laboratory analytical validation testing, and an internal auditing process to ensure that all standard operating procedures are complied with.

#### 2.14 Corrosive environment

Seagate electronic drive components pass accelerated corrosion testing equivalent to 10 years exposure to light industrial environments containing sulfurous gases, chlorine and nitric oxide, classes G and H per ASTM B845. However, this accelerated testing cannot duplicate every potential application environment. Users should use caution exposing any electronic components to uncontrolled chemical pollutants and corrosive chemicals as electronic drive component reliability can be affected by the installation environment. The silver, copper, nickel and gold films used in Seagate products are especially sensitive to the presence of sulfide, chloride, and nitrate contaminants. Sulfur is found to be the most damaging. In addition, electronic components should never be exposed to condensing water on the surface of the printed circuit board assembly (PCBA) or exposed to an ambient relative humidity greater than 95%. Materials used in cabinet fabrication, such as vulcanized rubber, that can outgas corrosive compounds should be minimized or eliminated. The useful life of any electronic equipment may be extended by replacing materials near circuitry with sulfide-free alternatives.

# 3.0 Configuring and mounting the drive

This section contains the specifications and instructions for configuring and mounting the drive.

## 3.1 Handling and static-discharge precautions

After unpacking, and before installation, the drive may be exposed to potential handling and electrostatic discharge (ESD) hazards. Observe the following standard handling and static-discharge precautions:

#### Caution:


- Before handling the drive, put on a grounded wrist strap, or ground yourself frequently by touching the metal chassis of a computer that is plugged into a grounded outlet. Wear a grounded wrist strap throughout the entire installation procedure.
- Handle the drive by its edges or frame only.
- The drive is extremely fragile—handle it with care. Do not press down on the drive top cover.
- Always rest the drive on a padded, antistatic surface until you mount it in the computer.
- Do not touch the connector pins or the printed circuit board.
- Do not remove the factory-installed labels from the drive or cover them with additional labels. Removal voids the warranty. Some factory-installed labels contain information needed to service the drive. Other labels are used to seal out dirt and contamination.

# 3.2 Configuring the drive

Each drive on the Serial ATA interface connects in a point-to-point configuration with the Serial ATA host adapter. There is no master/slave relationship because each drive is considered a master in a point-to-point relationships. If two drives are attached on one Serial ATA host adapter, the host operating system views the two devices as if they were both "masters" on two separate ports. This means both drives behave as if they are Device 0 (master) devices.

Serial ATA drives are designed for easy installation. It is usually not necessary to set any jumpers on the drive for proper operation; however, if you connect the drive and receive a "drive not detected" error, your SATA-equipped motherboard or host adapter may use a chipset that does not support SATA speed autonegotiation. If you have a motherboard or host adapter that does not support autonegotiation:

- Install a jumper as shown in Figure 2 below to limit the data transfer rate to 1.5 Gbits per second (and leave the drive connected to the SATA-equipped motherboard or host adapter that doesn't support autonegotiation) or
- Install a SATA host adapter that supports autonegotiation, leave the drive jumper block set to "Normal operation" (see Figure 2 below), and connect the drive to that adapter. This option has the benefit of not limiting the drive to a 1.5 Gbits/sec transfer rate.



SATA interface connector

Figure 2. Jumper options

#### 3.3 Serial ATA cables and connectors

The Serial ATA interface cable consists of four conductors in two differential pairs, plus three ground connections. The cable size may be 30 to 26 AWG with a maximum length of one meter (39.37 inches). See Table 4 for connector pin definitions. Either end of the SATA signal cable can be attached to the drive or host.

For direct backplane connection, the drive connectors are inserted directly into the host receptacle. The drive and the host receptacle incorporate features that enable the direct connection to be hot pluggable and blind mateable.

For installations which require cables, you can connect the drive as illustrated in Figure 3.




Figure 3. Attaching SATA cabling

Each cable is keyed to ensure correct orientation. NL35 Series 7200.2 Serial ATA drives support latching SATA connectors.

# 3.4 Drive mounting

You can mount the drive in any orientation using four screws in the side-mounting holes or four screws in the bottom-mounting holes. See Figure 4 on page 17 for drive mounting dimensions. Follow these important mounting precautions when mounting the drive:

- Allow a minimum clearance of 0.030 inches (0.76 mm) around the entire perimeter of the drive for cooling.
- Use only 6-32 UNC mounting screws.
- The screws should be inserted no more than 0.150 inch (3.81 mm) into the bottom or side mounting holes.
- Do not overtighten the mounting screws (maximum torque: 6 inch-lb).




Figure 4. Mounting dimensions—top, side and end view

# 4.0 Serial ATA (SATA) interface

These drives use the industry-standard Serial ATA interface that supports FIS data transfers. It supports ATA programmed input/output (PIO) modes 0–4; multiword DMA modes 0–2, and Ultra DMA modes 0–6.

For detailed information about the Serial ATA interface, refer to the "Serial ATA: High Speed Serialized AT Attachment" specification.

# 4.1 Hot-Plug compatibility

NL35 Series 7200.2 Serial ATA drives incorporate connectors which enable you to hot plug these drives in accordance with the Serial ATA II: Extension to Serial ATA 1.0a specification. This specification can be downloaded from www.serialata.org.

# 4.2 Serial ATA device plug connector pin definitions

Table 4 summarizes the signals on the Serial ATA interface and power connectors..

Table 4: Serial ATA connector pin definitions

Segment	Pin	Function	Definition	
	S1	Ground	2nd mate	
	S2	A+	Differential signal pair A from Phy	
	S3	A-		
	S4	Ground	2nd mate	
	S5	B-	Differential signal pair B from Phy	
	S6	B+		
Signal	S7	Ground	2nd mate	
Key and spacing separate signal and power segments				
	P1	V <sub>33</sub>	3.3V power	
	P2	V <sub>33</sub>	3.3V power	
	P3	V <sub>33</sub>	3.3V power, pre-charge, 2nd mate	
	P4	Ground	1st mate	
	P5	Ground	2nd mate	
	P6	Ground	2nd mate	
	P7	V <sub>5</sub>	5V power, pre-charge, 2nd mate	
Power	P8	V <sub>5</sub>	5V power	
	P9	V <sub>5</sub>	5V power	
	P10	Ground	2nd mate	
	P11	Ground or LED signal	If grounded, drive does not use deferred spin	
	P12	Ground	1st mate.	
	P13	V <sub>12</sub>	12V power, pre-charge, 2nd mate	
	P14	V <sub>12</sub>	12V power	
	P15	V <sub>12</sub>	12V power	

#### Notes:

- 1. All pins are in a single row, with a 1.27 mm (0.050") pitch.
- 2. The comments on the mating sequence apply to the case of backplane blindmate connector only. In this case, the mating sequences are:
  - the ground pins P4 and P12.
  - the pre-charge power pins and the other ground pins.
  - · the signal pins and the rest of the power pins.
- 3. There are three power pins for each voltage. One pin from each voltage is used for pre-charge when installed in a blind-mate backplane configuration.
- 4. All used voltage pins (V<sub>x</sub>) must be terminated.

# 4.3 Supported ATA commands

The following table lists Serial ATA standard commands that the drive supports. For a detailed description of the ATA commands, refer to the Serial ATA: High Speed Serialized AT Attachment specification. See "S.M.A.R.T. commands" on page 27.for details and subcommands used in the S.M.A.R.T. implementation.

Table 5: Supported ATA commands

Command name	Command code (in hex)
Check Power Mode	98 <sub>H</sub> or E5 <sub>H</sub>
Device Configuration Freeze Lock	B1 <sub>H</sub> / C1 <sub>H</sub>
Device Configuration Identify	B1 <sub>H</sub> / C2 <sub>H</sub>
Device Configuration Restore	B1 <sub>H</sub> / C0 <sub>H</sub>
Device Configuration Set	B1 <sub>H</sub> / C3 <sub>H</sub>
Device Reset	08 <sub>H</sub>
Download Microcode	92 <sub>H</sub>
Execute Device Diagnostics	90 <sub>H</sub>
Flush Cache	E7 <sub>H</sub>
Flush Cache Extended	EA <sub>H</sub>
Format Track	50 <sub>H</sub>
Identify Device	EC <sub>H</sub>
Idle	97 <sub>H</sub> or E3 <sub>H</sub>
Idle Immediate	95 <sub>H</sub> or E1 <sub>H</sub>
Initialize Device Parameters	91 <sub>H</sub>
Read Buffer	E4 <sub>H</sub>
Read DMA	C8 <sub>H</sub>
Read DMA Extended	25 <sub>H</sub>
Read DMA Without Retries	C9 <sub>H</sub>
Read Log Ext	2F <sub>H</sub>
Read Multiple	C4 <sub>H</sub>
Read Multiple Extended	29 <sub>H</sub>
Read Native Max Address	F8 <sub>H</sub>
Read Native Max Address Extended	27 <sub>H</sub>
Read Sectors	20 <sub>H</sub>
Read Sectors Extended	24 <sub>H</sub>
Read Sectors Without Retries	21 <sub>H</sub>
Read Verify Sectors	40 <sub>H</sub>
Read Verify Sectors Extended	42 <sub>H</sub>
Read Verify Sectors Without Retries	41 <sub>H</sub>
Recalibrate	10 <sub>H</sub>
Security Disable Password	F6 <sub>H</sub>
Security Erase Prepare	F3 <sub>H</sub>

Command name	Command code (in hex)
Security Erase Unit	F4 <sub>H</sub>
Security Freeze	F5 <sub>H</sub>
Security Set Password	F1 <sub>H</sub>
Security Unlock	F2 <sub>H</sub>
Seek	70 <sub>H</sub>
Set Features	EF <sub>H</sub>
Set Max Address	F9 <sub>H</sub>
Note: Individual Set Max Address commands are identified by the value placed in the Set Max Features register as defined to the right.	Address: 00 <sub>H</sub> Password: 01 <sub>H</sub> Lock: 02 <sub>H</sub> Unlock: 03 <sub>H</sub> Freeze Lock: 04 <sub>H</sub>
Set Max Address Extended	37 <sub>H</sub>
Set Multiple Mode	C6 <sub>H</sub>
Sleep	99 <sub>H</sub> or E6 <sub>H</sub>
S.M.A.R.T. Disable Operations	B0 <sub>H</sub> / D9 <sub>H</sub>
S.M.A.R.T. Enable/Disable Autosave	B0 <sub>H</sub> / D2 <sub>H</sub>
S.M.A.R.T. Enable Operations	B0 <sub>H</sub> / D8 <sub>H</sub>
S.M.A.R.T. Execute Offline	B0 <sub>H</sub> / D4 <sub>H</sub>
S.M.A.R.T. Read Attribute Thresholds	B0 <sub>H</sub> / D1 <sub>H</sub>
S.M.A.R.T. Read Data	B0 <sub>H</sub> / D0 <sub>H</sub>
S.M.A.R.T. Read Log Sector	B0 <sub>H</sub> / D5 <sub>H</sub>
S.M.A.R.T. Return Status	B0 <sub>H</sub> / DA <sub>H</sub>
S.M.A.R.T. Save Attribute Values	B0 <sub>H</sub> / D3 <sub>H</sub>
S.M.A.R.T. Write Log Sector	B0 <sub>H</sub> / D6 <sub>H</sub>
Standby	96 <sub>H</sub> or E2 <sub>H</sub>
Standby Immediate	94 <sub>H</sub> or E0 <sub>H</sub>
Write Buffer	E8 <sub>H</sub>
Write DMA	CA <sub>H</sub>
Write DMA Extended	35 <sub>H</sub>
Write DMA FUA Extended	CD <sub>H</sub>
Write DMA Without Retries	CB <sub>H</sub>
Write Log Extended	3F <sub>H</sub>
Write Multiple	C5 <sub>H</sub>
Write Multiple Extended	39 <sub>H</sub>
Write Multiple FUA Extended	CE <sub>H</sub>
Write Sectors	30 <sub>H</sub>
Write Sectors Without Retries	31 <sub>H</sub>
Write Sectors Extended	34 <sub>H</sub>

# 4.3.1 Identify Device command

The Identify Device command (command code  $EC_H$ ) transfers information about the drive to the host following power up. The data is organized as a single 512-byte block of data, whose contents are shown in Table 5 on page 21. All reserved bits or words should be set to zero. Parameters listed with an "x" are drive-specific or vary with the state of the drive. See Section 2.0 on page 3 for default parameter settings.

The following commands contain drive-specific features that may not be included in the Serial ATA specification.

Word	Description	Value	
0	Configuration information:  • Bit 15: 0 = ATA; 1 = ATAPI  • Bit 7: removable media  • Bit 6: removable controller  • Bit 0: reserved	0C5A <sub>H</sub>	
1	Number of logical cylinders	16,383	
2	ATA-reserved	0000 <sub>H</sub>	
3	Number of logical heads	16	
4	Retired	0000 <sub>H</sub>	
5	Retired	0000 <sub>H</sub>	
6	Number of logical sectors per logical track: 63	003F <sub>H</sub>	
7–9	Retired	0000 <sub>H</sub>	
10–19	Serial number: (20 ASCII characters, 0000 <sub>H</sub> = none)	ASCII	
20	Retired	0000 <sub>H</sub>	
21	Retired	0400 <sub>H</sub>	
22	Obsolete	0000 <sub>H</sub>	
23–26	Firmware revision (8 ASCII character string, padded with blanks to end of string)	x.xx	
27–46	Drive model number: (40 ASCII characters, padded with blanks to end of string)	ST3500641NS ST3500841NS	
47	(Bits 7–0) Maximum sectors per interrupt on Read multiple and Write multiple (16)	8010 <sub>H</sub>	
48	Reserved	0000 <sub>H</sub>	
49	Standard Standby timer, IORDY supported and may be disabled	2F00 <sub>H</sub>	
50	ATA-reserved	0000 <sub>H</sub>	
51	PIO data-transfer cycle timing mode	0200 <sub>H</sub>	
52	Retired	0200 <sub>H</sub>	
53	Words 54–58, 64–70 and 88 are valid	0007 <sub>H</sub>	
54	Number of current logical cylinders	xxxx <sub>H</sub>	
55	Number of current logical heads	xxxx <sub>H</sub>	
56	Number of current logical sectors per logical track	xxxx <sub>H</sub>	
57–58	Current capacity in sectors	xxxx <sub>H</sub>	
59	Number of sectors transferred during a Read Multiple or Write Multiple command	xxxx <sub>H</sub>	

Word	Description	Value	
60–61	Total number of user-addressable LBA sectors available (see Section 2.1 for related information)  *Note: The maximum value allowed in this field is: 0FFFFFFFh (268,435,455 sectors, 137 Gbytes). Drives with capacities over 137 Gbytes will have 0FFFFFFFh in this field and the actual number of user-addressable LBAs specified in words 100-103. This is required for drives that support the 48-bit addressing feature.	0FFFFFFFh*	
62	Retired	0000 <sub>H</sub>	
63	Multiword DMA active and modes supported (see note following this table)	<i>xx</i> 07 <sub>H</sub>	
64	Advanced PIO modes supported (modes 3 and 4 supported)	0003 <sub>H</sub>	
65	Minimum multiword DMA transfer cycle time per word (120 nsec)	0078 <sub>H</sub>	
66	Recommended multiword DMA transfer cycle time per word (120 nsec)	0078 <sub>H</sub>	
67	Minimum PIO cycle time without IORDY flow control (240 nsec)	00F0 <sub>H</sub>	
68	Minimum PIO cycle time with IORDY flow control (120 nsec)	0078 <sub>H</sub>	
69–74	ATA-reserved	0000 <sub>H</sub>	
75	Queue depth	0000 <sub>H</sub>	
76	Serial ATA capabilities	xxxx <sub>H</sub>	
77	Reserved for future Serial ATA definition	xxxx <sub>H</sub>	
78	Serial ATA features supported	xxxx <sub>H</sub>	
79	Serial ATA features enabled	xxxx <sub>H</sub>	
80	Major version number	003E <sub>H</sub>	
81	Minor version number	0000 <sub>H</sub>	
82	Command sets supported	364B <sub>H</sub>	
83	Command sets supported	7C03 <sub>H</sub>	
84	Command sets support extension	4003 <sub>H</sub>	
85	Command sets enabled	30 <i>xx</i> <sub>H</sub>	
86	Command sets enabled	0001 <sub>H</sub>	
87	Command sets enable extension	4000 <sub>H</sub>	
88	Ultra DMA support and current mode (see note following this table)	xx3F <sub>H</sub>	
89	Security erase time	0000 <sub>H</sub>	
90	Enhanced security erase time	0000 <sub>H</sub>	
92	Master password revision code	FFFE <sub>H</sub>	
93	Hardware reset value (see description following this table)		
95–99	ATA-reserved	0000 <sub>H</sub>	
100– 103	Total number of user-addressable LBA sectors available (see Section 2.1 for related information). These words are required for drives that support the 48-bit addressing feature. Maximum value: 0000FFFFFFFFFFh.	ST3500641NS = 976,773,168 ST3500841NS = 976,773,168	
104– 127	ATA-reserved	0000 <sub>H</sub>	
128	Security status	0001 <sub>H</sub>	

Word	Description	Value
129– 159	Seagate-reserved	xxxx <sub>H</sub>
160– 254	ATA-reserved	0000 <sub>H</sub>
255	Integrity word	xxA5 <sub>H</sub>

Note. Advanced Power Management (APM) and Automatic Acoustic Management (AAM) features are not supportedNote. See the bit descriptions below for words 63, 88, and 93 of the Identify Drive data.

Description	Description (if bit is set to 1)			
	Bit	Word 63		
	0	Multiword DMA mode 0 is supported.		
	1	Multiword DMA mode 1 is supported.		
	2	Multiword DMA mode 2 is supported.		
	8	Multiword DMA mode 0 is currently active.		
	9	Multiword DMA mode 1 is currently active.		
	10	Multiword DMA mode 2 is currently active.		
	Bit	Word 88		
-	0	Ultra DMA mode 0 is supported.		
	1	Ultra DMA mode 1 is supported.		
	2	Ultra DMA mode 2 is supported.		
;	3	Ultra DMA mode 3 is supported.		
	4	Ultra DMA mode 4 is supported.		
	5	Ultra DMA mode 5 is supported.		
	6	Ultra DMA mode 6 is supported.		
	8	Ultra DMA mode 0 is currently active.		
!	9	Ultra DMA mode 1 is currently active.		
	10	Ultra DMA mode 2 is currently active.		
	11	Ultra DMA mode 3 is currently active.		
	12	Ultra DMA mode 4 is currently active.		
	13	Ultra DMA mode 5 is currently active.		
	14	Ultra DMA mode 6 is currently active.		

#### 4.3.2 Set Features command

This command controls the implementation of various features that the drive supports. When the drive receives this command, it sets BSY, checks the contents of the Features register, clears BSY and generates an interrupt. If the value in the register does not represent a feature that the drive supports, the command is aborted. Power-on default has the read look-ahead and write caching features enabled. The acceptable values for the Features register are defined as follows:

#### Table 6: Set Features command values

02<sub>H</sub> Enable write cache (default).

03<sub>H</sub> Set transfer mode (based on value in Sector Count register).

Sector Count register values:

00<sub>H</sub> Set PIO mode to default (PIO mode 2).

01<sub>H</sub> Set PIO mode to default and disable IORDY (PIO mode 2).

08<sub>H</sub> PIO mode 0

09<sub>H</sub> PIO mode 1

0A<sub>H</sub> PIO mode 2

0B<sub>H</sub> PIO mode 3

0C<sub>H</sub> PIO mode 4 (default)

20<sub>H</sub> Multiword DMA mode 0

21<sub>H</sub> Multiword DMA mode 1

22<sub>H</sub> Multiword DMA mode 2

40<sub>H</sub> Ultra DMA mode 0

41<sub>H</sub> Ultra DMA mode 1

42<sub>H</sub> Ultra DMA mode 2

43<sub>H</sub> Ultra DMA mode 3

44<sub>H</sub> Ultra DMA mode 4

45<sub>H</sub> Ultra DMA mode 5

46<sub>H</sub> Ultra DMA mode 6

10<sub>H</sub> Enable use of SATA features

55<sub>H</sub> Disable read look-ahead (read cache) feature.

82<sub>H</sub> Disable write cache

90<sub>H</sub> Disable use of SATA features

AA<sub>H</sub> Enable read look-ahead (read cache) feature (default).

F1<sub>H</sub> Report full capacity available

**Note.** At power-on, or after a hardware or software reset, the default values of the features are as indicated above.

#### 4.3.3 S.M.A.R.T. commands

S.M.A.R.T. provides near-term failure prediction for disc drives. When S.M.A.R.T. is enabled, the drive monitors predetermined drive attributes that are susceptible to degradation over time. If self-monitoring determines that a failure is likely, S.M.A.R.T. makes a status report available to the host. Not all failures are predictable. S.M.A.R.T. predictability is limited to the attributes the drive can monitor. For more information on S.M.A.R.T. commands and implementation, see the *Draft ATA-5 Standard*.

SeaTools diagnostic software activates a built-in drive self-test (DST S.M.A.R.T. command for D4<sub>H</sub>) that eliminates unnecessary drive returns. The diagnostic software ships with all new drives and is also available at: <a href="http://seatools.seagate.com">http://seatools.seagate.com</a>.

You must have a recent BIOS or software package that supports S.M.A.R.T. to use this S.M.A.R.T. commands. The table below shows the S.M.A.R.T. command codes that the drive uses.

Table 7: S.M.A.R.T. commands

Code in features register	S.M.A.R.T. command
D0 <sub>H</sub>	S.M.A.R.T. Read Data
D2 <sub>H</sub>	S.M.A.R.T. Enable/Disable Attribute Autosave
D3 <sub>H</sub>	S.M.A.R.T. Save Attribute Values
D4 <sub>H</sub>	S.M.A.R.T. Execute Off-line Immediate (runs DST)
D5 <sub>H</sub>	S.M.A.R.T. Read Log Sector
D6 <sub>H</sub>	S.M.A.R.T. Write Log Sector
D8 <sub>H</sub>	S.M.A.R.T. Enable Operations
D9 <sub>H</sub>	S.M.A.R.T. Disable Operations
DA <sub>H</sub>	S.M.A.R.T. Return Status

**Note.** If an appropriate code is not written to the Features Register, the command is aborted and 0x04 (abort) is written to the Error register.

#### 4.3.3.1 S.M.A.R.T. Command Transport (SCT)

NL35 Series 7200.2 Serial ATA drives implement SCT technologies to enable the drive to perform in a nearline storage environment.

The command transport uses log sectors to pass-through commands, to inquire about status, and to control data flow. For detailed information about SCT, refer to the T13 working draft 1701DT-N, Rev. 5 (or later). T13 working draft publications are available in PDF form at the following URL:

http://www.t13.org/docs2005/DT1701r5-SCT.pdf

Or, for the latest list of downloadable working drafts, go to the following URL and download the latest revision: http://www.t13.org/docs2005/

# 5.0 Seagate Technology support services

#### Internet

For information regarding Seagate products and services, visit <u>www.seagate.com</u>. Worldwide support is available 24 hours daily by email for your questions.

#### **Presales Support:**

Presales@Seagate.com

## **Technical Support:**

DiscSupport@Seagate.com

#### **Warranty Support:**

http://www.seagate.com/support/service/index.html

#### mySeagate

my.seagate.com is the industry's first Web portal designed specifically for OEMs and distributors. It provides self-service access to critical applications, personalized content and the tools that allow our partners to manage their Seagate account functions. Submit pricing requests, orders and returns through a single, password-protected Web interface-anytime, anywhere in the world.

# spp.seagate.com

spp.seagate.com supports Seagate resellers with product information, program benefits and sales tools. You may register for customized communications that are not available on the web. These communications contain product launch, EOL, pricing, promotions and other channel-related information. To learn more about the benefits or to register, go to spp.seagate.com, any time, from anywhere in the world.

# **Seagate Service Centers**

#### **Presales Support**

Our Presales Support staff can help you determine which Seagate products are best suited for your specific application or computer system, as well as product availability and compatibility.

#### **Technical Support**

Seagate technical support is available to assist you online at <u>support.seagate.com</u> or through one of our call centers. Have your system configuration information and your "ST" model number available.

**SeaTDD™** (+1-405-324-3655) is a telecommunications device for the deaf (TDD). You can send questions or comments 24 hours daily and exchange messages with a technical support specialist during normal business hours for the call center in your region.

# **Customer Service Operations**

#### **Warranty Service**

Seagate offers worldwide customer support for Seagate products. Seagate distributors, OEMs and other direct customers should contact their Seagate Customer Service Operations (CSO) representative for warranty-related issues. Resellers or end users of drive products should contact their place of purchase or Seagate warranty service for assistance. Have your serial number and model or part number available.

#### **Data Recovery Services**

Seagate offers data recovery services for all formats and all brands of storage media. Our data recovery services labs are currently located throughout the world. Additional information, including an online request form and data loss prevention resources, is available at <a href="http://services.seagate.com/index.aspx">http://services.seagate.com/index.aspx</a>

#### **Authorized Service Centers**

Seagate Service Centers are available on a global basis for the return of defective products. Contact your customer support representative for the location nearest you.

# **USA/Canada/Latin America support services**

For an extensive list of telephone numbers to technical support, presales and warranty service in USA/ Canada/Latin America, including business hours, go to the "Contact Us" page on <a href="https://www.seagate.com">www.seagate.com</a>.

# **Global Customer Support**

Presales, Technical, and Warranty Support

Call Center Toll-free Direct dial

USA, Canada,

and Mexico 1-800-SEAGATE +1-405-324-4700

**Data Recovery Services** 

Call Center Toll-free Direct dial FAX

USA, Canada, 1-800-475-01435 +1-905-474-2162 1-800-475-0158 and Mexico +1-905-474-2459

# **Europe, the Middle East and Africa Support Services**

For an extensive list of telephone numbers to technical support, presales and warranty service in Europe, the Middle East and Africa, go to the "Contact Us" page on <a href="https://www.seagate.com">www.seagate.com</a>.

## **Asia/Pacific Support Services**

For an extensive list of telephone numbers to technical support, presales and warranty service in Asia/Pacific, go to the "Contact Us" page on <a href="https://www.seagate.com">www.seagate.com</a>.

Index	Device Configuration Identify 21 Device Configuration Restore 21 Device Configuration Set 21		
A	Device Reset 21		
ACA 11	dimensions 17		
acceleration 9	disc surface 5		
acoustics 9	Download Microcode 21		
Active 7	<b>-</b>		
Active mode 7	E		
actuator arm 5 AFR 10	Electrical fast transient 10 Electromagnetic compatibility 11		
Agency certification 11	Electromagnetic Compatibility (EMC) 11		
altitude 8	Electromagnetic Compatibility control Regulation 11		
Ambient temperature 8	Electromagnetic Compatibility Directive (89/336/EEC		
ambient temperature 4, 5	11		
Annualized Failure Rate 10	Electromagnetic immunity 10		
Areal density 4	Electrostatic discharge 10		
ATA commands 21	electrostatic discharge (ESD) 15		
Australia/New Zealand Standard AS/NZS3548 1995	EN 55022, Class B 11		
11 Australian Communication Authority (ACA) 11	EN 55024 11		
Australian Communication Authority (ACA) 11 Australian C-Tick 11	EN 60950 11		
Australian G-nek 11 Average latency 4	Environmental specifications 8		
Average seek time 4	EPRML 4		
	error-correction algorithms 1 errors 10		
В	ESD 15		
	EU 11		
buffer 4	European Union (EU) requirements 11		
Bytes per sector 3	Execute Device Diagnostics 21		
C	F		
cables and connectors 16	-		
Cache 4	FCC verification 11 features 1		
capacity 3	Federal Communications Commission 11		
case temperature 8	Flush Cache 21		
CE mark 11	Flush Cache Extended 21		
certification 11	Format Track 21		
Check Power Mode 21	Formatted capacity 3		
Class B computing device 11 compatibility 11	,		
Conducted noise 6	G		
Conducted RF immunity 10	Gbytes 3		
Configuring the drive 15	geometry 3		
connectors 16	Gs 9		
Corrosive environment 13	Guaranteed sectors 3		
CSA C22.2 (950) 11	guaranteed sectors 3		
cycles 10	g		
Cylinders 3	Н		
D	Handling precautions 15		
	heads 3		
data-transfer rates 1	humidity 8		
DC power 5	•		
Default logical geometry 3 Device Configuration Freeze Lock 21	I		
201135 Coringaration 1 10020 Look 21	I/O data-transfer rate 4		

Identify Device 21	point-to-point 2, 16
Identify Device command 23	Power consumption 5
Idle 7, 21	power consumption 5
Idle Immediate 21	Power dissipation 5
Idle mode 5, 7	Power modes 7
IEC950 11	Power specifications 5
Information Technology Equipment (ITE) 11	Power-management modes 7
Initialize Device Parameters 21	Power-on to Ready 5
Input noise ripple 6	precautions 15
input voltage 5	printed circuit board 15
Interface 4	programmable power management 7
interface 19	_
Interleave 4	R
Internal data-transfer rate 4	Radiated RF immunity 10
is 4	Radio and television interference 12
ISO document 7779 9	radio frequency (RF) 10
ITE 11	random seeks 5
1/	Read Buffer 21
K	Read DMA 21
Korea Ministry of Information and Communication	Read DMA Extended 21
(MIC) 11	Read DMA without Retries 21
Korean RRL 11	read errors 10
	Read Log Ext 21
L	Read Multiple 21
lotonov 4	Read Multiple Extended 21
latency 4	Read Native Max Address 21
latency time 5 LBA mode 3	Read Native Max Address Extended 21
logical geometry 3	Read Sectors 21
logical geometry 3	Read Sectors Extended 21
M	Read Sectors Without Retries 21
IAI	Read Verify Sectors 21
maintenance 10	Read Verify Sectors Extended 21
master/slave 2	Read Verify Sectors Without Retries 21
maximum temperature 8	read/write actuator arm 5
MIC 11	Read/write heads 3
mounting 17	Read/write power 5
mounting screws 8	Ready to spindle stop 5
mounting the drive 15	Recalibrate 21
N.I	Recording density 4
N	Recording method 4
noise 6	Recording technology 4
nominal power 4	relative humidity 8
Nonoperating shock 8	Reliability 10
Nonoperating vibration 9	RF 10
Nonrecoverable read errors 10	RMS read/write current 6 RoHS 12
	RRL 11
0	NNL 11
Operating power 5	S
Operating power 3 Operating shock 8	
Operating shock of Operating vibration 9	S.M.A.R.T. Disable Operations 22
Sportaining vibration o	S.M.A.R.T. Enable Operations 22
P	S.M.A.R.T. Enable/Disable Autosave 22
	S.M.A.R.T. Execute Offline 22
Physical characteristics 4	S.M.A.R.T. implementation 21

S.M.A.R.T. Read Attribute Thresholds S.M.A.R.T. Read Data 22 S.M.A.R.T. Read Log Sector 22 S.M.A.R.T. Return Status 22 S.M.A.R.T. Save Attribute Values 22 S.M.A.R.T. Write Log sector 22 S.M.A.R.T. Write Log sector 22 Safety certification 11 SATA 4, 19 screws 8 sector 3 sectors 3 Sectors per track 3 Security Disable Password 21 Security Erase Prepare 21 Security Erase Unit 22 Security Freeze 22 Security Vereze 22 Security Unlock 22 Seek 22 Seek mode 5 Seek mode power 5 Seek time 4 Seeking 5 Serial ATA 4 Serial ATA (SATA) interface 19 serial ATA ports 2 Servo electronics 5 Set Features 22 Set Max Address Extended 22 Set Max Address Extended 22 Set Multiple Mode 22 Shock 8 single-track seeks 4 Sleep 5, 7, 22 Sleep mode 7 Spinule stop 5 Spinup 5 Standby 15, 7, 22 Standby 15, 7, 22 Standby 16, 7, 22 Standby	22
<u> </u>	
<b>T</b> technical support services 29	
temperature 4, 8 temperature gradient 8	

timer 7
timers 7
Track density 4
Track-to-track 4
Track-to-track seek time 4
Tunneling Magnetoresistive (TMR) heads 1
TUV North America 11

# U

UL 1950 11

# V

Vibration 9 voltage 5 Voltage dips, interrupts 10 Voltage tolerance 6

## W

wet bulb temperature 8
Write Buffer 22
Write DMA 22
Write DMA Extended 22
Write DMA FUA Extended 22
Write DMA Without Retries 22
Write Log Extended 22
Write Multiple 22
Write Multiple Extended 22
Write Multiple FUA Extended 22
Write Sectors 22
Write Sectors Extended 22
Write Sectors Without Retries 22

