

FRONT



FreeAgent[™]Desk
EXTERNAL DRIVE


QUICK START GUIDE




THANKS FOR PURCHASING A FREEAGENT™ DESK EXTERNAL DRIVE!

CONTENTS


AC Adaptor




Firewire 800 Cable



USB Cable



FreeAgent Desk




Stand



Rubber Feet


SOLD SEPARATELY

eSATA Cable




eSATA cable not included. Ask your retailer.


POWER




CONNECT



INSTALL



OPTIONAL



BACK

WWW.SEAGATE.COM

Visit us at our Support pages for assistance with:

- **Installation:** Additional instructions and troubleshooting assistance
- **KnowledgeBase:** FAQ's, How to use this product
- **Download Center:** Installation software, utilities and diagnostics
- **Warranty Information**
- And all of your other storage needs

A comprehensive soft copy of your **Users Guide** is included with your product. Click on the **Help Icon** for assistance.

To contact support, visit us at our **Contact Us** page.

NOTE: To protect your data, always follow the safe removal procedures for your operating system when disconnecting your product.

FCC DECLARATION OF CONFORMANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

© 2008 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology, the Wave logo, and FreeAgent are trademarks or registered trademarks of Seagate Technology LLC, or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners. When referring to hard drive capacity, one gigabyte, or GB, equals one billion bytes and one terabyte, or TB, equals one thousand billion bytes when referring to hard drive capacity. Your computer's operating system may use a different standard of measurement and report a lower capacity. In addition, some of the listed capacity is used for formatting and other functions, and thus will not be available for data storage.

Seagate Technology LLC
9300 Dine Drive
Scotts Valley
CA 95066 U.S.A.

PH: 100XXXXXX 0708