


lower left



NOTES:

1. Board interconnection notes:

- denotes a single push-on type connector.
- denotes wire soldered to PC board.
- ◇ denotes molex connection. Numbers inside or along side indicate the pin number of the plug-in connector.

2. Calibration control note: ⊖ indicates internal control.

3. All controls, jacks, and displays on exterior of unit are shown with box around the name.

4. Arrow on slider of controls indicates the clockwise rotation of the control.

