



# CHAPTER 6. CIRCUIT SCHEMATICS AND PARTS LAYOUT



2/9













7/9

Reset/Driver block









9/9

Connector block




### Control PWB parts layout (Top side)






1/1





CNLIUA	1	+24V
2	DG	
3	+5VA	
4	CML	
5	CI	
6	HS	
7	RES	
8	TXOUT	
9	RXIN	
10	TELMUTE	
11	TELOUT	
12	TELIN	

CNHST/2	1	RHS
2	DG	




TEL/LIU and Hook SW PWB parts layout






2/2

Printer PWB circuit




Printer PWB parts layout





1/1


[4] Power supply PWB circuit





[5] Operation panel PWB circuit

1/1



Note: Since the parts of this PWB cannot be supplied, change it as a unit.