

## TELEVISION TECHNICAL BULLETIN

**MODELS**      66CS03H                      59CS03H                      59CSD8H

**REASON**      Due to a running change during production, the loudspeaker has been changed for a smaller type.

**ACTION**      When fitting the new, small speaker in place of the larger type, a holder has to be fitted following the procedure outlined below.

1. Remove the old speaker.
2. Stick the adhesive foam to the speaker holder.
3. Fit the new speaker into the plastic holder.
4. Fit the new speaker and holder into the cabinet.

<b><u>REF NO</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>	<b><u>PRICE CODE</u></b>
-	Loudspeaker	VSP1306PB067S	AR
-	Speaker holder	GBFL-1003BM00	AD
-	Adhesive foam	PMLT-1032BM00	AC

