

**TELEVISION TECHNICAL BULLETIN**

**MODELS** DV5161H

**SYMPTOM** Works for about one minute, then shuts down.

**CAUSE** C711.

**ACTION** Replace C711, using the part number given below.

<b><u>REF NO</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>	<b><u>PRICE CODE</u></b>
C711	Capacitor, 1nF 2000V	RC-KZ0024CEZZ	AA

**Sharp Electronics (UK) Limited**

Reference TT04082000-5

Revision 1



White – Carry out as required  
Yellow – Carry out as required and whenever the unit comes in for service  
Red – Carry out on all units