

TELEVISION TECHNICAL BULLETIN

MODELS DV5105H

SYMPTOM Will not come out of standby.

CAUSE Resistor R612 is open circuit.

ACTION Replace R612 with a 2.2R fuseable resistor and fit a 1.2R resistor in place of the wire link labeled J13.

Use the part numbers listed below.

<u>REF NO</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>	<u>PRICE CODE</u>
R613	2.2R, 1/2W Safety	RR-XZ0204BMZZ	AA
J13	1.2R, 1/2W	VRD-RA2HD1R2J	AA

