

VIEWCAM TECHNICAL BULLETIN

MODELS VLC690H VLC790H

SYMPTOM The battery may discharge after a few days if left connected to the camcorder.

CAUSE Battery discharges through IC902.

ACTION Remove R705 located on the SYSTEM PWB.