

## VIEWCAM TECHNICAL BULLETIN

---

**MODELS**      VLC690H                      VLC680H                      VLC790H                      VLC7950H  
  
                    VLC780H

**SYMPTOM**    Intermittent chewing of tapes.

**CAUSE**        Loose clinching of cassette housing shaft.

**ACTION**        Replace the Main Shaft Assembly, using the part number given below.

<b><u>REF NO</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>	<b><u>PRICE CODE</u></b>
16	Main shaft assembly	NSFTZ0093GEZZ	AM