


SERVICE NOTES

RADIO

6106T/00K/00L/00X
/88K/88L/88X



R190 05

CONTROLS

Wave range switch	1
Volume control + battery switch	2
Tuning	3

BEDIENING

Golfgebiedschakelaar	1
Volumeregelaar + batterijschakelaar	2
Afstemming	3

BEDIENUNG

Wellenbereichschalter	1
Lautstärkeregler + Batterieschalter	2
Abstimmung	3

COMMANDE

Comm. de gammes	1
Contrôle de volume + interrupteur	2
Syntonisation	3

MANDOS

Comm. de márgenes	1
Control de volumen + interruptor	2
Sintonía	3

SPECIFICATION

Loudspeaker	AD 2216Z (Z = 10 Ω)
I.P.	452 kc/s
Battery	4,5 V (3x1,5)
Consumption	6-10 mA
Dimensions	148x84x31 mm

SPESIFICATIE

Luidspreker	M.F.
Batterij	Verbruik
Afmetingen	

SPEZIFIKATION

Lautsprecher	ZF
Batterie	Verbrauch
Abmessungen	

SPECIFICATION

Haut-parleur	AD 2216Z (Z = 10 Ω)
M.F.	452 kc/s
Batterie	4,5 V (3x1,5)
Consumption	6-10 mA
Dimensions	148x84x31 mm

ESPECIFICACION

Altavoz	F.I.
Batería	Consumo
Dimensiones	



Wave ranges - Golfgebieden - Wellenbereiche - Gammes d'ondes - Márgenes de ondas

L.W. - L.G. - LW - G.O. - O.L.	: 1176 - 2000 m (255 - 150 kc/s)
M.W. - M.G. - MW - P.O. - O.M.	: 185 - 580 m (1622 - 517 kc/s)

Transistors


TS1 - 0C44	TS5 - 0C71
TS2 - 0C45	TS6, 7 - 2-0C72
TS3 - 0C45	GR1 - 0A79
TS4 - 0C71	

SERVICE INFORMATION




A


Page 20




B




C



D




CR1



CR2

S	1.	3	2	4.	5	6	7	8.	9	10.	11	12	13.	14	15.	16.	17.	18.	19.	20.	21.	22.	23.	24.	25.	
C	2.2a.	1.1a.	7.5	3.	6.	4.	8	8	9	10.	11.	12.	13.	14.	15.	16.	17	18.	19.	13.	20.	22.	22.	22.	22.	25.
R																										



R194. 57A

