

Model: CDX-C810DSP**No. 417****Subject: THE BASS LEVEL SOUND RETURNS TO
NORMAL LEVEL SOUND, EVEN WHEN BASS
LEVEL IS SET TO MAXIMUM.****Date:** March 5, 1997**Symptom:
(122)**

The Bass sound will not remain in the level it was set for. This can be seen when switching a source. Follow the steps below to check if the unit has a problem.

1. Select the source to FM, then adjust the Bass to MAX.
2. Change the source to CD and adjust the Bass setting to MAX.
3. Change the source back to FM, go back to the Bass setting, although the indicator still reads MAX. ,the actual sound has been set back to a normal Bass setting.

Solution: Replace DSP Micon IC505

REF	DESCRIPTION	PART NUMBER
IC505	μ PD78P058GC-290C-3B9	8-759-468-40

